



Changes for the Better



INVERTER

Model

FR-E700

Remarkable usability

Top level driving performance!

Compact body

# All-rounder

Easy for anybody and high performance



Mitsubishi Electric Corporation Nagoya Works is a factory certified for ISO14001 (standards for environmental management systems) and ISO9001 (standards for quality assurance management systems)



# Evolution in all functions

# Easy/powerful compact inverter

## 1 Top level driving performance in compact body

The inverter became more powerful.


### (1) High torque 200%/0.5Hz is realized by advanced magnetic flux vector control (3.7K or less)

Advancement from general-purpose magnetic flux vector control to advanced magnetic flux vector control ! Class top-level driving performance is realized.

Since V/F control and general-purpose magnetic flux vector control operations are available, operation after replacement of the conventional model (FR-E500 series) is ensured.


For the 5.5K to 15K, 150%/0.5Hz torque is realized.

### Speed/torque characteristics example



### Advanced auto tuning


Many kinds of 3 phase induction motors can be optimally controlled with Mitsubishi original "non-rotation" auto tuning function. High precision tuning is enabled even when a test operation of a machine can not be performed at parameter adjustment.



Advanced magnetic flux vector control is optimum for lift for the automated-storage requiring high torque at low speed.

### (2) Short time overload capacity is increased (200% 3s)


Short time overload capacity is increased to 200% 3s (conventional model 200% 0.5s). Overcurrent trip is less likely to occur.



An impact load placed when a running bogie steps over the bump does not affect operation.

### (3) Torque limit/current limit function

Improved torque limit/current limit function provides a machine protection, load limit, and stop-on-contact operation.



Torque limit ensures mechanical protection such as prevention of tool blade breakage.

## 2 Overriding operability

Usability was thoroughly pursued.

### (1) Improved setting dial


Mitsubishi inverter has a setting dial of course.

- The scrolling speed of the dial was made to variable for more improved operability.
- The nonslip setting dial is easier to turn.



### (2) Easy setting mode


Setting of Pr.79 Operation mode selection which select the combination of the start command and speed command can be easily made.



### (3) With a provided USB connector, setting is easily done from a personal computer using the FR Configurator (to be released)

An USB connector (mini-B connector) is provided as standard. The inverter can be easily connected without a USB-RS-485 converter. Wizard (interactive) function of the FR Configurator (inverter setup software) realizes setting support. In addition, a high-speed graph function with USB enables high speed sampling display.

Expanded advanced operability with USB and FR-Configurator



### (4) Operation panel for enclosure surface mounting is supported (to be released)

An optional operation panel for an enclosure surface mounting can be connected. In addition, an operation panel for conventional model (FR-E500 series) can be connected. The operation panel of the inverter cannot be removed.

### (5) Parameter unit FR-PU07 (option)

The FR-PU07, an optional parameter unit, can be connected as well. Setting such as direct input method with a numeric keypad, operation status indication, and help function are usable. The display language can be selected from 8 languages. Parameter setting values of maximum of three inverters can be stored. A battery pack type (available soon) allows parameter setting and parameter copy without powering on the inverter.




Features	1
Connection with Peripheral Devices	6
Standard Specifications	7
Outline Dimension Drawings	9
Terminal Connection Diagram	13
Terminal Specification Explanation	13
Operation panel	15
Parameter unit	15
FR Configurator	15
Parameter List	19
Explanations of Parameters	26
Protective Functions	49
Option and Peripheral Devices	50
Precautions for Operation/Selection	59
Precautions for Peripheral Device Selection	59
Application to Motor	64
Main Differences and Compatibilities with the FR-E500 Series	68
Warranty	69
Service	70
International FA Center	70

### 3 Enhanced expandability

Expandability catching up with the FR-A700 series is realized.

#### (1) A plug-in option is mountable

Plug-in options supporting digital input, analog output extension, and variety of communication provide scalability which is almost equivalent to the FR-A700 series. (One type of plug-in option can be mounted. An option comes with a dedicated front cover as a package.)



Compatible Plug-in Options	
• FR-A7AX E kit ...16-bit digital input	• FR-A7NC E kit ...CC-Link
• FR-A7AY E kit ...Digital output	• FR-A7ND E kit* ...DeviceNet
• FR-A7AR E kit ...Relay output	• FR-A7NP E kit* ...PROFIBUS-DP
	• FR-A7NL E kit* ...LONWORKS

\*: to be released soon

#### (2) Control terminals are selectable according to applications

Terminal cards other than standard terminal such as analog, pulse train, two port RS-485 terminal are available as options. (to be released soon)  
A crimp ring terminal type is also available. (to be released)  
A terminal card is removable and can be easily replaced from a standard terminal card.



#### (3) Support various kinds of network

EIA-485 (RS-485), ModbusRTU (equipped as standard), CC-Link, PROFIBUS-DP\*, DeviceNet\*, LONWORKS\* (option)  
\*: to be released soon  
LONWORKS® is a registered trademark of Echelon Corporation and DeviceNet® is of ODVA. Other company and product names herein are the trademarks of their respective owners.

#### (4) Break resistor can be connected to the 0.4K to 15K

A brake transistor is built-in to the 0.4K to 15K. Connecting an optional brake resistor increases regeneration capability.

### 4 Compact and space saving

Compact design expands flexibility of enclosure design.

#### (1) Compact body with high performance function

Installation size is the same as the conventional mode (FR-E500 series) in consideration of intercompatibility. (200V class 0.1K to 7.5K)



#### (2) Side by side installation saves space

Space can be saved by side by side no clearance installation\*.  
\*: Use the inverter at the ambient temperature of 40°C or less.



#### (3) Heatsink protrusion attachment option (1.5K or more) (to be released soon)

A heatsink portion of the inverter can be protruded outside the enclosure by fitting an optional heatsink protrusion attachment FR-E7CN. Protruding a hot section outside the enclosure allows selection of downsized enclosure, reducing cost for enclosure cooling equipments.

### 5 Ensured maintenance

700 series are the pioneer of long life and high reliability.

#### (1) Long-life design

- The life of cooling fan has been extended to 10 years\*1 of design life. The life of the cooling fan is further extended with ON/OFF control of the cooling fan.
- Longevity of capacitor was achieved with the adoption of a design life of 10 years\*1,\*2. (A capacitor with specification of 5000 hours at 105°C ambient temperature is adapted.)

\*1: Ambient temperature : annual average 40°C (free from corrosive gas, flammable gas, oil mist, dust and dirt) Since the design life is a calculated value, it is not a guaranteed value.  
\*2: Output current : 80% of the inverter rated current

Components	Guideline of the FR-E700 Life	Guideline of JEMA*3
Cooling fan	10 years	2 to 3 years
Main circuit smoothing capacitor	10 years	5 years
Printed board smoothing capacitor	10 years	5 years

\*3: Excerpts from "Periodic check of the transistorized inverter" of JEMA (Japan Electrical Manufacturers Association)

#### (2) Most advanced life check

- Degrees of deterioration of main circuit capacitor, control circuit capacitor, and inrush current limit circuit can be monitored.
  - Trouble can be avoided with the self-diagnostic alarm\*4 that is output when the life span is near.
- \*4: Any one of main circuit capacitor, control circuit capacitor, inrush current limit circuit or cooling fan reaches the output level, an alarm is output. Capacity of the main circuit capacitor can be measured by setting parameter at a stop and turning the power from off to on. Measuring the capacity enables an alarm to be output.

#### (3) Easy replacement of cooling fan

A cooling fan is provided on top of the inverter of all capacities requiring a cooling fan (1.5K to 15K). A cooling fan can be easily replaced without disconnecting main circuit wires.



#### (4) Combed shaped wiring cover

Since a wiring cover can be fitted after wiring, wiring work is easily done.



#### (5) Removable control terminal block

Wiring of the control circuit when replacing the same series inverter can be done by changing the terminal card.

### 6 Environment-friendly

Human and environment-friendly inverter

#### (1) EU restriction of the use of certain hazardous substances (RoHS) directive compliance

Human and environment-friendly inverter in compliant with RoHS Directive


#### (2) Filter option (to be released soon)

- The inverter with filter pack (a package of power factor improving DC reactor, common mode core and capacitive filter) conforms to the Japanese harmonic suppression guideline.
- The inverter itself can comply with the EMC Directive (2nd Environment) with the newly developed noise filter (EMC filter).

### 7 Full of useful functions

Enhanced functions for all sorts of applications

- Automatic restart after instantaneous power failure function with frequency search



Detection of coasting speed (frequency search function) prevents the motor speed from decreasing at a restart, starting the motor smoothly with less output current.

- Power-failure deceleration stop function/operation continuation at instantaneous power failure function  
The motor can be decelerated to a stop when a power failure or undervoltage occurred to prevent the motor from coasting. For fail-safe of machine tool, etc., it is effective to stop the motor when a power failure has occurred. With the newly adapted operation continuation at instantaneous power failure function, the motor continues running without coasting even if an instantaneous power failure occurs during operation.

\*: The inverter may trip and the motor may coast depending on the load condition.

- Brake sequence mode..... For mechanical brake control of the lift
- Regeneration avoidance function ..... Regenerative overvoltage is less likely to occur in the pressing machine.
- Optimum excitation control..... More energy saving is possible with the maximum motor efficiency control.
- Main circuit power supply DC input..... DC power supply can be connected.
- Enhanced I/O terminal function..... Analog input (voltage/current) can be switched. and so on

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

**Lineup**

**FR-E720**    **-0.1K-**   

Symbol	Voltage	Symbol	Number of Power Phases	Symbol	Inverter Capacity	Symbol	Protective Structure
1	100V class	None	Three-phase input	0.1K to 15K	Represents the inverter capacity "kW".	None	Enclosed-type structure IP20
2	200V class	S	Single-phase input			C	Totally enclosed structure IP40
4	400V class	W	Single-phase input (double voltage output)				


Inverter Type	Inverter Capacity	Inverter Capacity										
		0.1K	0.2K	0.4K	0.75K	1.5K	2.2K	3.7K	5.5K	7.5K	11K	15K
Three-phase 200V FR-E720-□□	Enclosed-type structure (IP20)	●	●	●	●	●	●	●	●	●	●	●
	Totally enclosed structure (IP40)	○	○	○	○	○	○	○	○	○	○	○
Three-phase 400V FR-E740-□□	Enclosed-type structure (IP20)	—	—	○	○	○	○	○	○	○	○	○
	Totally enclosed structure (IP40)	—	—	○	○	○	○	○	○	○	○	○
Single-phase 200V FR-E720S-□□*	Enclosed-type structure (IP20)	○	○	○	○	○	○	—	—	—	—	—
Single-phase 100V FR-E710W-□□*	Enclosed-type structure (IP20)	○	○	○	○	—	—	—	—	—	—	—

\*:Output of the single-phase 200V and single-phase 100V input specifications is three-phase 200V. ●:Available models ○:Models to be released —:Not available



Complies with UL, cUL, EN (LVD) standards

**Connection with Peripheral Devices**



- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

# Standard specifications

## Rating

### ● Three-phase 200V power supply

Type FR-E720-□K(-C) *7		0.1	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
Applicable motor capacity (kW) *1		0.1	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
Output	Rated capacity (kVA) *2	0.3	0.6	1.2	2.0	3.2	4.4	7.0	9.5	13.1	18.7	23.9
	Rated current (A) *6	0.8 (0.8)	1.5 (1.4)	3 (2.5)	5 (4.1)	8 (7)	11 (10)	17.5 (16.5)	24 (23)	33 (31)	47 (44)	60 (57)
	Overload current rating *3	150% 60s, 200% 3s (inverse time characteristics)										
	Voltage *4	Three-phase 200 to 240V										
Power supply	Rated input AC voltage/frequency	Three-phase 200 to 240V 50Hz/60Hz										
	Permissible AC voltage fluctuation	170 to 264V 50Hz/60Hz										
	Permissible frequency fluctuation	±5%										
	Power supply capacity (kVA) *5	0.4	0.8	1.5	2.5	4.5	5.5	9	12	17	20	28
Protective structure (JEM1030)		Enclosed type (IP20). IP40 for totally enclosed structure series.										
Cooling system		Self-cooling					Forced air cooling					
Approximate mass (kg)		0.5	0.5	0.7	1.0	1.4	1.4	1.7	4.3	4.3	9.0	9.0

\*1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.

\*2 The rated output capacity indicated assumes that the output voltage is 230V.

\*3 The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.

\*4 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about  $\sqrt{2}$  that of the power supply.

\*5 The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).

\*6 Setting 2kHz or more in Pr. 72 PWM frequency selection to perform low acoustic noise operation in the ambient temperature exceeding 40°C (totally-enclosed structure is 30°C), the rated output current is the value in parenthesis.

\*7 Totally enclosed structure series ends with -C.

## Common specifications

Control specifications	Control method		Soft-PWM control/high carrier frequency PWM control (V/F control, advanced magnetic flux vector control, general-purpose magnetic flux vector control, optimum excitation control can be selected)
	Output frequency range		0.2 to 400Hz
	Frequency setting resolution	Analog input	0.06Hz/60Hz (terminal2, 4: 0 to 10V/10bit) 0.12Hz/60Hz (terminal2, 4: 0 to 5V/9bit) 0.06Hz/60Hz (terminal4: 4 to 20mA/10bit)
		Digital input	0.01Hz
	Frequency accuracy	Analog input	Within ±0.5% of the max. output frequency (25°C ±10°C)
		Digital input	Within 0.01% of the set output frequency
	Voltage/frequency characteristics		Base frequency can be set from 0 to 400Hz Constant torque/variable torque pattern can be selected
	Starting torque		200% or more (at 0.5Hz)...when advanced magnetic flux vector control is set (3.7K or less)
	Torque boost		Manual torque boost
	Acceleration/deceleration time setting		0.01 to 360s, 0.1 to 3600s (acceleration and deceleration can be set individually), linear or S-pattern acceleration/deceleration mode can be selected.
DC injection brake		Operation frequency (0 to 120Hz), operation time (0 to 10s), operation voltage (0 to 30%) variable	
Stall prevention operation level		Operation current level can be set (0 to 200% adjustable), whether to use the function or not can be selected	
Operation specifications	Frequency setting signal	Analog input	Two points Terminal 2: 0 to 10V, 0 to 5V can be selected Terminal 4: 0 to 10V, 0 to 5V, 4 to 20mA can be selected
		Digital input	Entered from operation panel and parameter unit
	Start signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.
	Input signal		Seven points You can select from among multi-speed selection, remote setting, stop-on contact selection, second function selection, terminal 4 input selection, JOG operation selection, PID control valid terminal, brake opening completion signal, external thermal input, PU-external operation switchover, V/F switchover, output stop, start self-holding selection, forward rotation, reverse rotation command, inverter reset, PU-NET operation switchover, external-NET operation switchover, command source switchover, inverter operation enable signal, and PU operation external interlock
	Operational functions		Maximum/minimum frequency setting, frequency jump operation, external thermal relay input selection, automatic restart after instantaneous power failure operation, forward/reverse rotation prevention, remote setting, brake sequence, second function, multi-speed operation, stop-on contact control, droop control, regeneration avoidance, slip compensation, operation mode selection, offline auto tuning function, PID control, computer link operation (RS-485)
	Output signal points	Open collector output	Two points
		Relay output	One point
	Operating status		You can select from among inverter operation, up-to-frequency, overload alarm, output frequency detection, regenerative brake prealarm, electronic thermal relay function prealarm, inverter operation ready, output current detection, zero current detection, PID lower limit, PID upper limit, PID forward/reverse rotation output, brake opening request, fan alarm, heatsink overheat pre-alarm, deceleration at an instantaneous power failure, PID control activated, during retry, life alarm, current average value monitor, remote output, minor failure output, alarm output, alarm output 3, and maintenance timer alarm
	For meter Output points	Pulse output	MAX 2.4kHz: one point
	For meter		You can select from among output frequency, motor current (steady), output voltage, frequency setting, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, reference voltage output, motor load factor, PID set point, PID measured value, output power Pulse train output (1440 pulses/s/full scale)
Indication	Operation panel Parameter unit (FR-PU07)	Operating status	You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, and cumulative power
		Alarm definition	Alarm definition is displayed when the protective function is activated and the past 8 alarm definitions (output voltage/current/frequency/cumulative energization time right before the protective function was activated) are stored
	Additional display by the parameter unit (FR-PU04/FR-PU07) only	Operating status	Not used
		Alarm definition	Output voltage/current/frequency/cumulative energization time immediately before protective function is activated
		Interactive guidance	Function (help) for operation guide
Protective/warning function			<Protective functions> Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during constant speed, overvoltage during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent, output phase failure, external thermal relay operation, option alarm, parameter error, PU disconnection, retry count excess, CPU alarm, brake transistor alarm, inrush resistance overheat, communication error, analog input error, USB communication error, brake sequence error 4 to 7 <Warning functions> Fan alarm*2, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error, regenerative brake prealarm, electronic thermal relay function prealarm, maintenance output, undervoltage
Environment	Ambient temperature		-10°C to +50°C (non-freezing) (-10°C to +40°C for totally-enclosed structure feature) *3
	Ambient humidity		90%RH maximum (non-condensing)
	Storage temperature*1		-20°C to +65°C
	Atmosphere		Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)
	Altitude/vibration		Maximum 1000m above sea level, 5.9m/s <sup>2</sup> or less


\*1 Temperatures applicable for a short time, e.g. in transit.

\*2 As the FR-E720-0.75K or less is not provided with the cooling fan, this alarm does not function.


\*3 When using the inverters at the ambient temperature of 40°C or less, the inverters can be installed closely attached (0cm clearance).

# Outline Dimension Drawings


●FR-E720-0.1K, 0.2K, 0.4K, 0.75K




●FR-E720-1.5K, 2.2K



●FR-E720-3.7K





●FR-E720-5.5K, 7.5K




- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry


●FR-E720-11K, 15K



When used with the plug-in option




\* When the FR-A7NC E kit is mounted, a terminal block protrudes making the depth approx. 2mm greater.




Inverter Type	W	W1	H	H1	D	D1
FR-E720-11K, 15K	220	195	260	244	190	205.1

(Unit: mm)

●Parameter unit (option) (FR-PU07)




●Parameter unit (option) (FR-PU04)



- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

# Terminal Connection Diagram



**Note**

- To prevent a malfunction caused by noise, separate the signal cables more than 10cm from the power cables.
- After wiring, wire offcuts must not be left in the inverter.  
 Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean. When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.

# Terminal Specification Explanation

Type	Terminal Symbol	Terminal Name	Description			
Main circuit	R/L1, S/L2, T/L3	AC power input	Connect to the commercial power supply. Keep these terminals open when using the high power factor converter (FR-HC) or power regeneration common converter (FR-CV).			
	U, V, W	Inverter output	Connect a three-phase squirrel-cage motor.			
	P/+, PR	Brake resistor connection	Connect a brake transistor (MRS, MYS, FR-ABR) across terminals P/+ -PR. (The brake resistor can not be connected to the 0.1K or 0.2K)			
	P/+, N/-	Brake unit connection	Connect the brake unit (FR-BU2), power regeneration common converter (FR-CV) or high power factor converter (FR-HC).			
	P/+, P1	DC reactor connection	Remove the jumper across terminals P/+ -P1 and connect a DC reactor.			
		Earth (Ground)	For earthing (grounding) the inverter chassis. Must be earthed (grounded).			
Control circuit/input signal	Contact input	STF	Forward rotation start	Turn on the STF signal to start forward rotation and turn it off to stop.	When the STF and STR signals are turned on simultaneously, the stop command is given.	
		STR	Reverse rotation start	Turn on the STR signal to start reverse rotation and turn it off to stop.		
		RH, RM, RL	Multi-speed selection	Multi-speed can be selected according to the combination of RH, RM and RL signals.		
		MRS	Output stop	Turn on the MRS signal (20ms or more) to stop the inverter output. Use to shut off the inverter output when stopping the motor by electromagnetic brake.		
		RES	Reset	Used to reset alarm output provided when protective circuit is activated. Turn on the RES signal for more than 0.1s, then turn it off. Initial setting is for reset always. By setting Pr. 75, reset can be set to enabled only at an inverter alarm occurrence. Recover about 1s after reset is cancelled.		
		SD	Contact input common (Sink)	Common terminal for contact input terminal (sink logic) and terminal FM. Common output terminal for 24VDC 0.1A power supply (PC terminal). Isolated from terminals 5 and SE.		
		PC	External transistor common, 24VDC power supply, contact input common (source)	When connecting the transistor output (open collector output), such as a programmable controller (PLC), when sink logic is selected, connect the external power supply common for transistor output to this terminal to prevent a malfunction caused by undesirable currents. Can be used as 24VDC 0.1A power supply. When source logic has been selected, this terminal serves as a contact input common.		
	Frequency setting	10	Frequency setting power supply	Used as power supply when connecting potentiometer for frequency setting (speed setting) from outside of the inverter.	5.2VDC ± 0.2V permissible load current 10mA	
		2	Frequency setting (voltage)	Inputting 0 to 5VDC (or 0 to 10V) provides the maximum output frequency at 5V (10V) and makes input and output proportional. Use Pr. 73 to switch between input 0 to 5VDC (initial setting) and 0 to 10VDC input.	Input resistance 10kΩ ± 1kΩ Permissible maximum voltage 20VDC	
		4	Frequency setting (current)	Inputting 0 to 20mA (or 0 to 5V / 0 to 10V) provides the maximum output frequency at 20mA makes input and output proportional. This input signal is valid only when the AU signal is on (terminal 2 input is invalid). Use Pr. 267 to switch from among input 4 to 20mA (initial setting), 0 to 5VDC and 0 to 10VDC. Set the voltage/current input switch in the "V" position to select voltage input (0 to 5V/0 to 10V).	Voltage input: Input resistance 10kΩ ± 1kΩ Permissible maximum voltage 20VDC Current input: Input resistance 233Ω ± 5Ω Maximum permissible current 30mA.	
		5	Frequency setting common	Common terminal for the frequency setting signals (terminals 2 or 4). Do not earth (ground).		
	Control circuit/output signal	Relay	A, B, C	Relay output (fault output)	1 changeover contact output indicates that the inverter fault occurs. Fault: discontinuity across B-C (continuity across A-C), Normal: continuity across B-C (discontinuity across A-C) Contact capacity 230VAC 0.3A (power factor = 0.4) 30VDC 0.3A	
		Open collector	RUN	Inverter running	Switched low when the inverter output frequency is equal to or higher than the starting frequency (initial value 0.5Hz). Switched high during stop or DC injection brake operation.*1	Permissible load 24VDC (Maximum 27VDC) 0.1A (a voltage drop is 3.4V maximum when the signal is on)
			FU	Frequency detection	Switched low when the inverter output frequency is equal to or higher than the preset detected frequency and high when less than the preset detected frequency.*1	
		Pulse	FM	For meter	Select one e.g. output frequency from monitor items.*2 The output signal is proportional to the magnitude of the corresponding monitoring item.	Permissible load current 1mA 1440 pulses/s at 60Hz
Communication	—	PU connector	With the PU connector, RS-485 communication can be made. · Conforming standard: EIA-485 (RS-485) · Transmission format: Multi-drop link · Communication speed: 4800 to 38400bps · Overall extension: 500m			
	—	USB connector	The FR Configurator can be operated by connecting the inverter to the personal computer through USB. · Interface: conforms to USB1.1 · Transmission Speed: 12Mbps · Connector: USB connector (Mini-B receptacle)			

\*1 Low indicates that the open collector output transistor is on (conducts). High indicates that the transistor is off (does not conduct).

\*2 Not output during inverter reset.



### Note

- Set Pr. 267 and a voltage/current input switch correctly, then input an analog signal in accordance with the setting. Applying a voltage with voltage/current input switch in "I" position (current input is selected) or a current with switch in "V" position (voltage input is selected) could cause component damage of the inverter or analog circuit of output devices.
- The inverter will be damaged if power is applied to the inverter output terminals (U, V, W). Never perform such wiring.
-  indicates that terminal functions can be selected using Pr. 178 to Pr. 192 (I/O terminal function selection).
- Terminal names and terminal functions are those of the factory set.

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

# Explanation of the Operation Panel

The operation panel cannot be removed from the inverter.

### Operation mode indication

PU: Lit to indicate PU operation mode.  
 EXT: Lit to indicate external operation mode.  
 NET: Lit to indicate network operation mode.

### Unit indication

Hz: Lit to indicate frequency.  
 ALit to indicate current.  
 (Off to indicate voltage and flicker to indicate set frequency monitor.)

### Monitor (4-digit LED)

Shows the frequency, parameter number, etc.

### Setting dial

(Setting dial: Mitsubishi inverter dial)  
 Used to change the frequency setting and parameter values.

Press to display the following.

- Displays the set frequency in the monitor mode
- Currently set value is displayed during calibration
- Displays the order in the error history mode



### Mode switchover

Used to change each setting mode.

Pressing **PU/EXT** simultaneously changes the operation mode.  
 Pressing for a while (2s) can lock operation.

### Determination of each setting

If pressed during operation, monitor changes as below;



### Operating status display

Lit or flicker during inverter operation. \*

\* On: Indicates that forward rotation operation is being performed.  
 Slow flickering (1.4s cycle): Reverse rotation operation  
 Fast flickering (0.2s cycle): Indicates that operation is not being performed but the **RUN** was pressed or the start command was given.  
 When the start command is given and the frequency command is less than the starting frequency.

### Parameter setting mode

Lit to indicate parameter setting mode.

### Monitor indication

Lit to indicate monitoring mode.

### Stop operation

Alarms can be reset

### Operation mode switchover


Used to switch between the PU and external operation mode.  
 When using the external operation mode (operation using a separately connected frequency setting potentiometer and start signal), press this key to light up the EXT indication.

(Press **MODE** simultaneously (0.5s) or change Pr: 79 setting to change to combined mode.)  
 PU: PU operation mode  
 EXT: External operation mode  
 Cancels PU stop also.

### Start command

The rotation direction can be selected by setting Pr: 40.


## Basic operation of the operation panel



- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry


# Explanations of Parameter unit

## Parameter unit (FR-PU07)



Key	Description
<b>PrSET</b>	Use for parameter setting Press to choose the parameter setting mode.
<b>MON</b>	First priority monitor is displayed. In the initial setting, the output frequency is displayed.
<b>ESC</b>	Operation cancel key
<b>FUNC</b>	Used to display the function menu. A variety of functions can be used on the function menu.
<b>SHIFT</b>	Used to shift to the next item in the setting or monitoring mode.
<b>0 to 9</b>	Used to enter a frequency, parameter number or set value.
<b>EXT</b>	Inverter operates in the external operation mode.
<b>PU</b>	Used to select the PU operation mode to display the frequency setting screen.
<b>▲ / ▼</b>	<ul style="list-style-type: none"> <li>• Used to keep on increasing or decreasing the running frequency. Hold down to vary the frequency.</li> <li>• Press either of these keys on the parameter setting mode screen to change the parameter setting value sequentially.</li> <li>• On the selecting screen, these keys are used to move the cursor.</li> <li>• Hold down <b>SHIFT</b> and press either of these keys to advance or return the display screen one page.</li> </ul>
<b>FWD</b>	Forward rotation command key.
<b>REV</b>	Reverse rotation command key.
<b>STOP / RESET</b>	<ul style="list-style-type: none"> <li>• Stop command key.</li> <li>• Used to reset the inverter when an alarm occurs.</li> </ul>
<b>WRITE</b>	<ul style="list-style-type: none"> <li>• Used to write a set value in the setting mode.</li> <li>• Used as a clear key in the all parameter clear or alarm history clear mode.</li> </ul>
<b>• / READ</b>	<ul style="list-style-type: none"> <li>• Used as a decimal point when entering numerical value.</li> <li>• Used as a parameter number read key in the setting mode.</li> <li>• Used as an item select key on the menu screen such as parameter list or monitoring list.</li> <li>• Used as an alarm definition display key in the alarm history display mode.</li> <li>• Used as a command voltage read key in the calibration mode.</li> </ul>

●Monitor: Merely pressing **SHIFT** calls 6 different monitor screens in sequence.




●Parameter setting: When changing 5s to 180s as the Pr. 8 Deceleration time setting




●Pr. List:

Displays the parameters list.

You can select the parameter from the list to read and write the parameter setting.



●Multiple copies: You can read the parameter settings of the inverter into the FR-PU07 and store the settings of maximum three inverters. You can also copy the stored parameter settings to another inverter of the same series.



# FR Configurator (VFD SETUP SOFTWARE)


## FR-SW3-SETUP-WJ (Windows\*2000 Professional, XP Home Edition, XP Professional supported)

FR Configurator is a software offers an easy operating environment.  
 Can be utilized effectively from inverter setting up to maintenance.  
 Parameter setting, monitoring, etc. can be performed on a display of Windows \* personal computer.  
 A personal computer and an inverter can be easily connected with a USB cable.  
 (RS-485 communication using PU connector is also available.)

\* Windows is a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.



### FR Configurator



### Startup

Desired function can be performed just after a start-up of the software.

- (1) Open the recent used System File
- (2) Perform Easy Setup
- (3) Perform each functions
- (4) Help



### Easy Setup

From station number to parameter setting, setting with wizard style dialog (interactive) is available.

Procedure for Easy Setup

- (1) System File setting
- (2) Communication setting
- (3) Inverter recognition
- (4) Control method selection
- (5) Motor setting
- (6) Start command, frequency command setting
- (7) Parameter setting



### Navigation area

In Navigation area, switching ONLINE/OFFLINE and changing operation mode can be performed.


- (1) Frequency setting and forward/reverse rotation [Test operation]
- (2) Display the connected inverter in tree view [System List]
- (3) Function setting without regard to parameter number [Basic setting]



### Monitor area

In Monitor area, inverter status can be monitored.

- (1) Display monitor data in waveform
- (2) Display current waveform with High Speed graph function [Graph]



### System area

In System area, parameter setting, Diagnosis, Troubleshooting, etc. can be performed.

- (1) Parameter reading, writing, verification, Functional List and Individual List display are available. [Parameter List]
- (2) Convert parameter setting from conventional models [Convert]



### Setting wizard

Setting wizard can set parameters with wizard style dialog (interactive). Inputting or selecting required items for each function, parameter setting can be made, without regard to parameter number.

### Help

Displays operating instructions and details of each parameters.

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

# Parameter List

For simple variable-speed operation of the inverter, the initial setting of the parameters may be used as they are. Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check can be made from the operation panel. For details of parameters, refer to the instruction manual.



## REMARKS

- ⊙ indicates simple mode parameters. (initially set to extended mode)
- The shaded parameters in the table allow its setting to be changed during operation even if "0" (initial value) is set in Pr. 77 Parameter write selection.

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Basic functions	⊙ 0	Torque boost	0 to 30%	0.1%	6/4/3/2% *1	26	
	⊙ 1	Maximum frequency	0 to 120Hz	0.01Hz	120Hz	26	
	⊙ 2	Minimum frequency	0 to 120Hz	0.01Hz	0Hz	26	
	⊙ 3	Base frequency	0 to 400Hz	0.01Hz	60Hz	26	
	⊙ 4	Multi-speed setting (high speed)	0 to 400Hz	0.01Hz	60Hz	26	
	⊙ 5	Multi-speed setting (middle speed)	0 to 400Hz	0.01Hz	30Hz	26	
	⊙ 6	Multi-speed setting (low speed)	0 to 400Hz	0.01Hz	10Hz	26, 43	
	⊙ 7	Acceleration time	0 to 3600/360s	0.1/0.01s	5/10s *2	27	
	⊙ 8	Deceleration time	0 to 3600/360s	0.1/0.01s	5/10s *2	27	
DC injection brake	⊙ 9	Electronic thermal O/L relay	0 to 500A	0.01A	Rated inverter current	27	
	10	DC injection brake operation frequency	0 to 120Hz	0.01Hz	3Hz	27	
	11	DC injection brake operation time	0 to 10s	0.1s	0.5s	27	
JOG operation	12	DC injection brake operation voltage	0 to 30%	0.1%	6/4/2% *3	27	
	— 13	Starting frequency	0 to 60Hz	0.01Hz	0.5Hz	27	
	— 14	Load pattern selection	0 to 3	1	0	28	
Acceleration/ deceleration time	15	Jog frequency	0 to 400Hz	0.01Hz	5Hz	28	
	16	Jog acceleration/deceleration time	0 to 3600/360s	0.1/0.01s	0.5s	28	
	— 17	MRS input selection	0, 2, 4	1	0	28	
Stall prevention	— 18	High speed maximum frequency	120 to 400Hz	0.01Hz	120Hz	26	
	— 19	Base frequency voltage	0 to 1000V, 8888, 9999	0.1V	9999	26	
	20	Acceleration/deceleration reference frequency	1 to 400Hz	0.01Hz	60Hz	27	
Multi-speed setting	21	Acceleration/deceleration time increments	0, 1	1	0	27	
	22	Stall prevention operation level	0 to 200%	0.1%	150%	29	
Frequency jump	23	Stall prevention operation level compensation factor at double speed	0 to 200%, 9999	0.1%	9999	29	
	24	Multi-speed setting (speed 4)	0 to 400Hz, 9999	0.01Hz	9999	26	
	25	Multi-speed setting (speed 5)	0 to 400Hz, 9999	0.01Hz	9999	26	
	26	Multi-speed setting (speed 6)	0 to 400Hz, 9999	0.01Hz	9999	26	
Frequency jump	27	Multi-speed setting (speed 7)	0 to 400Hz, 9999	0.01Hz	9999	26	
	— 29	Acceleration/deceleration pattern selection	0, 1, 2	1	0	29	
	— 30	Regenerative function selection	0, 1, 2	1	0	29, 32	
	31	Frequency jump 1A	0 to 400Hz, 9999	0.01Hz	9999	30	
Speed display	32	Frequency jump 1B	0 to 400Hz, 9999	0.01Hz	9999	30	
	33	Frequency jump 2A	0 to 400Hz, 9999	0.01Hz	9999	30	
	34	Frequency jump 2B	0 to 400Hz, 9999	0.01Hz	9999	30	
	35	Frequency jump 3A	0 to 400Hz, 9999	0.01Hz	9999	30	
RUN key rotation direction selection	36	Frequency jump 3B	0 to 400Hz, 9999	0.01Hz	9999	30	
	— 37	Speed display	0, 0.01 to 9998	0.001	0	30	
— 40	RUN key rotation direction selection	0, 1	1	0	30		

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Frequency detection	41	Up-to-frequency sensitivity	0 to 100%	0.1%	10%	30	
	42	Output frequency detection	0 to 400Hz	0.01Hz	6Hz	30	
	43	Output frequency detection for reverse rotation	0 to 400Hz, 9999	0.01Hz	9999	30	
Second functions	44	Second acceleration/deceleration time	0 to 3600/360s	0.1/0.01s	5/10s*2	27	
	45	Second deceleration time	0 to 3600/360s, 9999	0.1/0.01s	9999	27	
	46	Second torque boost	0 to 30%, 9999	0.1%	9999	26	
	47	Second V/F (base frequency)	0 to 400Hz, 9999	0.01Hz	9999	26	
	48	Second stall prevention operation current	0 to 200%, 9999	0.1%	9999	29, 43	
	51	Second electronic thermal O/L relay	0 to 500A, 9999	0.01A	9999	27	
Monitor functions	52	DU/PU main display data selection	0, 5, 7 to 12, 14, 20, 23 to 25, 52 to 57, 100	1	0	31	
	54	FM terminal function selection	1 to 3, 5, 7 to 12, 14, 21, 24, 52, 53	1	1	31	
	55	Frequency monitoring reference	0 to 400Hz	0.01Hz	60Hz	31	
	56	Current monitoring reference	0 to 500A	0.01A	Rated inverter current	31	
Automatic restart functions	57	Restart coasting time	0, 0.1 to 5s, 9999	0.1s	9999	32	
	58	Restart cushion time	0 to 60s	0.1s	1s	32	
—	59	Remote function selection	0, 1, 2, 3	1	0	33	
—	60	Energy saving control selection	0, 9	1	0	33	
Automatic acceleration /deceleration	61	Reference current	0 to 500A, 9999	0.01A	9999	33	
	62	Reference value at acceleration	0 to 200%, 9999	1%	9999	33	
	63	Reference value at deceleration	0 to 200%, 9999	1%	9999	33	
—	65	Retry selection	0 to 5	1	0	34	
—	66	Stall prevention operation reduction starting frequency	0 to 400Hz	0.01Hz	60Hz	29	
Retry	67	Number of retries at alarm occurrence	0 to 10, 101 to 110	1	0	34	
	68	Retry waiting time	0.1 to 360s	0.1s	1s	34	
	69	Retry count display erase	0	1	0	34	
—	70	Special regenerative brake duty	0 to 30%	0.1%	0%	29	
—	71	Applied motor	0, 1, 3 to 6, 13 to 16, 23, 24, 40, 43, 44, 50, 53, 54	1	0	34	
—	72	PWM frequency selection	0 to 15	1	1	34	
—	73	Analog input selection	0, 1, 10, 11	1	1	35	
—	74	Input filter time constant	0 to 8	1	1	35	
—	75	Reset selection/disconnected PU detection/PU stop selection	0 to 3, 14 to 17	1	14	35	
—	77	Parameter write selection	0, 1, 2	1	0	35	
—	78	Reverse rotation prevention selection	0, 1, 2	1	0	35	
—	© 79	Operation mode selection	0, 1, 2, 3, 4, 6, 7	1	0	36	

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Motor constants	80	Motor capacity	0.1 to 15kW, 9999	0.01kW	9999	37	
	81	Number of motor poles	2, 4, 6, 8, 10, 9999	1	9999	37	
	82	Motor excitation current	0 to 500A (0 to ****), 9999 *4	0.01A (1) *4	9999	37	
	83	Motor rated voltage	0 to 1000V	0.1V	200V	37	
	84	Rated motor frequency	10 to 120Hz	0.01Hz	60Hz	37	
	89	Speed control gain (advanced magnetic flux vector)	0 to 200%, 9999	0.1%	9999	37	
	90	Motor constant (R1)	0 to 50Ω (0 to ****) , 9999 *4	0.001Ω (1) *4	9999	37	
	91	Motor constant (R2)	0 to 50Ω (0 to ****) , 9999 *4	0.001Ω (1) *4	9999	37	
	92	Motor constant (L1)	0 to 1000mH (0 to 50Ω, 0 to ****), 9999 *4	0.1mH (0.001Ω, 1) *4	9999	37	
	93	Motor constant (L2)	0 to 1000mH (0 to 50Ω, 0 to ****) , 9999 *4	0.1mH (0.001Ω, 1) *4	9999	37	
	94	Motor constant (X)	0 to 100% (0 to 500Ω, 0 to ****) , 9999 *4	0.1% (0.01Ω, 1) *4	9999	37	
		96	Auto tuning setting/status	0, 1, 11, 21	1	0	37
PU connector communication	117	PU communication station number	0 to 31 (0 to 247)	1	0	38	
	118	PU communication speed	48, 96, 192, 384	1	192	38	
	119	PU communication stop bit length	0, 1, 10, 11	1	1	38	
	120	PU communication parity check	0, 1, 2	1	2	38	
	121	Number of PU communication retries	0 to 10, 9999	1	1	38	
	122	PU communication check time interval	0, 0.1 to 999.8s, 9999	0.1s	0	38	
	123	PU communication waiting time setting	0 to 150ms, 9999	1	9999	38	
		124	PU communication CR/LF presence/absence selection	0, 1, 2	1	1	38
—	⊙ 125	Terminal 2 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	39	
—	⊙126	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	39	
PID operation	127	PID control automatic switchover frequency	0 to 400Hz, 9999	0.01Hz	9999	39	
	128	PID action selection	0, 20, 21, 40 to 43, 50, 51, 60, 61	1	0	39	
	129	PID proportional band	0.1 to 1000%, 9999	0.1%	100%	39	
	130	PID integral time	0.1 to 3600s, 9999	0.1s	1s	39	
	131	PID upper limit	0 to 100%, 9999	0.1%	9999	39	
	132	PID lower limit	0 to 100%, 9999	0.1%	9999	39	
	133	PID action set point	0 to 100%, 9999	0.01%	9999	39	
	134	PID differential time	0.01 to 10.00s, 9999	0.01s	9999	39	
PU	145	PU display language selection	0 to 7	1	0	39	
—	146 *5	Built-in potentiometer switching	0, 1	1	1	39	
Current detection	150	Output current detection level	0 to 200%	0.1%	150%	40	
	151	Output current detection signal delay time	0 to 10s	0.1s	0s	40	
	152	Zero current detection level	0 to 200%	0.1%	5%	40	
	153	Zero current detection time	0 to 1s	0.01s	0.5s	40	
—	156	Stall prevention operation selection	0 to 31, 100, 101	1	0	29	
—	157	OL signal output timer	0 to 25s, 9999	0.1s	0s	29	
—	⊙ 160	User group read selection	0, 1, 9999	1	0	40	
—	161	Frequency setting/key lock operation selection	0, 1, 10, 11	1	0	40	

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting	
Automatic restart functions	162	Automatic restart after instantaneous power failure selection	0, 1, 10, 11	1	1	32		
	165	Stall prevention operation level for restart	0 to 200%	0.1%	150%	32		
—	168	Parameter for manufacturer setting. Do not set.						
—	169							
Cumulative monitor clear	170	Watt-hour meter clear	0, 10, 9999	1	9999	31		
	171	Operation hour meter clear	0, 9999	1	9999	31		
User group	172	User group registered display/batch clear	9999, (0 to 16)	1	0	40		
	173	User group registration	0 to 999, 9999	1	9999	40		
	174	User group clear	0 to 999, 9999	1	9999	40		
Input terminal function assignment	178	STF terminal function selection	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 60, 62, 65 to 67, 9999	1	60	41		
	179	STR terminal function selection	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 61, 62, 65 to 67, 9999	1	61	41		
	180	RL terminal function selection	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 62, 65 to 67, 9999	1	0	41		
	181	RM terminal function selection		1	1	41		
	182	RH terminal function selection		1	2	41		
	183	MRS terminal function selection		1	24	41		
	184	RES terminal function selection		1	62	41		
Output terminal function assignment	190	RUN terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 90, 91, 93, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 120, 125, 126, 146, 147, 164, 190, 191, 193, 195, 196, 198, 199, 9999	1	0	41		
	191	FU terminal function selection		1	4	41		
	192	A,B,C terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 90, 91, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 120, 125, 126, 146, 147, 164, 190, 191, 195, 196, 198, 199, 9999	1	99	41		
Multi-speed setting	232	Multi-speed setting (speed 8)	0 to 400Hz, 9999	0.01Hz	9999	26		
	233	Multi-speed setting (speed 9)	0 to 400Hz, 9999	0.01Hz	9999	26		
	234	Multi-speed setting (speed 10)	0 to 400Hz, 9999	0.01Hz	9999	26		
	235	Multi-speed setting (speed 11)	0 to 400Hz, 9999	0.01Hz	9999	26		
	236	Multi-speed setting (speed 12)	0 to 400Hz, 9999	0.01Hz	9999	26		
	237	Multi-speed setting (speed 13)	0 to 400Hz, 9999	0.01Hz	9999	26		
	238	Multi-speed setting (speed 14)	0 to 400Hz, 9999	0.01Hz	9999	26		
	239	Multi-speed setting (speed 15)	0 to 400Hz, 9999	0.01Hz	9999	26		
—	240	Soft-PWM operation selection	0, 1	1	1	34		
—	241	Analog input display unit switchover	0, 1	1	0	39		
—	244	Cooling fan operation selection	0, 1	1	1	41		

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting	
Slip compensation	245	Rated slip	0 to 50%, 9999	0.01%	9999	41		
	246	Slip compensation time constant	0.01 to 10s	0.01s	0.5s	41		
	247	Constant-power range slip compensation selection	0, 9999	1	9999	41		
—	249	Earth (ground) fault detection at start	0, 1	1	0	42		
—	250	Stop selection	0 to 100s, 1000 to 1100s, 8888, 9999	0.1s	9999	42		
—	251	Output phase loss protection selection	0, 1	1	1	42		
Life diagnosis	255	Life alarm status display	(0 to 15)	1	0	42		
	256	Inrush current limit circuit life display	(0 to 100%)	1%	100%	42		
	257	Control circuit capacitor life display	(0 to 100%)	1%	100%	42		
	258	Main circuit capacitor life display	(0 to 100%)	1%	100%	42		
	259	Main circuit capacitor life measuring	0, 1 (2, 3, 8, 9)	1	0	42		
Power failure stop	261	Power failure stop selection	0, 1, 2	1	0	43		
	—	267	Terminal 4 input selection	0, 1, 2	1	0	35	
	—	268	Monitor decimal digits selection	0, 1, 9999	1	9999	31	
	—	269	Parameter for manufacturer setting. Do not set.					
—	270	Stop-on contact control selection	0, 1	1	0	43		
Stop-on contact control	275	Stop-on contact excitation current low-speed multiplying factor	0 to 300%, 9999	0.1%	9999	43		
	276	PWM carrier frequency at stop-on contact	0 to 9, 9999	1	9999	43		
—	277	Stall prevention operation current switchover	0, 1	1	0	29		
Brake sequence function	278	Brake opening frequency	0 to 30Hz	0.01Hz	3Hz	44		
	279	Brake opening current	0 to 200%	0.1%	130%	44		
	280	Brake opening current detection time	0 to 2s	0.1s	0.3s	44		
	281	Brake operation time at start	0 to 5s	0.1s	0.3s	44		
	282	Brake operation frequency	0 to 30Hz	0.01Hz	6Hz	44		
	283	Brake operation time at stop	0 to 5s	0.1s	0.3s	44		
Droop control	286	Droop gain	0 to 100%	0.1%	0%	44		
	287	Droop filter time constant	0 to 1s	0.01s	0.3s	44		
—	292	Automatic acceleration/deceleration	0, 1, 7, 8, 11	1	0	33, 44		
—	293	Acceleration/deceleration separate selection	0 to 2	1	0	33		
—	295	Magnitude of frequency change setting	0, 0.01, 0.10, 1.00, 10.00	0.01	0	40		
—	298	Frequency search gain	0 to 32767, 9999	1	9999	37		
—	299	Rotation direction detection selection at restarting	0, 1, 9999	1	0	32		
RS-485 communication	338	Communication operation command source	0, 1	1	0	45		
	339	Communication speed command source	0, 1, 2	1	0	45		
	340	Communication startup mode selection	0, 1, 10	1	0	36		
	342	Communication EEPROM write selection	0, 1	1	0	38		
	343	Communication error count	—	1	0	38		

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Second motor constant	450	Second applied motor	0, 1, 9999	1	9999	34	
Output	495	Remote output selection	0, 1, 10, 11	1	0	45	
	496	Remote output data 1	0 to 4095	1	0	45	
	497	Remote output data 2	0 to 4095	1	0	45	
—	502	Stop mode selection at communication error	0, 1, 2, 3	1	0	38	
Maintenance	503	Maintenance timer	0 (1 to 9998)	1	0	46	
	504	Maintenance timer alarm output set time	0 to 9998, 9999	1	9999	46	
USB	547	USB communication station number	0 to 31	1	0	46	
	548	USB communication check time interval	0 to 999.8s, 9999	0.1s	9999	46	
Communication	549	Protocol selection	0, 1	1	0	38	
	550	NET mode operation command source selection	0, 2, 9999	1	9999	45	
	551	PU mode operation command source selection	2 to 4, 9999	1	9999	45	
Current average time monitor	555	Current average time	0.1 to 1.0s	0.1s	1s	46	
	556	Data output mask time	0.0 to 20.0s	0.1s	0s	46	
	557	Current average value monitor signal output reference current	0 to 500A	0.01A	Rated inverter current	46	
—	563	Energization time carrying-over times	(0 to 65535)	1	0	31	
—	564	Operating time carrying-over times	(0 to 65535)	1	0	31	
—	571	Holding time at a start	0.0 to 10.0s, 9999	0.1s	9999	27	
—	611	Acceleration time at a restart	0 to 3600s, 9999	0.1s	9999	32	
—	653	Speed smoothing control	0 to 200%	0.1%	0	47	
—	665	Regeneration avoidance frequency gain	0 to 200%	0.1%	100	47	
—	800	Control method selection	20, 30	1	20	37	
—	859	Torque current	0 to 500A (0 to ****) , 9999 *4	0.01A (1) *4	9999	37	
Protective Functions	872	Input phase loss protection selection	0, 1	1	1	42	
Regeneration avoidance function	882	Regeneration avoidance operation selection	0, 1, 2	1	0	47	
	883	Regeneration avoidance operation level	300 to 800V	0.1V	400VDC	47	
	885	Regeneration avoidance compensation frequency limit value	0 to 10Hz, 9999	0.01Hz	6Hz	47	
	886	Regeneration avoidance voltage gain	0 to 200%	0.1%	100%	47	
Free parameter	888	Free parameter 1	0 to 9999	1	9999	47	
	889	Free parameter 2	0 to 9999	1	9999	47	

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

Function	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Calibration parameters	C0 (900)	FM terminal calibration	—	—	—	47	
	C2 (902)	Terminal 2 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	39	
	C3 (902)	Terminal 2 frequency setting bias	0 to 300%	0.1%	0%	39	
	125 (903)	Terminal 2 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	39	
	C4 (903)	Terminal 2 frequency setting gain	0 to 300%	0.1%	100%	39	
	C5 (904)	Terminal 4 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	39	
	C6 (904)	Terminal 4 frequency setting bias	0 to 300%	0.1%	20%	39	
	126 (905)	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	39	
	C7 (905)	Terminal 4 frequency setting gain	0 to 300%	0.1%	100%	39	
	C22 *5 (922)	Frequency setting voltage bias frequency (built-in potentiometer)	0 to 400Hz	0.01Hz	0	39	
	C23 *5 (922)	Frequency setting voltage bias (built-in potentiometer)	0 to 300%	0.1%	0	39	
	C24 *5 (923)	Frequency setting voltage gain frequency (built-in potentiometer)	0 to 400Hz	0.01Hz	60Hz	39	
	C25 *5 (923)	Frequency setting voltage gain (built-in potentiometer)	0 to 300%	0.1%	100%	39	
	PU	990	PU buzzer control	0, 1	1	1	48
991		PU contrast adjustment	0 to 63	1	58	48	
Clear parameters Initial value change list	Pr.CL	Parameter clear	0, 1	1	0	48	
	ALLC	All parameter clear	0, 1	1	0	48	
	Er.CL	Alarm history clear	0, 1	1	0	48	
	Pr.CH	Initial value change list	—	—	—	48	

\*1 Differ according to capacities. (0.1K to 0.75K/1.5K to 3.7K/5.5K, 7.5K/11K, 15K)

\*2 Differ according to capacities. (3.7K or less/5.5K or more)

\*3 Differ according to capacities. (0.1K, 0.2K/0.4K to 7.5K/11K, 15K)

\*4 The range differs according to the Pr: 71 setting.

\*5 Set this parameter when calibrating the operation panel built-in potentiometer of the FR-E500 series operation panel (PA02) connected with cable.

# Explanations of Parameters

The abbreviations in the explanations below indicate **V/F** ...V/F control, **AD MFVC** ...advanced magnetic flux vector control, **GP MFVC** ...general-purpose magnetic flux vector control. (Parameters without any indication are valid for all control)


## Pr. 0, 46

### Manual torque boost **V/F**

*Pr. 0 Torque boost*      *Pr. 46 Second torque boost*

You can compensate for a voltage drop in the low-frequency region to improve motor torque reduction in the low-speed region.


- Motor torque in the low-frequency range can be adjusted to the load to increase the starting motor torque.
- Two kinds of starting torque boost can be switched by using RT signal.
- This function is valid for V/F control only.



Pr. 0 Initial Value		When Using the Mitsubishi Constant Torque Motor
0.1K to 0.75K	6%	←
1.5K to 3.7K	4%	←
5.5K, 7.5K	3%	2%*
11K, 15K	2%	←

\* If the Pr. 71 initial value is changed to the setting for use with a constant-torque motor, the Pr. 0 setting changes to the corresponding value in the above table.

- Use *Pr. 19 Base frequency voltage* to set the base voltage (e.g. rated motor voltage).
- This function is valid for V/F control only.



## Pr. 4 to 6, 24 to 27, 232 to 239



### Multi-speed setting operation

- Pr. 4 Multi-speed setting (high speed)*
- Pr. 5 Multi-speed setting (middle speed)*
- Pr. 6 Multi-speed setting (low speed)*
- Pr. 24 Multi-speed setting (speed 4)*
- Pr. 25 Multi-speed setting (speed 5)*
- Pr. 26 Multi-speed setting (speed 6)*
- Pr. 27 Multi-speed setting (speed 7)*
- Pr. 232 Multi-speed setting (speed 9)*
- Pr. 233 Multi-speed setting (speed 10)*
- Pr. 234 Multi-speed setting (speed 11)*
- Pr. 235 Multi-speed setting (speed 12)*
- Pr. 237 Multi-speed setting (speed 13)*
- Pr. 238 Multi-speed setting (speed 14)*
- Pr. 239 Multi-speed setting (speed 15)*

Can be used to change the preset speed in the parameter with the contact signals.

Any speed can be selected by merely turning on-off the contact signals (RH, RM, RL, REX signals).

- Operation is performed at the frequency set in *Pr. 4* when the RH signal turns on, *Pr. 5* when the RM signal turns on, and *Pr. 6* when the RL signal turns on.
- Frequency from 4 speed to 15 speed can be set according to the combination of the RH, RM, RL and REX signals. Set the running frequencies in *Pr. 24* to *Pr. 27*, *Pr. 232* to *Pr. 239* (In the initial value setting, speed 4 to speed 15 are unavailable)



\*1 When "9999" is set in *Pr. 232 Multi-speed setting (speed 8)*, operation is performed at 0Hz when RH, RM and RL are turned off and REX is turned on.

## Pr. 1, 2, 18


### Maximum/minimum frequency

*Pr. 1 Maximum frequency*      *Pr. 2 Minimum frequency*  
*Pr. 18 High speed maximum frequency*

Motor speed can be limited.

- Clamp the upper and lower limits of the output frequency.
- To perform operation above 120Hz, set the maximum output frequency in *Pr. 18*.

(When *Pr. 18* is set, *Pr. 1* is automatically changed to the frequency set in *Pr. 18*. Also, when *Pr. 1* is set, *Pr. 18* is automatically changed to the frequency set in *Pr. 1*.)



## Pr. 3, 19, 47

### Base frequency, voltage **V/F**

*Pr. 3 Base frequency*      *Pr. 19 Base frequency voltage*  
*Pr. 47 Second V/F (base frequency)*

- Used to adjust the inverter outputs (voltage, frequency) to the motor rating.
- When running the standard motor, generally set the rated frequency of the motor in *Pr. 3 Base frequency*. When running the motor using commercial power supply-inverter switch-over operation, set *Pr. 3* to the same value as the power supply frequency.
- When you want to change the base frequency when switching multiple motors with one inverter, use the *Pr. 47 Second V/F (base frequency)*.

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry


**Pr. 7, 8, 20, 21, 44, 45**

**Acceleration/deceleration time setting**

- Pr. 7 Acceleration time                      Pr. 8 Deceleration time
- Pr. 20 Acceleration/deceleration reference frequency      Pr. 21 Acceleration/deceleration time increments
- Pr. 44 Second acceleration/deceleration time              Pr. 45 Second deceleration time

Used to set motor acceleration/deceleration time.  
Set a larger value for a slower speed increase/decrease or a smaller value for a faster speed increase/decrease.

- Use *Pr. 7 Acceleration time* to set the acceleration time to reach *Pr. 20 Acceleration/deceleration reference frequency* from 0Hz
- Use *Pr. 8 Deceleration time* to set the deceleration time taken to reach 0Hz from *Pr. 20 Acceleration/deceleration reference frequency*.



Pr. 21		Definition	
Setting			
0 (initial value)	Increments: 0.1s Range: 0 to 3600s	Increments and setting range of acceleration/ deceleration time setting can be changed.	
1	Increments: 0.01s Range: 0 to 360s		

**Pr. 9, 51**

**Motor protection from overheat (electronic thermal relay function)**

- Pr. 9 Electronic thermal O/L relay                      Pr. 51 Second electronic thermal O/L relay

Set the current of the electronic thermal relay function to protect the motor from overheat. This feature provides the optimum protective characteristics, including reduced motor cooling capability, at low speed.

- This function detects the overload (overheat) of the motor, stops the operation of the inverter's output transistor, and stops the output.
- Set the rated current [A] of the motor in *Pr. 9*.  
(When the power supply specification is 200V/220V 60Hz, set the 1.1 times the rated motor current.)
- Set "0" in *Pr. 9* to make the electronic thermal relay function invalid when using a motor with an external thermal relay, etc. (Note that the output transistor protection of the inverter functions (E.THT).)
- When using a Mitsubishi constant-torque motor
  - 1) Set any of "1, 13 to 16, 50, 53, 54" in *Pr. 71*. (This provides a 100% continuous torque characteristic in the low-speed range.)
  - 2) Set the rated current of the motor in *Pr. 9*.
- When the RT signal is on, thermal protection is provided based on the *Pr. 51* setting.

Use this function when running two motors of different rated currents individually by a single inverter. (When running two motors together, use external thermal relays.)


**Pr. 10 to 12**

**DC injection brake**

- Pr. 10 DC injection brake operation frequency      Pr. 11 DC injection brake operation time
- Pr. 12 DC injection brake operation voltage

The DC injection brake can be operated at a motor stop to adjust the stop timing and braking torque.

When 0 is set in *Pr. 11* or *Pr. 12*, DC injection brake is not performed.



Pr. 12 Initial Value		When Using the Mitsubishi Constant Torque Motor
0.1K, 0.2K	6%	←
0.4K to 3.7K	4%	←
5.5K to 7.5K	4%	2%*
11K to 15K	2%	←

\* If the *Pr. 71* initial value is changed to the setting for use with a constant-torque motor, the *Pr. 12* setting changes to the corresponding value in the above table.


**Pr. 13, 571**

**Starting frequency**

- Pr. 13 Starting frequency                      Pr. 571 Holding time at a start

You can set the starting frequency and hold the set starting frequency for a certain period of time.

Set these functions when you need the starting torque or want smooth motor drive at a start.




## Pr. 14 V/F pattern matching applications


### Pr. 14 Load pattern selection

You can select the optimum output characteristic (V/F characteristic) for the application and load characteristics. This function is valid for V/F control only.


#### For constant torque load (initial value)




#### For variable torque load



#### For constant torque elevator load



#### For constant torque elevator load




## Pr. 15, 16 Jog operation

### Pr. 15 Jog frequency

### Pr. 16 Jog acceleration/deceleration time

You can set the frequency and acceleration/deceleration time for jog operation. Jog operation can be performed from either of the external or the PU operation mode.

Can be used for conveyor positioning, test operation, etc.




## Pr. 17 Logic selection of output stop signal (MRS)

### Pr. 17 MRS input selection

The inverter output can be shut off by the MRS signal. Also, logic for the MRS signal can be selected.

When Pr. 17 is set to "4", the MRS signal from external terminal (output stop) can be changed to the normally closed (NC contact) input, and the MRS signal from communication can be changed to the normally open (NO contact) input.



Pr. 18 → Refer to the section about Pr. 1.

Pr. 19 → Refer to the section about Pr. 3.

Pr. 20, 21 → Refer to the section about Pr. 7.

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

**Pr. 22, 23, 48, 66, 156, 157, 277**


**Stall prevention operation**

- Pr. 22 Stall prevention operation level*
- Pr. 23 Stall prevention operation level compensation factor at double speed*
- Pr. 48 Second stall prevention operation current*
- Pr. 66 Stall prevention operation reduction starting frequency*
- Pr. 156 Stall prevention operation selection*
- Pr. 157 OL signal output timer*
- Pr. 277 Stall prevention operation current switchover*

This function monitors the output current and automatically changes the output frequency to prevent the inverter from coming to an alarm stop due to overcurrent, overvoltage, etc. It can also limit stall prevention and fast-response current limit operation during acceleration/deceleration, driving or regeneration.

In addition, torque limit which limits the output torque to the predetermined value can be selected.

- **Stall prevention**  
If the output current exceeds the stall prevention operation level, the output frequency of the inverter is automatically varied to reduce the output current.
- **Fast-response current limit**  
If the current exceeds the limit value, the output of the inverter is shut off to prevent an overcurrent.
- **Set in Pr. 22 the percentage of the output current to the rated inverter current at which stall prevention operation will be performed.** Normally set this parameter to 150% (initial value).
- **During high-speed operation above the rated motor frequency, acceleration may not be made because the motor current does not increase.** If operation is performed in a high frequency range, the current at motor lockup becomes smaller than the rated output current of the inverter, and the protective function (OL) is not executed even if the motor is at a stop.  
To improve the operating characteristics of the motor in this case, the stall prevention level can be reduced in the high frequency range. This function is effective for performing operation up to the high-speed range on a centrifugal separator etc. Normally, set 60Hz in Pr. 66 and 100% in Pr. 23.
- **By setting "9999" (initial value) in Pr. 23 Stall prevention operation level compensation factor at double speed, the stall prevention operation level is constant at the Pr. 22 setting up to 400Hz.**



- Stall prevention operation and fast response current limit function can be restricted according to the operation condition using Pr. 156.
- When Pr. 277 = "1", torque limit can be set. Torque limit level can be set using Pr. 22.


**Pr. 24 to 27** ➔ Refer to the section about Pr. 4.

**Pr. 29**

**Acceleration/deceleration pattern**

*Pr. 29 Acceleration/deceleration pattern selection*

You can set the acceleration/deceleration pattern suitable for application.



- **Linear acceleration/deceleration (setting "0", initial value)**  
For the inverter operation, the output frequency is made to change linearly (linear acceleration/deceleration) to prevent the motor and inverter from excessive stress to reach the set frequency during acceleration, deceleration, etc. when frequency changes.
- **S-pattern acceleration/deceleration A (setting "1")**  
For machine tool spindle applications, etc. Used when acceleration/deceleration must be made in a short time to a high-speed range of not lower than Pr. 3 Base frequency (fb).
- **S-pattern acceleration/deceleration B (setting "2")**  
For prevention of load shifting in conveyor and other applications. Since acceleration/deceleration is always made in an S shape from current frequency (f2) to target frequency (f1), this function eases shock produced at acceleration/deceleration and is effective for load collapse prevention, etc.

**Pr. 30, 70**

**Selection of regeneration unit**

*Pr. 30 Regenerative function selection*    *Pr. 70 Special regenerative brake duty*

- When making frequent starts/stops, use the optional brake resistor to increase the regeneration capability. (0.4K or more)
- Use a power regeneration common converter (FR-CV) for continuous operation in regeneration status.  
Use a high efficiency converter (FR-HC) for harmonic suppression and power factor improvement.

Pr. 30 Set Value	Pr. 70 Set Value	Regeneration Unit
0 (initial value)	*1	Brake resistor (MRS, MYS) Brake unit (FR-BU2) Power regeneration common converter (FR-CV) High power factor converter (FR-HC)
1	10/6% *2	High-duty brake resistor (FR-ABR)
2	—	High power factor converter (FR-HC) (when an automatic restart after instantaneous power failure is selected)

\*1 The brake duty varies according to the inverter capacity.  
\*2 7.5K or less/11K or more


**Pr. 31 to 36**

**Avoid mechanical resonance points (frequency jump)**

- Pr. 31 Frequency jump 1A*
- Pr. 33 Frequency jump 2A*
- Pr. 35 Frequency jump 3A*

- Pr. 32 Frequency jump 1B*
- Pr. 34 Frequency jump 2B*
- Pr. 36 Frequency jump 3B*

When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped.



- Up to three areas may be set, with the jump frequencies set to either the top or bottom point of each area.
- The settings of frequency jumps 1A, 2A, 3A are jump points, and operation is performed at these frequencies in the jump areas.
- Frequency jump is not performed if the initial value is set to "9999".
- During acceleration/deceleration, the running frequency within the set area is valid.

**Pr. 37**

**Speed display**

*Pr. 37 Speed display*

The monitor display and frequency setting of the PU (FR-PU04/FR-PU07) can be changed to the machine speed.

- To display the machine speed, set in *Pr. 37* the machine speed for 60Hz operation.

<i>Pr. 37</i> Setting	Output Frequency Monitor	Set Frequency Monitor	Frequency Setting Parameter Setting
0 (initial value)	Hz	Hz	Hz
0.01 to 9998	Machine speed *1	Machine speed *1	

\*1 Machine speed conversion formula.....*Pr.37* x frequency/60Hz  
 \*2 Hz is displayed in 0.01Hz increments and machine speed is in 0.001.

**Pr. 40**

**RUN key rotation direction selection**

*Pr. 40 RUN key rotation direction selection*

- Used to choose the direction of rotation by operating the RUN key of the operation panel.

<i>Pr. 40</i> Setting	Description
0	Forward rotation
1	Reverse rotation

**Pr. 41 to 43**

**Detection of output frequency (SU, FU signal)**


*Pr. 41 Up-to-frequency sensitivity*

*Pr. 42 Output frequency detection*


*Pr. 43 Output frequency detection for reverse rotation*

The inverter output frequency is detected and output at the output signals.

- The *Pr. 41* value can be adjusted within the range 0% ±100% on the assumption that the set frequency is 100%.
- This parameter can be used to ensure that the running frequency has been reached to provide the operation start signal etc. for related equipment.



- When the output frequency rises to or above the *Pr. 42* setting, the output frequency detection signal (FU) is output. This function can be used for electromagnetic brake operation, open signal, etc.
- When the detection frequency is set to *Pr. 43*, frequency detection for reverse operation use only can also be set. This function is effective for switching the timing of electromagnetic brake operation between forward rotation (rise) and reverse rotation (fall) during vertical lift operation, etc.



**Pr. 44, 45** ➔ Refer to the section about *Pr. 7.*

**Pr. 46** ➔ Refer to the section about *Pr. 0.*

**Pr. 47** ➔ Refer to the section about *Pr. 3.*

**Pr. 48** ➔ Refer to the section about *Pr. 22.*

**Pr. 51** ➔ Refer to the section about *Pr. 9.*

**Pr. 52, 54, 170, 171, 268, 563, 564**

**Change of DU/PU monitor descriptions  
Cumulative monitor clear**

*Pr. 52 DU/PU main display data selection*    *Pr. 54 FM terminal function selection*  
*Pr. 170 Watt-hour meter clear*            *Pr. 171 Operation hour meter clear*  
*Pr. 268 Monitor decimal digits selection*    *Pr. 563 Energization time carrying-over times*  
*Pr. 564 Operating time carrying-over times*

The monitor to be displayed on the main screen of the control panel and parameter unit (FR-PU04/FR-PU07) can be selected.

Types of Monitor	Unit	Pr. 52 Setting		Pr. 54 (FM) Set Value	Full-scale Value
		Operation Panel LED	PU Main Monitor		
Output frequency	0.01Hz	0/100		1	Pr. 55
Output current	0.01A	0/100		2	Pr. 56
Output Voltage	0.1V	0/100		3	400V
Fault or alarm indication	—	0/100		—	—
Frequency setting value	0.01Hz	5	*1	5	Pr. 55
Motor torque *2	0.1%	7	*1	7	Rated torque of the applied motor × 2
Converter output voltage	0.1V	8	*1	8	400V
Regenerative brake duty	0.1%	9	*1	9	Brake duty set in Pr. 30 and Pr. 70
Electronic thermal O/L relay load factor	0.1%	10	*1	10	Electronic thermal relay function operation level
Output current peak value	0.01A	11	*1	11	Pr. 56
Converter output voltage peak value	0.1V	12	*1	12	400V
Output power	0.01kW	14	*1	14	Rated inverter power × 2
Input terminal status	—	—	*1	—	—
Output terminal status	—	—	*1	—	—
Cumulative energization time *3	1h	20		—	—
Reference voltage output	—	—	—	21	—
Actual operation time *3, *4	1h	23		—	—
Motor load factor	0.1%	24		24	200%
Cumulative power	0.01kWh *5	25		—	—
PID set point	0.1%	52		52	100%
PID measured value	0.1%	53		53	100%
PID deviation	0.1%	54		—	—
Inverter I/O terminal monitor	—	55	—	—	—
Option input terminal status	—	56	—	—	—
Option output terminal status	—	57	—	—	—

- \*1 Selected by the parameter unit (FR-PU04/FR-PU07)
- \*2 The motor torque display remains "0" under V/F control.
- \*3 The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0. When the operation panel is used, the time is displayed up to 65.53 (65530h) on the assumption that 1h = 0.001, and thereafter, it is added up from 0.
- \*4 The actual operation time is not added up if the cumulative operation time before power supply-off is less than 1h.
- \*5 When using the parameter unit (FR-PU04/FR-PU07), "kW" is displayed.

- Writing "0" in Pr. 170 clears the cumulative power monitor.
- You can check the numbers of cumulative energization time monitor exceeded 65535h with Pr. 563 and the numbers of actual operation time monitor exceeded 65535h with Pr. 564.
- Writing "0" in Pr. 171 clears the actual operation time monitor.

Pr. 268 Setting	Definition
9999 (initial value)	No function
0	For the first or second decimal places (0.1 increments or 0.01 increments) of the monitor, numbers in the first decimal place and smaller are rounded to display an integral value (1 increments). The monitor value smaller than 0.99 is displayed as 0.
1	When 2 decimal places (0.01 increments) are monitored, the 0.01 decimal place is dropped and the monitor displays the first decimal place (0.1 increments). When the monitor display digit is originally in 1 increments, it is displayed unchanged in 1 increments.

- When Pr. 52 is set to "100", the set frequency monitor is displayed during a stop and the output frequency monitor is displayed during operation. (LED of Hz flickers during stop and is lit during operation.)

	Pr. 52		
	0	100	
	During running/stop	During stop	During running
Output frequency	Output frequency	Set frequency *	Output frequency
Output current	Output current		
Output voltage	Output voltage		
Fault or alarm indication	Fault or alarm indication		

- \* The set frequency displayed indicates the frequency to be output when the start command is on.  
Different from the frequency setting displayed when Pr. 52 = "5", the value based on maximum/minimum frequency and frequency jump is displayed.

**Pr. 55, 56**


**Reference of the monitor output from terminal FM**

*Pr. 55 Frequency monitoring reference*    *Pr. 56 Current monitoring reference*

Set the full-scale value of the monitor value output from terminal FM.

Monitor*	Reference Parameter	Initial Value
Frequency	Pr. 55	60Hz
Current	Pr. 56	Rated inverter current

- \* Refer to the section about Pr. 52 for monitor names.



**Pr. 30, 57, 58, 162, 165, 299, 611**

**Automatic restart operation after instantaneous power failure/flying start**


- Pr. 30 Regenerative function selection*      *Pr. 57 Restart coasting time*
- Pr. 58 Restart cushion time*              *Pr. 162 Automatic restart after instantaneous power failure selection*
- Pr. 165 Stall prevention operation level for restart*      *Pr. 299 Rotation direction detection selection at restarting*
- Pr. 611 Acceleration time at a restart*

You can restart the inverter without stopping the motor in the following cases:

- When power comes back on after an instantaneous power failure
- When motor is coasting at start


Pr. Number	Setting Range	Description
30	0 (initial value), 1	When MRS (X10) turns ON then OFF The motor starts at the starting frequency
	2	When MRS (X10) turns ON then OFF Automatic restart operation
57	0	1.5K or less ..... 1s, 2.2K to 7.5K ..... 2s, 11K or more ..... 3s The above times are coasting time.
	0.1 to 5s	Set the waiting time for inverter-triggered restart after an instantaneous power failure.
	9999 (initial value)	No restart
58	0 to 60s	Set a voltage starting time at restart.
162	0	With frequency search
	1 (initial value)	Without frequency search (reduced voltage system)
	10	Frequency search at every start
	11	Reduced voltage system at every start
165	0 to 200%	Considers the rated inverter current as 100% and sets the stall prevention operation level during restart operation.
299	0 (initial value)	Without rotation direction detection
	1	With rotation direction detection
	9999	When Pr. 78 = 0, the rotation direction is detected. When Pr. 78 = 1, 2, the rotation direction is not detected.
611	0 to 3600s	Set the acceleration time to reach the set frequency at a restart.
	9999 (initial value)	Acceleration time for restart is the normal acceleration time (e.g. Pr. 7).

- When Pr. 162 = "1" (initial value) or "11", automatic restart operation is performed in a reduced voltage system, where the voltage is gradually risen with the output frequency unchanged from prior to an instantaneous power failure independently of the coasting speed of the motor.



\* The output shut off timing differs according to the load condition.

- When "0" or "10" is set in Pr. 162, the inverter smoothly starts after detecting the motor speed upon power restoration. (The motor capacity should be equal to or one rank lower than the inverter capacity)  
When using the frequency search, perform offline auto tuning. Also be noted that there is a wiring length limit. (Refer to page 61)
- Even when the motor is rotating in the opposite direction, the inverter can be restarted smoothly as the direction of rotation is detected. (You can select whether to make rotation direction detection or not with Pr. 299 Rotation direction detection selection at restarting.)



\* The output shut off timing differs according to the load condition.

- Restart operation after turning MRS (X10) signal ON then OFF can be selected using Pr. 30. Set when restart operation after instantaneous power failure is selected while using the high power factor converter (FR-HC).

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry


**Pr. 59**

**Remote setting function**

*Pr. 59 Remote function selection*

- If the operation panel is located away from the enclosure, you can use contact signals to perform continuous variable-speed operation, without using analog signals.
- By merely setting this parameter, you can use the acceleration, deceleration and setting clear functions of the motorized speed setter (FR-FK).

Pr. 59 Setting	Description	
	RH, RM, RL signal function	Frequency setting storage function
0 (initial value)	Multi-speed setting	—
1	Remote setting	With
2	Remote setting	Not used
3	Remote setting	Not used (Turning off STF/STR clears remotely set frequency)



\* External running frequency (other than multi-speed) or PU running frequency

**Pr. 60**

**Energy saving control selection V/F**

*Pr. 60 Energy saving control selection*

Without a fine parameter setting, the inverter automatically performs energy saving operation. This function is optimum for fan and pump applications. This function is valid for V/F control only.

Pr. 60 Setting	Description
0 (initial value)	Normal operation mode
9	Optimum excitation control mode The optimum excitation control mode is a control system which controls excitation current to improve the motor efficiency to maximum and determines output voltage as an energy saving system. *

\* Output current may slightly increase, since output voltage is controlled.

**Pr. 61 to 63, 292, 293**

**Automatic acceleration/deceleration**

*Pr. 61 Reference current*

*Pr. 62 Reference value at acceleration*

*Pr. 63 Reference value at deceleration*

*Pr. 292 Automatic acceleration/deceleration*

*Pr. 293 Acceleration/deceleration separate selection*

The inverter automatically sets appropriate parameters for operation.

- The inverter operates in the same conditions as when appropriate values are set in each parameter even if acceleration/deceleration time and V/F pattern are not set. This operation mode is useful when you just want to operate, etc. without fine parameter setting.
- If the automatic acceleration/deceleration has been selected, inputting the jog or RT (second function selection) signal during an inverter stop will switch to the normal operation and give priority to JOG operation or second function selection. After automatic acceleration/deceleration operation has been started, none of JOG signal and RT signal are accepted.

Pr. 292 Setting	Operation	Automatic Setting Parameter
0 (initial value normal mode)	—	—
1 (shortest acceleration/ deceleration mode)	Without brake resistor and brake unit	Set when you want to accelerate/ decelerate the motor for the shortest time. (stall prevention operation level 150%) Pr. 7, Pr. 8
11 (shortest acceleration/ deceleration mode)	With brake resistor and brake unit	
7 (brake sequence mode 1)	With mechanical brake opening completion signal input	—
8 (brake sequence mode 2)	Without mechanical brake opening completion signal input	

- Use Pr. 61 to Pr. 63 to change the reference current for the shortest acceleration/deceleration mode and optimum acceleration/ deceleration mode.
- Calculation of acceleration/deceleration can be performed individually. This function is made valid in the shortest acceleration/deceleration mode.

Pr. 293 Setting	Description
0 (initial value)	Both acceleration/deceleration time is calculated.
1	Only acceleration time is calculated.
2	Only deceleration time is calculated.

**Pr. 65, 67 to 69**

**Retry function at fault occurrence**

Pr. 65 Retry selection      Pr. 67 Number of retries at alarm occurrence  
Pr. 68 Retry waiting time      Pr. 69 Retry count display erase

If a fault occurs, the inverter resets itself automatically to restart. You can also select the fault description for a retry.

When you have selected automatic restart after instantaneous power failure (Pr. 57 Restart coasting time ≠ 9999), restart operation is performed at the retry operation time which is the same of that of a power failure.

- Use Pr. 65 to select the fault to be activated for retries.

"●" indicates the alarms selected for retry.

Fault Display for Retry	Pr. 65 Setting					
	0	1	2	3	4	5
E.OC1	●	●		●	●	●
E.OC2	●	●		●	●	●
E.OC3	●	●		●	●	●
E.OV1	●		●	●	●	●
E.OV2	●		●	●	●	●
E.OV3	●		●	●	●	●
E.THM	●					
E.THT	●					
E. BE	●				●	
E. GF	●				●	
E.OHT	●				●	
E.OLT	●				●	
E.OP1	●				●	
E. PE	●				●	
E.MB4	●				●	
E.MB5	●				●	
E.MB6	●				●	
E.MB7	●				●	
E.USB	●				●	
E.ILF	●				●	

- Set the number of retries at fault occurrence in Pr. 67.

Pr. 67 Setting	Description
0 (initial value)	No retry function
1 to 10	Set the number of retries at fault occurrence. A fault output is not provided during retry operation.
101 to 110	Set the number of retries at fault occurrence. (The setting value of minus 100 is the number of retries.) A fault output is provided during retry operation.

- Use Pr. 68 to set the waiting time from when an inverter fault occurs until a retry is made in the range 0 to 10s. (Setting value "0" equals to 0.1s.)
- Reading the Pr. 69 value provides the cumulative number of successful restart times made by retry. (Use setting value "0" to clear.)

**Pr. 66** ➡ Refer to the section about Pr. 22.

**Pr. 67 to 69** ➡ Refer to the section about Pr. 65.

**Pr. 70** ➡ Refer to the section about Pr. 30.

**Pr. 71, 450**

**Motor selection (applied motor)**

Pr. 71 Applied motor      Pr. 450 Second applied motor

Setting of the used motor selects the thermal characteristic appropriate for the motor.

Setting is required to use a constant-torque motor. Thermal characteristic of the electronic thermal relay function suitable for the motor is set.

Pr. 71, Pr. 450 Setting	Thermal Characteristic of the Electronic Thermal Relay Function	Motor (○: Motor used)	
		Standard (SF-JR, etc.)	Constant-torque (SF-JRCA, etc.)
0	Thermal characteristics of a standard motor (Pr. 71 initial value)	○	
1	Thermal characteristics of the Mitsubishi constant-torque motor		○
40	Thermal characteristic of Mitsubishi high efficiency motor SF-HR	○ *1	
50	Thermal characteristic of Mitsubishi constant torque motor SF-HRCA		○ *2
3	Standard	○	
13	Constant-torque		○
23	Mitsubishi standard motor SF-JR4P (1.5kW or less)	○	
43	Mitsubishi high efficiency SF-HR	○ *1	
53	Mitsubishi constant-torque SF-HRCA		○ *2
4	Standard	○	
14	Constant-torque		○
24	Mitsubishi standard motor SF-JR4P (1.5kW or less)	○	
44	Mitsubishi high efficiency SF-HR	○ *1	
54	Mitsubishi constant-torque SF-HRCA		○ *2
5	Standard*3	○	
15	Constant-torque *3		○
6	Standard *4	○	
16	Constant-torque *4		○
9999	Function invalid (only Pr. 450 can be set, initial value)		

- \*1 Motor constants of Mitsubishi high efficiency motor SF-HR
- \*2 Motor constants of Mitsubishi constant-torque motor SF-HRCA.
- \*3 Star connection
- \*4 Delta connection

- For the 5.5K and 7.5K, the Pr. 0 Torque boost and Pr. 12 DC injection brake operation voltage settings are automatically changed according to the Pr. 71 and Pr. 450 settings as follows.

Automatic Change Parameter	Standard Motor Setting *1	Constant-torque Motor Setting *2
Pr. 0	3%	2%
Pr. 12	4%	2%

- \*1 Pr. 71, Pr. 450 setting: 0, 3 to 6, 23, 24, 40, 43, 44
- \*2 Pr. 71, Pr. 450 setting: 1, 13 to 16, 50, 53, 54

**Pr. 72, 240**

**Carrier frequency and Soft-PWM selection**

Pr. 72 PWM frequency selection      Pr. 240 Soft-PWM operation selection

You can change the motor sound.

Pr. Number	Setting Range	Description
72	0 to 15	PWM carrier frequency can be changed. The setting is in [kHz]. Note that 0 indicates 0.7kHz and 15 indicates 14.5kHz.
240	0	Soft-PWM is invalid
	1	When Pr. 72 = "0 to 5", Soft-PWM is valid.

Features  
Peripheral Devices  
Standard Specifications  
Outline Dimension Drawings  
Terminal Connection Diagram Terminal Specification Explanation  
Operation panel Parameter unit FR Configurator  
Parameter List  
Explanations of Parameters  
Protective Functions  
Options  
Instructions  
Motor  
Compatibility  
Warranty  
Inquiry

**Pr. 73, 267**


**Analog input selection**

*Pr. 73 Analog input selection Pr. 267 Terminal 4 input selection*

- You can select the function that switches between forward rotation and reverse rotation according to the analog input terminal specifications and analog input level.
- Either voltage input (0 to 5V, 0 to 10V) or current input (4 to 20mA) can be selected for terminals 4 used for analog input. Set the voltage/current input switch in the "V" position to select voltage input (0 to 5V/0 to 10V) and "I" position to select current input (4 to 20mA), and change the parameter setting (*Pr. 267*).

(    indicates main speed setting)

Pr. 73 Setting	Terminal 2 Input	Terminal 4 Input	Reversible Operation
0	0 to 10V	When the AU signal is off ×	Not function
1 (initial value)	0 to 5V		
10	0 to 10V		
11	0 to 5V		
0	×	When the AU signal is on According to <i>Pr. 267</i> setting 0:4 to 20mA (initial value)	Not function
1 (initial value)			
10			
11			
	×	1:0 to 5V 2:0 to 10V	Yes



**Pr. 74**

**Response level of analog input and noise elimination**

*Pr. 74 Input filter time constant*

- The time constant of the primary delay filter can be set for the external frequency command (analog input (terminal 2, 4) signal).
    - Effective for filtering noise in the frequency setting circuit.
    - Increase the filter time constant if steady operation cannot be performed due to noise.
- A larger setting results in slower response. (The time constant can be set between approximately 10ms to 1s with the setting of 0 to 8.)

**Pr. 75**

**Reset selection, disconnected PU detection**

*Pr. 75 Reset selection/disconnected PU detection/PU stop selection*

You can select the reset input acceptance, disconnected PU (FR-PU04/FR-PU07) connector detection function and PU stop function.

Pr. 75 Setting	Reset Selection	Disconnected PU Detection	PU Stop Selection
0	Reset input normally enabled	If the PU is disconnected, operation will be continued.	Pressing  decelerates the motor to a stop only in the PU operation mode.
1	Reset input is enabled only when a fault occurs.		
2	Reset input normally enabled	When the PU is disconnected, the inverter output is shut off.	Pressing  decelerates the motor to a stop in any of the PU, external and communication operation modes.
3	Reset input is enabled only when a fault occurs.		
14 (initial value)	Reset input normally enabled	If the PU is disconnected, operation will be continued.	Pressing  decelerates the motor to a stop in any of the PU, external and communication operation modes.
15	Reset input is enabled only when a fault occurs.		
16	Reset input normally enabled	When the PU is disconnected, the inverter output is shut off.	Pressing  decelerates the motor to a stop in any of the PU, external and communication operation modes.
17	Reset input is enabled only when a fault occurs.		

- Reset selection**  
You can select the operation timing of reset function (RES signal, reset command through communication) input.
- Disconnected PU detection**  
This function detects that the PU (FR-PU04/FR-PU07) has been disconnected from the inverter for longer than 1s and causes the inverter to provide a fault output (E.PUE) and come to an inverter trip.
- PU stop selection**  
In any of the PU operation, external operation and network operation modes, the motor can be stopped by pressing of the PU.

**Pr. 77**

**Prevention of parameter rewrite**

*Pr. 77 Parameter write selection*

You can select whether write to various parameters can be performed or not. Use this function to prevent parameter values from being rewritten by misoperation.

Pr. 77 Setting	Description
0 (initial value)	Write is enabled only during a stop.
1	Parameter can not be written.
2	Parameter write is enabled in any operation mode regardless of operating status.

**Pr. 78**

**Prevention of reverse rotation of the motor**

*Pr. 78 Reverse rotation prevention selection*

This function can prevent reverse rotation fault resulting from the incorrect input of the start signal.

Pr. 78 Setting	Description
0 (initial value)	Both forward and reverse rotations allowed
1	Reverse rotation disabled
2	Forward rotation disallowed

**Pr. 79, 340**

**Operation mode selection**

Pr. 79 Operation mode selection Pr. 340 Communication startup mode selection

- Used to select the operation mode of the inverter. Mode can be changed as desired between operation using external signals (external operation), operation from the PU (FR-PU04/FR-PU07), combined operation of PU operation and external operation (external/PU combined operation, and network operation (when RS-485 communication or a communication option is used)

Pr. 79 Setting	Description	LED Indication : OFF : ON
0 (initial value)	Use external/PU switchover mode (press  to switch between the PU and external operation mode. At power on, the inverter is placed in the external operation mode.	External operation mode  PU operation mode 
1	Fixed to PU operation mode	
2	Fixed to external operation mode Operation can be performed by switching between the external and Net operation mode.	External operation mode  NET operation mode 
3	External/PU combined operation mode 1	
	<b>Running frequency</b> Operation panel and PU (FR-PU04/FR-PU07) setting or external signal input (multi-speed setting, across terminals 4-5 (valid when AU signal turns on)).	<b>Start signal</b> External signal input (terminal STF, STR)
4	External/PU combined operation mode 2	
	<b>Running frequency</b> External signal input (terminal 2, 4, JOG, multi-speed selection, etc.)	<b>Start signal</b> Input from the operation panel and the PU (FR-PU04/FR-PU07) ()
6	Switchover mode Switch among PU operation, external operation, and NET operation while keeping the same operating status.	PU operation mode  External operation mode  NET operation mode 
7	External operation mode (PU operation interlock) X12 signal ON Operation mode can be switched to the PU operation mode. (output stop during external operation) X12 signal OFF Operation mode can not be switched to the PU operation mode.	PU operation mode  External operation mode 

- Specify the operation mode at power on (Pr. 340)
  - When power is switched on or when power comes back on after instantaneous power failure, the inverter can be started up in the network operation mode. After the inverter has started up in the network operation mode, parameter write and operation can be performed from a program. Set this mode for communication operation using the inverter RS-485 communication or communication option.
  - You can set the operation mode at power on (reset) according to the Pr. 79 and Pr. 340 settings.

Pr. 340 Setting	Pr. 79 Setting	Operation Mode at Power-on, Power Restoration, Reset	Operation Mode Switching
0 (initial value)	As set in Pr. 79.		
1	0	NET operation mode	Can be switched to external, PU or NET operation mode*1
	1	PU operation mode	Fixed to PU operation mode
	2	NET operation mode	Switching between the external and NET operation mode is enabled Switching to PU operation mode disabled
	3, 4	External/PU combined operation mode	Operation mode switching disabled
	6	NET operation mode	Switching among the external, PU, and NET operation mode is enabled while running.
	7	X12 (MRS) signal ON ..NET operation mode	Can be switched to external, PU or NET operation mode*1
		X12 (MRS) signal ON ..External operation mode	Fixed to external operation mode (forcibly switched to external operation mode)
10	0	NET operation mode	Switching between the PU and Net operation mode is enabled*2
	1	PU operation mode	Fixed to PU operation mode
	2	NET operation mode	Fixed to NET operation mode
	3, 4	External/PU combined operation mode	Operation mode switching disabled
	6	NET operation mode	Switching between the PU and NET operation mode is enabled while running*2
	7	External operation mode	Fixed to external operation mode (forcibly switched to external operation mode)

\*1 Operation mode can not be directly changed between the PU operation mode and network operation mode  
 \*2 Operation mode can be changed between the PU operation mode and network operation mode with key of the operation panel and X65 signal.

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram Specification
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

**Pr. 80, 81, 89, 800**

**Selection of control method and control mode** **AD MFVC** **GP MFVC**

*Pr. 80 Motor capacity* *Pr. 81 Number of motor poles*  
*Pr. 89 Speed control gain (advanced magnetic flux vector)* *Pr. 800 Control method selection*

Advanced magnetic flux vector control and general-purpose magnetic flux vector control can be selected by setting the motor capacity, number of poles in *Pr. 80 and Pr. 81*. Selection of advanced magnetic flux vector control or general-purpose magnetic flux vector control can be made by *Pr. 800*.

Parameter Number	Setting Range	Description
80	0.1 to 15kW	Set the applied motor capacity.
	9999 (initial value)	V/F Control
81	2, 4, 6, 8, 10	Set the number of motor poles.
	9999 (initial value)	V/F Control
800	20 (initial value)	Advanced magnetic flux vector control *
	30	General-purpose magnetic flux vector control *

\* Set a value other than "9999" in *Pr. 80* and *Pr. 81*.

- The motor speed fluctuation at load fluctuation can be adjusted using *Pr. 89*.

**Pr. 82 to 84, 90 to 94, 96, 298, 859**

**Offline auto tuning**

<i>Pr. 82 Motor excitation current</i>	<i>Pr. 83 Motor rated voltage</i>
<i>Pr. 84 Rated motor frequency</i>	<i>Pr. 90 Motor constant (R1)</i>
<i>Pr. 91 Motor constants (R2)</i>	<i>Pr. 92 Motor constant (L1)</i>
<i>Pr. 93 Motor constant (L2)</i>	<i>Pr. 94 Motor constant (X)</i>
<i>Pr. 96 Auto tuning setting/status</i>	<i>Pr. 298 Frequency search gain</i>
<i>Pr. 859 Torque current</i>	

Offline auto tuning operation for automatic calculation of motor constants can be executed when using advanced magnetic flux vector control and general-purpose magnetic flux vector control. When offline auto tuning is performed under V/F control, *Pr. 298 Frequency search gain* necessary for frequency search for automatic restart after instantaneous power failure is set as well as the motor constants (R1).

Parameter Number	Setting Range	Description
96	0 (initial value)	Without offline auto tuning
	1	Offline auto tuning for advanced magnetic flux vector control
	11	Offline auto tuning for general-purpose magnetic flux vector control (compatible with FR-E500 series)
	21	Offline auto tuning for V/F control (automatic restart after instantaneous power failure (with frequency search))

- You can copy the offline auto tuning data (motor constants) to another inverter with the PU (FR-PU07).
- Even when motors (other manufacturer's motor, SF-JRC, etc.) other than Mitsubishi standard motor (SF-JR SF-HR 0.2kW or more) and Mitsubishi constant-torque motor (SF-JRCA SF-HRCA four-pole 0.4kW to 15kW) are used or the wiring length is long, using the offline auto tuning function runs the motor with the optimum operating characteristics.
- Offline auto tuning conditions
  - A motor should be connected.
  - The motor capacity is equal to or one rank lower than the inverter capacity.  
(note that the capacity should be 0.1kW or more)
  - The maximum frequency is 120Hz.
  - A high-slip motor, high-speed motor and special motor cannot be tuned.
- As the motor may run slightly, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs.  
\* This instruction must be followed especially in elevator.  
Note that if the motor runs slightly, tuning performance is unaffected.

**Pr. 89** ➡ Refer to the section about *Pr. 80*.

**Pr. 117 to 124, 342, 343, 502, 549**

**Communication initial setting**

<i>Pr. 117 PU communication station number</i>	<i>Pr. 118 PU communication speed</i>
<i>Pr. 119 PU communication stop bit length</i>	<i>Pr. 120 PU communication parity check</i>
<i>Pr. 121 Number of PU communication retries</i>	<i>Pr. 122 PU communication check time interval</i>
<i>Pr. 123 PU communication waiting time setting</i>	<i>Pr. 124 PU communication CR/LF selection</i>
<i>Pr. 342 Communication EEPROM write selection</i>	<i>Pr. 343 Communication error count</i>
<i>Pr. 502 Stop mode selection at communication error</i>	<i>Pr. 549 Protocol selection</i>

**(1) Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 124)**

Used to perform required settings for RS-485 communication between the inverter and personal computer.

- Use PU connector of the inverter for communication.
- You can perform parameter setting, monitoring, etc. using the Mitsubishi inverter protocol or Modbus-RTU protocol.
- To make communication between the personal computer and inverter, initialization of the communication specifications must be made to the inverter.

Data communication cannot be made if the initial settings are not made or there is any setting error.

Pr. Number	Setting Range	Description
117	0 to 31 (0 to 247) *1	Specify the inverter station number. Set the inverter station numbers when two or more inverters are connected to one personal computer.
118	48, 96, 192, 384	Set the communication speed. The setting value × 100 equals the communication speed. For example, the communication speed is 19200bps when the setting value is 192.
119	0 1 (initial value) 10 11	<b>Stop bit length</b>
		<b>Data length</b>
		1bit
		2bit
1bit		
2bit		
120	0 1 2 (initial value)	Without parity check With odd parity check With even parity check
121	0 to 10	Set the permissible number of retries at occurrence of a data receive error. If the number of consecutive errors exceeds the permissible value, the inverter will come to an alarm stop.
	9999	If a communication error occurs, the inverter will not come to an alarm stop.
122	0 (initial value)	RS-485 communication can be made. Note that a communication error (E.PUE) occurs as soon as the inverter is switched to the operation mode with control source.
	0.1 to 999.8s	Sets the interval of communication check time. If a no-communication state persists for longer than the permissible time, the inverter will come to an alarm stop.
	9999	No communication check
123	0 to 150ms	Set the waiting time between data transmission to the inverter and response.
	9999 (initial value)	Set with communication data.
124	0	Without CR/LF
	1 (initial value)	With CR
	2	With CR/LF

Pr. Number	Setting Range	Description			
		At alarm occurrence	Indication	Error output	At error removal
502	0 (initial value) 3	Coasts to stop.	E.PUE	Output	Stop (E.PUE)
	1	Decelerates to stop	After stop E.PUE	Output after stop	Stop (E.PUE)
	2	Decelerates to stop	After stop E.PUE	Without output	Automatic restart functions

\*1 When making communication through Modbus-RTU protocol (Pr. 549 = "1"), the setting range within parenthesis is applied.

**(2) Communication EEPROM write selection (Pr. 342)**

Parameters written via the inverter's PU connector or from the communication option can be written to the RAM. When performing parameter change frequently, set "1" in Pr. 342.

**(3) Modbus-RTU communication specifications (Pr. 343, Pr. 549)**

Pr. Number	Setting Range	Description
343	—	Displays the number of communication errors during Modbus-RTU communication. (Reading only)
549	0 (initial value)	Mitsubishi inverter (computer link operation) protocol
	1	Modbus-RTU protocol

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

**Pr. 125, 126, 241, C2 (902) to C7 (905), C22 (922) to C25 (923)**

**Analog input frequency change and adjustment (calibration)**

- Pr. 125 Terminal 2 frequency setting gain frequency*
- Pr. 241 Analog input display unit switchover*
- C3 (Pr. 902) Terminal 2 frequency setting bias*
- C5(Pr. 904) Terminal 4 frequency setting bias frequency*
- C7 (Pr. 905) Terminal 4 frequency setting gain*
- C23 (Pr. 922) Frequency setting voltage bias (built-in potentiometer)*
- C25 (Pr. 923) Frequency setting voltage gain (built-in potentiometer)*
- Pr. 126 Terminal 4 frequency setting gain frequency*
- C2 (Pr. 902) Terminal 2 frequency setting bias frequency*
- C4 (Pr. 903) Terminal 2 frequency setting gain*
- C6 (Pr. 904) Terminal 4 frequency setting bias*
- C22 (Pr. 922) Frequency setting voltage bias frequency (built-in potentiometer)*
- C24 (Pr. 923) Frequency setting voltage gain frequency (built-in potentiometer)*

You can set the magnitude (slope) of the output frequency as desired in relation to the frequency setting signal (0 to 5VDC, 0 to 10V or 4 to 20mA).



C22 (Pr. 922) to C25 (Pr. 923) is available when the operation panel (PA02) for the FR-E500 series is connected with cable. You can calibrate the operation panel built-in potentiometer.

**(1) Change the frequency at maximum analog input. (Pr. 125, Pr. 126)**

Set Pr. 125 (Pr. 126) when changing only frequency setting (gain) of the maximum analog input voltage (current). (Other calibration parameter settings need not be changed.)

**(2) Analog input bias/gain calibration (C2 (Pr. 902) to C7 (Pr. 905))**

- The "bias" and "gain" functions are designed to adjust the relationships between the output frequency and the setting input signal, e.g. 0 to 5VDC/0 to 10VDC or 4 to 20mADC entered from outside the inverter.



**(3) Analog input display unit changing (Pr. 241)**

- You can change the analog input display unit (%V/mA) for analog input bias/gain calibration.


**Pr. 127 to 134**

**PID control, Dancer control**

- Pr. 127 PID control automatic switchover frequency*
- Pr. 129 PID proportional band*
- Pr. 131 PID upper limit*
- Pr. 133 PID action set point*
- Pr. 128 PID action selection*
- Pr. 130 PID integral time*
- Pr. 132 PID lower limit*
- Pr. 134 PID differential time*

- The inverter can be used to exercise process control, e.g. flow rate, air volume or pressure. The terminal 2 input signal or parameter setting is used as a set point and the terminal 4 input signal used as a feedback value to constitute a feedback system for PID control.

- Pr. 128 = "20, 21" (measured value input)



- Performs PID control by feedbacking the position signal of the dancer roller, controlling the dancer roller is in the specified position. Performs dancer control by setting 40 to 43 in Pr. 128 PID action selection. The main speed command is the speed command of each operation mode (external, PU, communication). Performs PID control by the position detection signal of the dancer roller, then the result is added to the main speed command.

**Pr. 145**

**Parameter unit display language selection**

Pr. 145 PU display language selection

You can switch the display language of the parameter unit (FR-PU04/FR-PU07) to another.

Pr. 145 Setting	Description
0 (initial value)	Japanese
1	English
2	German
3	French
4	Spanish
5	Italian
6	Swedish
7	Finnish

**Pr. 146**

**Built-in potentiometer switching**

Pr. 146 Built-in potentiometer switching

When connecting the operation panel (PA02) of the FR-E500 series with a cable, use Pr. 146 Built-in potentiometer switching for selecting the operation using the built-in frequency setting potentiometer, or using [UP/DOWN] key.

Pr. 146 Setting	Description
0	Built-in frequency setting potentiometer gain
1 (initial value)	Digital frequency setting by the [UP/DOWN] key.
9999	Frequency setting with the built-in frequency setting potentiometer is available when the frequency set by [UP/DOWN] key is "0Hz".

**Pr. 150 to 153**


**Detection of output current (Y12 signal)  
Detection of zero current (Y13 signal)**

*Pr. 150 Output current detection level*    *Pr. 151 Output current detection signal delay time*  
*Pr. 152 Zero current detection level*    *Pr. 153 Zero current detection time*

The output power during inverter running can be detected and output to the output terminal.


**(1) Output current detection (Y12 signal, Pr. 150, Pr. 151)**

- The output current detection function can be used for excessive torque detection, etc.
- If the output current remains higher than the *Pr. 150* setting during inverter operation for longer than the time set in *Pr. 151*, the output current detection signal (Y12) is output from the inverter's open collector or relay output terminal.



**(2) Zero current detection (Y13 signal, Pr. 152, Pr. 153)**

- If the output current remains lower than the *Pr. 152* setting during inverter operation for longer than the time set in *Pr. 153*, the zero current detection (Y13) signal is output from the inverter's open collector or relay output terminal.



**Pr. 156, 157** ➔ Refer to the section about *Pr. 22*.

**Pr. 160, 172 to 174**

**User group function**

*Pr. 160 User group read selection*    *Pr. 172 User group registered display/batch clear*  
*Pr. 173 User group registration*    *Pr. 174 User group clear*

- Parameter which can be read from the operation panel and parameter unit can be restricted.  
The inverter is set to display all parameters with initial setting.

Pr. 160 Setting	Description
0 (initial value)	All parameters are displayed.
1	Only the parameters registered in the user group can be displayed.
9999	Only the simple mode parameters can be displayed.

- User group function (*Pr. 160, Pr. 172 to Pr. 174*)
  - The user group function is designed to display only the parameters necessary for setting.
  - From among all parameters, a maximum of 16 parameters can be registered in the user group. When "1" is set in *Pr. 160*, only parameters registered in the user group can be accessed for reading and writing. (The parameters not registered in the user group can not be read.)
  - Set parameter numbers in *Pr. 173* to register parameters in the user group.
  - To delete a parameter from the user group, set its parameter number in *Pr. 174*. To batch-delete the registered parameters, set *Pr. 172* to "9999".

**Pr. 161, 295**

**Operation selection of the operation panel**

*Pr. 161 Frequency setting/key lock operation selection*    *Pr. 295 Magnitude of frequency change setting*

- The setting dial of the operation panel can be used for setting like a potentiometer.
- The key operation of the operation panel can be disabled.

Pr. 161 Setting	Description	
0 (initial value)	Setting dial frequency setting mode	Key lock mode
1	Setting dial potentiometer mode	invalid
10	Setting dial frequency setting mode	Key lock mode
11	Setting dial potentiometer mode	valid

- When setting the set frequency with the setting dial, the frequency setting increments of the setting dial can be changed, in proportion as the rotated amount of the setting dial (speed).

**Pr. 162, 165** ➔ Refer to the section about *Pr. 57*.

**Pr. 168, 169** Parameter for manufacturer setting. Do not set.

**Pr. 170, 171** ➔ Refer to the section about *Pr. 52*.

**Pr. 172 to 174** ➔ Refer to the section about *Pr. 160*.

## Pr.178 to 184

### Function assignment of input terminal

Pr. 178 STF terminal function selection    Pr. 179 STR terminal function selection  
 Pr. 180 RL terminal function selection    Pr. 181 RM terminal function selection  
 Pr. 182 RH terminal function selection    Pr. 183 MRS terminal function selection  
 Pr. 184 RES terminal function selection

Use these parameters to select/change the input terminal functions.

Pr. 178 to Pr. 184 Setting	Signal	Functions	
0	RL	Pr. 59 = 0 (initial value)	Low-speed operation command
		Pr. 59 = 1, 2 *1	Remote setting (setting clear)
		Pr. 270 = 1 *2	Stop-on contact selection 0
1	RM	Pr. 59 = 0 (initial value)	Middle-speed operation command
		Pr. 59 = 1, 2 *1	Remote setting (deceleration)
2	RH	Pr. 59 = 0 (initial value)	High-speed operation command
		Pr. 59 = 1, 2 *1	Remote setting (acceleration)
3	RT	Second function selection	
		Pr. 270 = 1 *2	Stop-on contact selection 1
4	AU	Terminal 4 input selection	
5	JOG	Jog operation selection	
7	OH	External thermal relay input*3	
8	REX	15-speed selection (combination with three speeds RL, RM, RH)	
10	X10	Inverter operation enable signal (FR-HC/FR-CV connection)	
12	X12	PU operation external interlock	
14	X14	PID control valid terminal	
15	BRI	Brake opening completion signal	
16	X16	PU-external operation switchover	
18	X18	V/F switchover (V/F control is exercised when X18 is on)	
24	MRS	Output stop	
25	STOP	Start self-holding selection	
60	STF	Forward rotation command (assigned to STF terminal (Pr. 178) only)	
61	STR	Reverse rotation command (assigned to STR terminal (Pr. 179) only)	
62	RES	Inverter reset	
65	X65	PU/NET operation switchover	
66	X66	External/NET operation switchover	
67	X67	Command source switchover	
9999	—	No function	

\*1 When Pr. 59 Remote function selection = "1 or 2", the functions of the RL, RM and RH signals change as listed above.

\*2 When Pr. 270 = "1", the functions of the RL and RT signals change as listed above.

\*3 The OH signal turns on when the relay contact "opens".

## Pr.190 to 192

### Terminal assignment of output terminal

Pr. 190 RUN terminal function selection    Pr. 191 FU terminal function selection  
 Pr. 192 A,B,C terminal function selection

You can change the functions of the open collector output terminal and relay output terminal.

Pr. 190 to Pr. 196 Setting		Signal	Functions
Positive logic	Negative logic		
0	100	RUN	Inverter running
1	101	SU	Up to frequency
3	103	OL	Overload alarm
4	104	FU	Output frequency detection
7	107	RBP	Regenerative brake prealarm
8	108	THP	Electronic thermal relay function prealarm
11	111	RY	Inverter operation ready
12	112	Y12	Output current detection
13	113	Y13	Zero current detection
14	114	FDN	PID lower limit
15	115	FUP	PID upper limit
16	116	RL	PID forward/reverse rotation output
20	120	BOF	Brake opening request
25	125	FAN	Fan fault output
26	126	FIN	Heatsink overheat pre-alarm
46	146	Y46	During deceleration due to instantaneous power failure (retained until release)
47	147	PID	During PID control activated
64	164	Y64	During retry
90	190	Y90	Life alarm
91	191	Y91	Fault output 3 (power-off signal)
93	193	Y93	Current average value monitor signal
95	195	Y95	Maintenance timer signal
96	196	REM	Remote output
98	198	LF	Alarm output
99	199	ALM	Fault output
9999	—	—	No function

Pr. 232 to 239 ➔ Refer to the section about Pr. 4.

Pr. 240 ➔ Refer to the section about Pr. 72.

Pr. 241 ➔ Refer to the section about Pr. 125.

## Pr.244

### Increase cooling fan life

Pr. 244 Cooling fan operation selection

You can control the operation of the cooling fan (200V class 1.5K or more) built in the inverter.

Pr. 244 Setting	Description
0	Operates in power-on status. Cooling fan on/off control invalid (the cooling fan is always on at power on)
1 (initial value)	Cooling fan on/off control valid. The fan is always on while the inverter is running. During a stop, the inverter status is monitored and the fan switches on-off according to the temperature.

## Pr.245 to 247

### Slip compensation

Pr. 245 Rated slip    Pr. 246 Slip compensation time constant  
 Pr. 247 Constant-power range slip compensation selection

The inverter output current may be used to assume motor slip to keep the motor speed constant.

**Pr.249**

**Earth (ground) fault detection at start**

*Pr. 249 Earth (ground) fault detection at start*

You can choose whether to make earth (ground) fault detection at start valid or invalid. Earth (ground) fault detection is executed only right after the start signal is input to the inverter.

Pr. 249 Setting	Description
0 (initial value)	Without earth (ground) fault detection
1	With earth (ground) fault detection*

- \* As detection is executed at starting, output is delayed for approx. 20ms every starting.
- If an earth (ground) fault is detected with "1" set in Pr. 249, fault output (E.GF) is displayed and the output is shut off.
- Protective function will not activate if an earth (ground) fault occurs during operation.
- If the motor capacity is smaller than the inverter capacity for the 5.5K or more, earth (ground) fault detection may not be provided.

**Pr.250**

**Selection of motor stopping method and start signal**

*Pr. 250 Stop selection*


Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns off.

Used to stop the motor with a mechanical brake, etc. together with switching off of the start signal.


You can also select the operations of the start signals (STF/STR).

Pr. 250 Setting	Description	
	Start signal (STF/STR)	Stop operation
0 to 100s	STF signal: Forward rotation start STR signal: Reverse rotation start	The motor is coasted to a stop when the preset time elapses after the start signal is turned off.
1000s to 1100s	STF signal: Start signal STR signal: Forward/reverse signal	The motor is coasted to a stop (Pr. 250 - 1000)s after the start signal is turned off.
9999	STF signal: Forward rotation start STR signal: Reverse rotation start	When the start signal is turned off, the motor decelerates to stop.
8888	STF signal: Start signal STR signal: Forward/reverse signal	

When "9999 (initial value) or 8888" is set in Pr. 250



When a value other than "9999" (initial value) or "8888" is set in Pr. 250



**Pr.251, 872**

**Input/output phase failure protection selection**

*Pr. 251 Output phase loss protection selection Pr. 872 Input phase loss protection selection*

You can disable the output phase failure protection function that stops the inverter output if one of the inverter output side (load side) three phases (U, V, W) opens.

The input phase failure protection function of the inverter input side (R, S, T) can be made valid.

Pr. Number	Setting Range	Description
251	0	Without output phase failure protection
	1 (initial value)	With output phase failure protection
872	0	Without input phase failure protection
	1 (initial value)	With input phase failure protection

**Pr.255 to 259**

**Display of the life of the inverter parts**

*Pr. 255 Life alarm status display Pr. 256 Inrush current limit circuit life display  
Pr. 257 Control circuit capacitor life display Pr. 258 Main circuit capacitor life display  
Pr. 259 Main circuit capacitor life measuring*

Degrees of deterioration of main circuit capacitor, control circuit capacitor or inrush current limit circuit and cooling fan can be diagnosed by monitor.

When any part has approached the end of its life, an alarm can be output by self diagnosis to prevent a fault.

(Use the life check of this function as a guideline since the life except the main circuit capacitor is calculated theoretically.)

Pr. Number	Setting Range	Description
255	(0 to 15)	Displays whether the control circuit capacitor, main circuit capacitor, cooling fan, and each parts of the inrush current limit circuit has reached the life alarm output level or not. (Reading only)
256	(0 to 100%)	Displays the deterioration degree of the inrush current limit circuit. (Reading only)
257	(0 to 100%)	Displays the deterioration degree of the control circuit capacitor. (Reading only)
258	(0 to 100%)	Displays the deterioration degree of the main circuit capacitor. (Reading only) The value measured by Pr. 259 is displayed.
259	0, 1	Setting "1" and turning the power supply off starts the measurement of the main circuit capacitor life. When the Pr. 259 value is "3" after powering on again, the measuring is completed. Displays the deterioration degree in Pr. 258.

**Pr.261**

**Operation at instantaneous power failure**


Pr. 261 Power failure stop selection

When a power failure or undervoltage occurs, the inverter can be decelerated to a stop or can be decelerated and re-accelerated to the set frequency.

Pr. Number	Setting Range	Description
261	0 (initial value)	Coasts to stop. When undervoltage or power failure occurs, the inverter output is shut off.
	1	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop.
	2	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop. If power is restored during a power failure, the inverter accelerates again.


**(1) Power failure stop mode (Pr. 261 = "1")**

- If power is restored during power failure deceleration, deceleration to a stop is continued and the inverter remains stopped. To restart, turn off the start signal once, then turn it on again.



**(2) Original operation continuation at instantaneous power failure function (Pr. 261 = "2")**

- When power is restored during deceleration after a power failure, acceleration is made again up to the set frequency.



**Pr.267** → Refer to the section about Pr. 73.

**Pr.268** → Refer to the section about Pr. 52.

**Pr.269** Parameter for manufacturer setting. Do not set.

**Pr.270, 275, 276, 6, 48**

**Stop-on-contact control** AD MFVC GP MFVC

Pr. 270 Stop-on contact control selection      Pr. 275 Stop-on contact excitation current low-speed multiplying factor  
 Pr. 276 PWM carrier frequency at stop-on contact      Pr. 6 Multi-speed setting (low speed)  
 Pr. 48 Second stall prevention operation current


To ensure accurate positioning at the upper limit etc. of a lift, stop-on-contact control causes a mechanical brake to be closed while the motor is developing a holding torque to keep the load in contact with a mechanical stopper etc.

This function suppresses vibration which is liable to occur when the load is stopped upon contact in vertical motion applications, ensuring steady precise positioning.

Pr. 270 Setting	Description
0 (initial value)	Without stop-on-contact control
1	Stop-on-contact control

- Select advanced magnetic flux vector control or general-purpose magnetic flux vector control.

When both the RT and RL signals are switched on, the inverter enters the stop-on contact mode, in which operation is performed at the frequency set in Pr. 6 "Multi-speed setting (low speed)" independently of the preceding speed.



\* Goes into stop-on-contact control when both RL and RT switch on. RL and RT may be switched on in any order with any time difference.  
 (a) Acceleration time (Pr. 7)    (b) Deceleration time (Pr. 8)  
 (c) Second deceleration time (Pr. 44/Pr. 45)

Pr. Number	Setting Range	Description
6	0 to 400Hz	Sets the output frequency for stop-on-contact control. The frequency should be as low as possible (about 2Hz). If it is set to more than 30Hz, the operating frequency will be 30Hz.
48	0 to 200%	Sets the stall prevention operation level for stall prevention operation level. (Pr. 22 when Pr. 48 = "9999")
275	0 to 300%	Usually set a value between 130% and 180%. Set the force (holding torque) for stop-on-contact control.
	9999	Without compensation.
276	0 to 9	Sets a PWM carrier frequency for stop-on-contact control.
	9999	As set in Pr. 72 PWM frequency selection.

**Pr. 278 to 283, 292**

**Brake sequence function** AD MFVC GP MFVC

- Pr. 278 Brake opening frequency* *Pr. 279 Brake opening current*
- Pr. 280 Brake opening current detection time* *Pr. 281 Brake operation time at start*
- Pr. 282 Brake operation frequency* *Pr. 283 Brake operation time at stop*
- Pr. 292 Automatic acceleration/deceleration*


This function is used to output from the inverter the mechanical brake opening completion signal timing signal in vertical lift and other applications.

This function prevents the load from dropping with gravity at a start due to the operation timing error of the mechanical brake or an overcurrent alarm from occurring at a stop, ensuring secure operation.


<Operation example>

- **At start:** When the start signal is input to the inverter, the inverter starts running. When the internal speed command reaches the value set in *Pr. 278* and the output current is not less than the value set in *Pr. 279*, the inverter outputs the brake opening request signal (BOF) after the time set in *Pr. 280* has elapsed.  
When the time set in *Pr. 281* elapses after the brake opening completion signal (BRI) was activated, the inverter increases the output frequency to the set speed.
  - **At stop:** When the speed has decreased to the frequency set in *Pr. 282*, the brake opening request signal (BOF) is turned off. When the time set in *Pr. 283* elapses after the brake operation confirmation signal (BRI) was activated, the inverter output is switched off.
- \* If *Pr. 292* = "8" (mechanical brake opening completion signal not input), this time is the time after the brake opening request signal is output.

1) *Pr. 292* = "7" (brake opening completion signal input)



2) *Pr. 292* = "8" (brake opening completion signal not input)



Pr. Number	Setting Range	Description
278	0 to 30Hz	Set to the rated slip frequency of the motor + about 1.0Hz. This parameter may be set only if <i>Pr. 278</i> ≤ <i>Pr. 282</i> .
279	0 to 200%	Generally, set this parameter to about 50 to 90%. If the setting is too low, the load is liable to drop due to gravity at start. Suppose that the rated inverter current is 100%.
280	0 to 2s	Generally, set this parameter to about 0.1 to 0.3s.
281	0 to 5s	<i>Pr. 292</i> = 7: Set the mechanical delay time until the brake is loosened. <i>Pr. 292</i> = 8: Set the mechanical delay time until the brake is loosened + about 0.1 to 0.2s.
282	0 to 30Hz	At this frequency, the brake opening request signal (BOF) is switched off. Generally, set this parameter to the <i>Pr. 278</i> setting + 3 to 4Hz. This parameter may be only set if <i>Pr. 282</i> ≥ <i>Pr. 278</i> .
283	0 to 5s	<i>Pr. 292</i> = 7: Set the mechanical delay time until the brake is closed + 0.1s. <i>Pr. 292</i> = 8: Set the mechanical delay time until the brake is closed + 0.2 to 0.3s.
292	0, 1, 7, 8, 11	Brake sequence function is made valid when a setting is "7" or "8".

**Pr. 286, 287**


**Droop control** AD MFVC

- Pr. 286 Droop gain* *Pr. 287 Droop filter time constant*

This function is designed to balance the load in proportion to the load torque to provide the speed drooping characteristic. This function is effective for balancing the load when using multiple inverters

Pr. Number	Setting Range	Description
286	0 (initial value)	Droop control is invalid
	0.1 to 100%	Set the drooping amount at the rated torque as a percentage with respect to the rated motor frequency.
287	0.00 to 1.00s	Set the time constant of the filter applied on the torque amount current.

- **Droop control**  
This control is valid when a value other than "0" is set in *Pr. 286* under advanced magnetic flux vector control.  
The maximum droop compensation frequency is 120Hz.



- Pr. 292, 293** ➔ Refer to the section about *Pr. 61*.
- Pr. 295** ➔ Refer to the section about *Pr. 161*.
- Pr. 298** ➔ Refer to the section about *Pr. 82*.
- Pr. 299** ➔ Refer to the section about *Pr. 57*.

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

**Pr. 338, 339, 550, 551**

**Operation command source and speed command source during communication operation**

*Pr. 338 Communication operation command source    Pr. 339 Communication speed command source  
Pr. 550 NET mode operation command source selection    Pr. 551 PU mode control source selection*

When the RS-485 communication with the PU connector or communication option is used, the external operation command and speed command can be made valid. Operation command in the PU operation mode can be selected.

Pr. Number	Setting Range	Description
338	0 (initial value)	Operation command source communication
	1	Operation command source external
339	0 (initial value)	Speed command source communication
	1	Speed command source external (Frequency setting from communication is invalid, terminal 2 setting from external is valid)
	2	Speed command source external (Frequency setting from communication is valid, terminal 2 setting from external is invalid)
550*	0	Selects the communication option as NET operation mode command source.
	2	Selects the PU connector as the NET operation mode control source
	9999 (initial value)	Automatic communication option recognition Normally, PU connector is valid. When a communication option is mounted, the communication option is valid.
551*	2	Selects the PU connector as the PU operation mode control source
	3	Select the USB connector as the PU operation mode control source
	4	Selects the operation panel as the PU operation mode control source.
	9999 (initial value)	USB automatic recognition Normally, operation panel is valid. When the parameter unit is connected to the PU connector, PU is valid. When USB is connected, USB is valid.

\* Pr. 550 and Pr. 551 are always write-enabled.

**Pr. 340** ➡ Refer to the section about Pr. 79.

**Pr. 342, 343** ➡ Refer to the section about Pr. 117.

**Pr. 450** ➡ Refer to the section about Pr. 71.

**Pr. 495 to 497**

**Remote output function (REM signal)**

*Pr. 495 Remote output selection    Pr. 496 Remote output data 1  
Pr. 497 Remote output data 2*

You can utilize the on/off of the inverter's output signals instead of the remote output terminal of the PLC.

Pr. Number	Setting Range	Description	
495	0 (initial value)	Remote output data clear at powering off	Remote output data clear at inverter reset
	1	Remote output data retention at powering off	
	10	Remote output data clear at powering off	Remote output data retention at inverter reset
	11	Remote output data retention at powering off	
496*	0 to 4095	Refer to the following diagram.	
497*	0 to 4095		

\* The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

**<Remote output data>**

Pr. 496

b11										b0	
*	*	*	*	*	*	ABC	FU	*	*	*	RUN

Pr. 497

b11										b0	
*	*	RA3*2	RA2*2	RA1*2	Y6*2	Y5*2	Y4*2	Y3*2	Y2*2	Y1*2	Y0*2

\*1 As desired (always 0 when read)

\*2 Y0 to Y6 are available only when the extension output option (FR-A7AY E kit) is fitted

\*3 RA1 to RA3 are available only when the relay output option (FR-A7AR E kit) is fitted

**Pr. 502** ➡ Refer to the section about Pr. 117.


**Pr. 503, 504**

**Maintenance of parts**

Pr. 503 Maintenance timer Pr. 504 Maintenance timer alarm output set time

When the cumulative energization time of the inverter reaches the parameter set time, the maintenance timer output signal (Y95) is output. **MT** (MT) is displayed on the operation panel.

This can be used as a guideline for the maintenance time of peripheral devices.



- The cumulative energization time of the inverter is stored into the E2PROM every hour and indicated in Pr. 503 Maintenance timer in 100h increments. Pr. 503 is clamped at 9998 (999800h).

**Pr. 547, 548**

**Inverter setup using USB communication**

Pr. 547 USB communication station number Pr. 548 USB communication check time interval

Inverter setup with setup software (FR Configurator) can be easily performed by USB communication.

Pr. Number	Setting Range	Description
547	0 (initial value)	Set the station number of USB device (inverter) within the range "0 to 31".
	1 to 31	
548	0 to 999.8	Set the communication check time interval of USB communication. If data is not received within the time set in Pr. 548, <b>EUSB</b> (E.USB) is displayed.
	9999 (initial value)	Communication time interval is not checked.

**Pr. 549** ➡ Refer to the section about Pr. 117.

**Pr. 550, 551** ➡ Refer to the section about Pr. 338.

**Pr. 555 to 557**


**Current average value monitor signal**

Pr. 555 Current average time Pr. 556 Data output mask time  
Pr. 557 Current average value monitor signal output reference current

The average value of the output current during constant speed operation and the maintenance timer value are output as a pulse to the current average value monitor signal (Y93).

The pulse width output to the I/O module of the PLC or the like can be used as a guideline due to abrasion of machines and elongation of belt and for aged deterioration of devices to know the maintenance time.

The current average value monitor signal (Y93) is output as pulse for 20s as 1 cycle and repeatedly output during constant speed operation.



**Pr. 563, 564** ➡ Refer to the section about Pr. 52.

**Pr. 571** ➡ Refer to the section about Pr. 13.

**Pr. 611** ➡ Refer to the section about Pr. 57.

Features  
Peripheral Devices  
Standard Specifications  
Outline Dimension Drawings  
Terminal Connection Diagram  
Terminal Specification Explanation  
Operation panel Parameter unit FR Configurator  
Parameter List  
Explanations of Parameters  
Protective Functions  
Options  
Instructions  
Motor  
Compatibility  
Warranty  
Inquiry

**Pr.653**

**Reduce mechanical resonance**

*Pr. 653 Speed smoothing control*

Mechanical vibration produced while motor is driving (resonance) can be reduced.

Set 100% in *Pr. 653* and check if the vibration will be reduced. Make adjustment gradually increasing the setting, until the vibration become the smallest.

**Pr.665, 882, 883, 885, 886**

**Regeneration avoidance function**

*Pr. 665 Regeneration avoidance frequency gain*    *Pr. 882 Regeneration avoidance operation selection*


*Pr. 883 Regeneration avoidance operation level*    *Pr. 885 Regeneration avoidance compensation frequency limit value*

*Pr. 886 Regeneration avoidance voltage gain*

This function detects a regeneration status and increases the frequency to avoid the regenerative status.

- Possible to avoid regeneration by automatically increasing the frequency and continue operation if the fan happens to rotate faster than the set speed due to the effect of another fan in the same duct.

Pr. Number	Setting Range	Description
882	0 (initial value)	Regeneration avoidance function invalid
	1	Regeneration avoidance function is always valid
	2	Regeneration avoidance function is valid only during a constant speed operation
883	300 to 800V	Set the bus voltage level at which regeneration avoidance operates. When the bus voltage level is set to low, overvoltage error will be less apt to occur. However, the actual deceleration time increases. The set value must be higher than the "power supply voltage $\times \sqrt{2}$ ".
885	0 to 10Hz	Set the limit value of frequency which rises at activation of regeneration avoidance function.
	9999	Frequency limit invalid
886	0 to 200%	Adjusts responsiveness at activation of regeneration avoidance. A larger setting will improve responsiveness to the bus voltage change. However, the output frequency could become unstable. When the load inertia of the motor is large, decrease the <i>Pr. 886</i> setting. When vibration is not suppressed by decreasing the <i>Pr. 886</i> setting, set a smaller value in <i>Pr. 665</i> .
665		



**Pr. 800** ➔ Refer to the section about *Pr. 80*.

**Pr. 859** ➔ Refer to the section about *Pr. 82*.

**Pr. 872** ➔ Refer to the section about *Pr. 251*.

**Pr.888, 889**

**Free parameter**

*Pr. 889 Free parameter 1*

*Pr. 889 Free parameter 2*

Parameters you can use for your own purposes.

You can input any number within the setting range 0 to 9999.

For example, the number can be used:

- As a unit number when multiple units are used.
- As a pattern number for each operation application when multiple units are used.
- As the year and month of introduction or inspection.

**Pr.C0(900)**


**Adjustment of terminal FM output (calibration)**

*C0 (Pr. 900) FM terminal calibration*

By using the operation panel or parameter unit, you can calibrate terminal FM to full scale deflection.

**FM terminal calibration (C0 (Pr. 900))**

- The terminal FM is preset to output pulses. By setting the calibration parameter *C0 (Pr. 900)*, the meter connected to the inverter can be calibrated by parameter setting without use of a calibration resistor.
- Using the pulse train output of the terminal FM, a digital display can be provided by a digital counter. The monitor value is 1440 pulses/s output at the full-scale value of *Pr. 54 FM terminal function selection*.



- \*1 Not needed when the operation panel or parameter unit (FR-PU04/FR-PU07) is used for calibration. Used when calibration must be made near the frequency meter for such a reason as a remote frequency meter. However, the frequency meter needle may not deflect to full-scale if the calibration resistor is connected. In this case, use this resistor and operation panel or parameter unit together.

**Pr.C2(902) to C7(905), C22(922) to C25(923)**

➔ Refer to the section about *Pr. 125*.

**Pr.990**

**Buzzer control of the operation panel**

*Pr. 990 PU buzzer control*

You can make the buzzer "beep" when you press key of the operation panel and parameter unit (FR-PU04/FR-PU07)

Pr. 990 Setting	Description
0	Without buzzer
1 (initial value)	With buzzer

**Pr.991**

**PU contrast adjustment**

*Pr. 991 PU contrast adjustment*

Contrast adjustment of the LCD of the parameter unit (FR-PU04/FR-PU07) can be performed.

Decreasing the setting value makes contrast light.

Pr. 991 Setting	Description
0 to 63	0: Light ↓ 63: Dark

**Pr.CL, ALLC, Er.CL, CH**

**Clear parameter, initial value change list**

*Pr.CL Parameter clear*

*ALLC All parameter clear*

*Er.CL Alarm history clear*

*Pr.CH Initial value change list*

- Set "1" in *Pr.CL parameter clear* to initialize all parameters. (Calibration parameters are not cleared.) \*
- Set "1" in *ALLC All parameter clear* to initialize all parameters.\*
- Set "1" in *Er.CL Faults history clear* to clear faults history.\*
- Using *Pr.CH Initial value change list*, only the parameters changed from the initial value can be displayed.

\* Parameters are not cleared when "1" is set in *Pr. 77 Parameter write selection*.

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Program Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

# Protective Functions

When a fault occurs, the inverter trips and the PU display automatically changes to any of the following fault or alarm indications.

	Function Name	Description	Display
Error message *2	Operation panel lock	Appears when operation was tried during operation panel lock.	HOLd
	Parameter write error	Appears when an error occurred during parameter writing.	Er 1 to Er 4
	Inverter reset	Appears when the RES signal is on.	Err.
Warnings *3	Stall prevention (overcurrent)	Appears during overcurrent stall prevention.	OL
	Stall prevention (overvoltage)	Appears during overvoltage stall prevention. Appears while the regeneration avoidance function is activated.	oL
	Regenerative brake prealarm	Appears if the regenerative brake duty reaches or exceeds 85% of the Pr. 70 Special regenerative brake duty value. If the regenerative brake duty reaches 100%, a regenerative overvoltage (E. OV_) occurs.	rb
	Electronic thermal relay function prealarm	Appears when the electronic thermal O/L relay has reached 85% of the specified value.	TH
	PU stop	Appears when  on the operation panel was pressed during external operation.	PS
	Maintenance signal output	Appears when the cumulative energization time has exceeded the maintenance output timer set value.	MT
	Undervoltage	Appears when the main circuit power became low voltage.	Uu
Alarms *4	Fan alarm	Appears when the cooling fan remains stopped when operation is required or when the speed has decreased.	Fa
Fault *5	Overcurrent shut-off during acceleration	Appears when an overcurrent occurred during acceleration.	EOC 1
	Overcurrent shut-off during constant speed	Appears when an overcurrent occurred during constant speed operation.	EOC 2
	Overcurrent shut-off during deceleration or stop	Appears when an overcurrent occurred during deceleration and at a stop.	EOC 3
	Regenerative overvoltage shut-off during acceleration	Appears when an overvoltage occurred during acceleration.	EOv 1
	Regenerative overvoltage shut-off during constant speed	Appears when an overvoltage occurred during constant speed operation.	EOv 2
	Regenerative overvoltage shut-off during deceleration or stop	Appears when an overvoltage occurred during deceleration and at a stop.	EOv 3
	Inverter overload shut-off (electronic thermal relay function)*1	Appears when the electronic thermal relay function for inverter element protection was activated.	EFHF
	Motor overload shut-off (electronic thermal relay function)*1	Appears when the electronic thermal relay function for motor protection was activated.	EFHN
	Fin overheat	Appears when the heatsink overheated.	EFIn
	Input phase loss	Appears if one of the three phases on the inverter input side opened.	EILF
	Stall prevention	Appears when the output frequency drops to 1Hz as a result of deceleration due to the excess motor load.	EOLF
	Brake transistor alarm detection	This function stops the inverter output if an alarm occurs in the brake circuit, e.g. damaged brake transistors. In this case, the inverter must be powered off immediately.	E. bE
	Output side earth (ground) fault overcurrent	Appears when an earth (ground) fault occurred on the inverter's output side. (detects only at a start)	E. GF
	Output phase loss	Appears if one of the three phases on the inverter output side opened.	E. LF
	External thermal relay operation*6	Appears when the external thermal relay connected to the OH signal was activated.	EOHF
	Communication option fault	Appears when a communication error occurred in the communication option.	EOP 1
	Option fault	Appears when a contact fault or the like of the connector between the inverter and communication option occurs.	E. 1
	Parameter storage device fault	Appears when operation of the element where parameters stored became abnormal. (control board)	E. PE
	PU disconnection	Appears when a communication error between the PU and inverter occurred, the communication interval exceeded the permissible time during the RS-485 communication with the PU connector, or communication errors exceeded the number of retries during the RS-485 communication.	EPUE
	Retry count excess	Appears when the operation was not restarted within the set number of retries.	ErEr
	CPU error	Appears during the CPU and peripheral circuit errors occurred.	E. 61 E. 71 E.CPU
	Inrush current limit circuit fault	Appears when the resistor of the inrush current limit circuit overheated.	EIOH
	Analog input fault	Appears when voltage is input (7.3V or more for 5s or more) with the terminal 4 set to current input.	EAI E
	Brake sequence error	The inverter output is stopped when a sequence error occurs during use of the brake sequence function (Pr. 278 to Pr. 285).	ENb4 to ENb7
	USB communication fault	Appears when USB communication error occurred.	EUSb
	Internal circuit fault	Appears when an internal circuit error occurred.	E. 13

\*1 Resetting the inverter initializes the internal thermal integrated data of the electronic thermal relay function.  
 \*2 The error message shows an operational error. The inverter output is not shut off.  
 \*3 Warnings are messages given before fault occur. The inverter output is not shut off.  
 \*4 Alarms warn the operator of failures with output signals. The inverter output is not shut off.  
 \*5 When faults occur, the protective functions are activated to inverter trip and output the fault signals.  
 \*6 The external thermal operates only when the OH signal is set in Pr. 178 to Pr. 184 (input terminal function selection).

# Option and Peripheral Devices

## Option list





By fitting the following options to the inverter, the inverter is provided with more functions.  
One type of plug-in option can be mounted.








Name		Type	Applications, Specifications, etc.	Applicable Inverter	
Plug-in type	16-bit digital input	FR-A7AX E kit	<ul style="list-style-type: none"> <li>This input interface sets the high frequency accuracy of the inverter using an external BCD or binary digital signal.</li> <li>BCD code 3 digits (maximum 999) •BCD code 4 digits (maximum 9999)</li> <li>Binary 12 bits (maximum FFFH) •Binary 16 bits (maximum FFFFH)</li> </ul>	Shared among all models	
	Digital output Extension analog output	FR-A7AY E kit	<ul style="list-style-type: none"> <li>This option provides the inverter with open collector outputs selected from among the standard output signals.</li> <li>This option adds two different signals that can be monitored at the terminals AM0 and AM1, such as the output frequency, output voltage and output current.</li> <li>20mADC or 10VDC meter can be connected.</li> </ul>		
	Relay output	FR-A7AR E kit	<ul style="list-style-type: none"> <li>This option provides the inverter with three different relay contact outputs selected from among the standard output signals.</li> </ul>		
	Communication	CC-Link communication	FR-A7NC E kit	<ul style="list-style-type: none"> <li>This option allows the inverter to be operated or monitored or the parameter setting to be changed from PLC, etc.</li> </ul>	Shared among all models (To be released)
		LONWORKS communication	FR-A7NL E kit		
DeviceNet communication		FR-A7ND E kit			
PROFIBUS-DP communication		FR-A7NP E kit			
Stand-alone shared	Parameter unit (8 languages)	FR-PU07 FR-PU04	Interactive parameter unit with LCD display	Shared among all models	
	Parameter unit connection cable	FR-CB20□	Cable for connection of operation panel or parameter unit □ indicates a cable length. (1m, 3m, 5m)		
	USB cable	MR-J3USBCBL3M Cable length 3m	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Connector for amplifier mini-B connector (5 pin)</p> </div> <div style="text-align: center;">  <p>Connector for personal computer A connector</p> </div> </div>	Shared among all models	
	AC reactor	FR-HAL	For harmonic current reduction and inverter input power factor improvement (total power factor approx. 88%)		According to capacities
	DC reactor	FR-HEL	For harmonic current reduction and inverter input power factor improvement (total power factor approx. 93%)	According to capacities	
	Radio noise filter	FR-BIF(H)	For radio noise reduction (connect to the input side)	Shared among all models	
	Line noise filter	FR-BSF01 FR-BLF	For line noise reduction	Shared among all models	
	Brake resistor	MRS type, MYS type	For increasing the regenerative braking capability (permissible duty 3%ED)	For the 0.4K or more	
	High-duty brake resistor	FR-ABR	For improvement of braking capability of the built-in brake of the inverter	For the 0.4K or more	
	Brake unit Resistor unit Discharging resistor	FR-BU2 FR-BR GZG, GRZG type	For increasing the braking capability of the inverter (for high-inertia load or negative load) Brake unit, electrical-discharge resistor and resistor unit are used in combination	For the 0.4K or more	
	Power regeneration common converter Stand-alone reactor dedicated for the FR-CV	FR-CV FR-CVL	Unit which can return motor-generated braking energy back to the power supply in common converter system	According to capacities	
	High power factor converter	FR-HC	The high power factor converter switches the converter section on/off to reshape an input current waveform into a sine wave, greatly suppressing harmonics. (Used in combination with the standard accessory.)	According to capacities	
	DIN rail attachment	FR-UDA01 to 03	Attachment for installation on DIN rail	Compatible with the 3.7K or less	
	FR series manual controller/speed controller	Manual controller	FR-AX	For independent operation. With frequency meter, frequency potentiometer and start switch.	Shared among all models
		DC tach. follower	FR-AL	For synchronous operation (1.5VA) by external signal (0 to 5V, 0 to 10V DC)*	
Three speed selector		FR-AT	For three speed switching, among high, middle and low speed operation (1.5VA)*		
Motorized speed setter		FR-FK	For remote operation. Allows operation to be controlled from several places (5VA)*		
Ratio setter		FR-FH	For ratio operation. The ratios of five inverters can be set (3VA)*		
Speed detector		FR-FP	For tracking operation by a pilot generator (PG) signal (3VA)*		
Master controller		FR-FG	Master controller (5VA) for parallel operation of multiple (maximum 35) inverters.*		
Soft starter		FR-FC	For soft start and stop. Enables acceleration/deceleration in parallel operation (3VA)*		
Deviation detector		FR-FD	For continuous speed control operation. Used in combination with a deviation sensor or synchro (5VA)*		
Preamplifier		FR-FA	Used as an A/V converter or arithmetic amplifier (3VA)*		
Others	Pilot generator	QVAH-10	For tracking operation. 70V/35VAC 500Hz (at 2500r/min)	Shared among all models (To be released)	
	Deviation sensor	YVGC-500W-NS	For continuous speed control operation (mechanical deviation detection) Output 90VAC/90°C		
	Frequency setting potentiometer	WA2W 1kΩ	For frequency setting. Wire-wound 2W 1kΩ type B characteristic		
	Analog frequency meter (64mm × 60mm)	YM206NRI 1mA	Dedicated frequency meter (graduated to 120Hz). Moving-coil type DC ammeter		
	Calibration resistor	RV24YN 10kΩ	For frequency meter calibration. Carbon film type B characteristic		
FR Configurator (VFD setup software)	FR-SW3-SETUP-WJ	Supports an inverter startup to maintenance.	Shared among all models (To be released)		

\* Rated power consumption. The power supply specifications of the FR series manual controllers and speed controllers are 200VAC 50Hz, 220V/220VAC 60Hz, and 115VAC 60Hz.

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

Stand-alone option

Name (type)	Specifications, Structure, etc.																																																																																																																				
<p>AC reactor (for power coordination) FR-HAL-(H)□□K</p> 	<p>● Outline dimension (Unit: mm)</p> <table border="1" data-bbox="371 342 1082 600"> <thead> <tr> <th rowspan="2">Inverter Type</th> <th rowspan="2">W</th> <th rowspan="2">D</th> <th rowspan="2">H</th> <th rowspan="2">Mass (kg)</th> <th rowspan="2">Inverter Type</th> <th rowspan="2">W</th> <th rowspan="2">D</th> <th rowspan="2">H</th> <th rowspan="2">Mass (kg)</th> </tr> <tr> <th colspan="5">(Unit: mm)</th> </tr> </thead> <tbody> <tr> <td rowspan="10">200V</td> <td>0.4K</td> <td>104</td> <td>72</td> <td>99</td> <td>0.6</td> <td rowspan="10">400V</td> <td>H0.4K</td> <td>135</td> <td>59.6</td> <td>115</td> <td>1.5</td> </tr> <tr> <td>0.75K</td> <td>104</td> <td>74</td> <td>99</td> <td>0.8</td> <td>H0.75K</td> <td>135</td> <td>59.6</td> <td>115</td> <td>1.5</td> </tr> <tr> <td>1.5K</td> <td>104</td> <td>77</td> <td>99</td> <td>1.1</td> <td>H1.5K</td> <td>135</td> <td>59.6</td> <td>115</td> <td>1.5</td> </tr> <tr> <td>2.2K</td> <td>115</td> <td>77</td> <td>115</td> <td>1.5</td> <td>H2.2K</td> <td>135</td> <td>59.6</td> <td>115</td> <td>1.5</td> </tr> <tr> <td>3.7K</td> <td>115</td> <td>83</td> <td>115</td> <td>2.2</td> <td>H3.7K</td> <td>135</td> <td>70.6</td> <td>115</td> <td>2.5</td> </tr> <tr> <td>5.5K</td> <td>115</td> <td>83</td> <td>115</td> <td>2.3</td> <td>H5.5K</td> <td>160</td> <td>72</td> <td>142</td> <td>3.5</td> </tr> <tr> <td>7.5K</td> <td>130</td> <td>100</td> <td>135</td> <td>4.2</td> <td>H7.5K</td> <td>160</td> <td>91</td> <td>142</td> <td>5.0</td> </tr> <tr> <td>11K</td> <td>160</td> <td>111</td> <td>164</td> <td>5.2</td> <td>H11K</td> <td>160</td> <td>91</td> <td>146</td> <td>6.0</td> </tr> <tr> <td>15K</td> <td>160</td> <td>126</td> <td>167</td> <td>7.0</td> <td>H15K</td> <td>220</td> <td>105</td> <td>195</td> <td>9.0</td> </tr> </tbody> </table>  <p>(Note) 1. Make selection according to the applied motor capacity. (When the inverter capacity is larger than the motor capacity, make selection according to the motor capacity)                  2. Power factor improving reactor (FR-BAL) can be used.                  Power factor improving effect                  FR-BAL approx. 90%                  FR-HAL approx. 88%                  3. Outline dimension drawing shown is a one of a typical model.                  The shape differs according to each models.                  4. Install the AC reactor (FR-HAL) on horizontal or vertical plane.</p>										Inverter Type	W	D	H	Mass (kg)	Inverter Type	W	D	H	Mass (kg)	(Unit: mm)					200V	0.4K	104	72	99	0.6	400V	H0.4K	135	59.6	115	1.5	0.75K	104	74	99	0.8	H0.75K	135	59.6	115	1.5	1.5K	104	77	99	1.1	H1.5K	135	59.6	115	1.5	2.2K	115	77	115	1.5	H2.2K	135	59.6	115	1.5	3.7K	115	83	115	2.2	H3.7K	135	70.6	115	2.5	5.5K	115	83	115	2.3	H5.5K	160	72	142	3.5	7.5K	130	100	135	4.2	H7.5K	160	91	142	5.0	11K	160	111	164	5.2	H11K	160	91	146	6.0	15K	160	126	167	7.0	H15K	220	105	195	9.0
Inverter Type	W	D	H	Mass (kg)	Inverter Type	W	D	H	Mass (kg)																																																																																																												
										(Unit: mm)																																																																																																											
200V	0.4K	104	72	99	0.6	400V	H0.4K	135	59.6	115	1.5																																																																																																										
	0.75K	104	74	99	0.8		H0.75K	135	59.6	115	1.5																																																																																																										
	1.5K	104	77	99	1.1		H1.5K	135	59.6	115	1.5																																																																																																										
	2.2K	115	77	115	1.5		H2.2K	135	59.6	115	1.5																																																																																																										
	3.7K	115	83	115	2.2		H3.7K	135	70.6	115	2.5																																																																																																										
	5.5K	115	83	115	2.3		H5.5K	160	72	142	3.5																																																																																																										
	7.5K	130	100	135	4.2		H7.5K	160	91	142	5.0																																																																																																										
	11K	160	111	164	5.2		H11K	160	91	146	6.0																																																																																																										
	15K	160	126	167	7.0		H15K	220	105	195	9.0																																																																																																										
	<p>DC reactor (for power coordination) FR-HEL-(H)□□K</p> 	<p>● Outline dimension (Unit: mm)</p> <table border="1" data-bbox="371 857 1082 1115"> <thead> <tr> <th rowspan="2">Inverter Type</th> <th rowspan="2">W</th> <th rowspan="2">D</th> <th rowspan="2">H</th> <th rowspan="2">Mass (kg)</th> <th rowspan="2">Inverter Type</th> <th rowspan="2">W</th> <th rowspan="2">D</th> <th rowspan="2">H</th> <th rowspan="2">Mass (kg)</th> </tr> <tr> <th colspan="5">(Unit: mm)</th> </tr> </thead> <tbody> <tr> <td rowspan="10">200V</td> <td>0.4K</td> <td>70</td> <td>61</td> <td>71</td> <td>0.4</td> <td rowspan="10">400V</td> <td>H0.4K</td> <td>90</td> <td>60</td> <td>78</td> <td>0.6</td> </tr> <tr> <td>0.75K</td> <td>85</td> <td>61</td> <td>81</td> <td>0.5</td> <td>H0.75K</td> <td>66</td> <td>70</td> <td>100</td> <td>0.8</td> </tr> <tr> <td>1.5K</td> <td>85</td> <td>70</td> <td>81</td> <td>0.8</td> <td>H1.5K</td> <td>66</td> <td>80</td> <td>100</td> <td>1</td> </tr> <tr> <td>2.2K</td> <td>85</td> <td>70</td> <td>81</td> <td>0.9</td> <td>H2.2K</td> <td>76</td> <td>80</td> <td>110</td> <td>1.3</td> </tr> <tr> <td>3.7K</td> <td>77</td> <td>82</td> <td>92</td> <td>1.5</td> <td>H3.7K</td> <td>86</td> <td>95</td> <td>120</td> <td>2.3</td> </tr> <tr> <td>5.5K</td> <td>77</td> <td>92</td> <td>92</td> <td>1.9</td> <td>H5.5K</td> <td>96</td> <td>100</td> <td>128</td> <td>3</td> </tr> <tr> <td>7.5K</td> <td>86</td> <td>98</td> <td>113</td> <td>2.5</td> <td>H7.5K</td> <td>96</td> <td>105</td> <td>128</td> <td>3.5</td> </tr> <tr> <td>11K</td> <td>105</td> <td>112</td> <td>133</td> <td>3.3</td> <td>H11K</td> <td>105</td> <td>110</td> <td>137</td> <td>4.5</td> </tr> <tr> <td>15K</td> <td>105</td> <td>115</td> <td>133</td> <td>4.1</td> <td>H15K</td> <td>105</td> <td>125</td> <td>152</td> <td>5</td> </tr> </tbody> </table>  <p>(Note) 1. Be sure to remove the jumper across the inverter terminals P/+-P1. (A failure to do so will produce no power factor improving effect)                  2. The wiring length between the reactor and inverter should be within 5m.                  3. The size of the cables used should be equal to or larger than that of the power supply cables (R/L1, S/L2, T/L3).                  4. Make selection according to the motor capacity.                  (When the inverter capacity is larger than the motor capacity, make selection according to the motor capacity)                  5. Power factor improving reactor (FR-BEL) can be used.                  Power factor improving effect                  FR-BEL approx.95%                  FR-HEL approx.93%                  6. Outline dimension drawing shown is a one of a typical model.                  The shape differs according to each models.                  7. Install the DC reactor (FR-HEL) on horizontal or vertical plane.</p>										Inverter Type	W	D	H	Mass (kg)	Inverter Type	W	D	H	Mass (kg)	(Unit: mm)					200V	0.4K	70	61	71	0.4	400V	H0.4K	90	60	78	0.6	0.75K	85	61	81	0.5	H0.75K	66	70	100	0.8	1.5K	85	70	81	0.8	H1.5K	66	80	100	1	2.2K	85	70	81	0.9	H2.2K	76	80	110	1.3	3.7K	77	82	92	1.5	H3.7K	86	95	120	2.3	5.5K	77	92	92	1.9	H5.5K	96	100	128	3	7.5K	86	98	113	2.5	H7.5K	96	105	128	3.5	11K	105	112	133	3.3	H11K	105	110	137	4.5	15K	105	115	133	4.1	H15K	105	125	152
Inverter Type	W	D	H	Mass (kg)	Inverter Type	W	D	H	Mass (kg)																																																																																																												
										(Unit: mm)																																																																																																											
200V	0.4K	70	61	71	0.4	400V	H0.4K	90	60	78	0.6																																																																																																										
	0.75K	85	61	81	0.5		H0.75K	66	70	100	0.8																																																																																																										
	1.5K	85	70	81	0.8		H1.5K	66	80	100	1																																																																																																										
	2.2K	85	70	81	0.9		H2.2K	76	80	110	1.3																																																																																																										
	3.7K	77	82	92	1.5		H3.7K	86	95	120	2.3																																																																																																										
	5.5K	77	92	92	1.9		H5.5K	96	100	128	3																																																																																																										
	7.5K	86	98	113	2.5		H7.5K	96	105	128	3.5																																																																																																										
	11K	105	112	133	3.3		H11K	105	110	137	4.5																																																																																																										
	15K	105	115	133	4.1		H15K	105	125	152	5																																																																																																										
	<p>Radio noise filter FR-BIF (200V class) FR-BIF-H (400V class)</p> 	<p>● Outline dimension</p>  <p>Leakage currents: 4mA</p>  <p>(Unit: mm)</p> <p>(Note) 1. Can not be connected to the inverter output side.                  2. Wire should be cut as short as possible, and connect to the inverter terminal block.</p>																																																																																																																			

Name (type)	Specifications, Structure, etc.																																																																																																																																																																										
<p><b>Line noise filter</b> FR-BSF01 ...for small capacities FR- BLF</p> 	<p><b>● Outline dimension</b></p> <p><b>FR-BSF01</b></p>  <p><b>FR-BLF</b></p>    <p>(Note) 1. Each phase should be wound at least 3 times (4T, 4 turns) in the same direction. (The greater the number of turns, the more effective result is obtained.) 2. When the thickness of the wire prevents winding, use at least 4 in series and ensure that the current passes through each phase in the same direction. 3. Can be used on the output side in the same way as the input side. 4. Please use FR-BSF01 for inverters with small capacities of 3.7K or less. Thick wires (38mm<sup>2</sup> or more) can not be used. In such cases, use the FR-BLF.</p>																																																																																																																																																																										
<p><b>Brake Resistor</b> MRS type, MYS type</p>	<p><b>● Outline dimension</b></p> <p><b>MRS type</b></p>  <p><b>MYS type</b></p>  <p>(Unit : mm)</p> <table border="1" data-bbox="375 974 1013 1198"> <thead> <tr> <th colspan="2">Resistor Type</th> <th>Permissible Duty</th> <th>Resistance Value (Ω)</th> <th>Permissible Power (W)</th> <th>Applicable Motor Capacity (kW)</th> </tr> </thead> <tbody> <tr> <td rowspan="5">200V output</td> <td rowspan="4">MRS type</td> <td rowspan="4">3%</td> <td>MRS120W200</td> <td>200</td> <td>15</td> <td>0.4</td> </tr> <tr> <td>MRS120W100</td> <td>100</td> <td>30</td> <td>0.75</td> </tr> <tr> <td>MRS120W60</td> <td>60</td> <td>55</td> <td>1.5, 2.2</td> </tr> <tr> <td>MRS120W40</td> <td>40</td> <td>80</td> <td>2.2, 3.7</td> </tr> <tr> <td>MYS type</td> <td>6%</td> <td>MYS220W50*</td> <td>50/2</td> <td>2×80</td> <td>3.7</td> </tr> </tbody> </table> <p>(Note) 1. The temperature of the brake resistor becomes 200°C or more depending on the operation frequency, care must be taken for installation and heat dissipation. 2. The brake resistor can not be used with the 0.1K and 0.2K.</p> <p>* Two unit in parallel</p>	Resistor Type		Permissible Duty	Resistance Value (Ω)	Permissible Power (W)	Applicable Motor Capacity (kW)	200V output	MRS type	3%	MRS120W200	200	15	0.4	MRS120W100	100	30	0.75	MRS120W60	60	55	1.5, 2.2	MRS120W40	40	80	2.2, 3.7	MYS type	6%	MYS220W50*	50/2	2×80	3.7																																																																																																																																											
Resistor Type		Permissible Duty	Resistance Value (Ω)	Permissible Power (W)	Applicable Motor Capacity (kW)																																																																																																																																																																						
200V output	MRS type	3%	MRS120W200	200	15	0.4																																																																																																																																																																					
			MRS120W100	100	30	0.75																																																																																																																																																																					
			MRS120W60	60	55	1.5, 2.2																																																																																																																																																																					
			MRS120W40	40	80	2.2, 3.7																																																																																																																																																																					
	MYS type	6%	MYS220W50*	50/2	2×80	3.7																																																																																																																																																																					
<p><b>High-duty brake resistor</b> FR-ABR-(H)□□</p> 	<p><b>● Outline dimension</b></p> <table border="1" data-bbox="375 1265 1452 1646"> <thead> <tr> <th rowspan="2">Brake Resistor Type</th> <th rowspan="2">Permissible Brake Duty</th> <th colspan="4">Outline Dimension</th> <th rowspan="2">Resistance Value (Ω)</th> <th rowspan="2">Approx. Mass (kg)</th> <th rowspan="2">Brake Resistor Type</th> <th rowspan="2">Permissible Brake Duty</th> <th colspan="4">Outline Dimension</th> <th rowspan="2">Resistance Value (Ω)</th> <th rowspan="2">Approx. Mass (kg)</th> </tr> <tr> <th>W</th> <th>W1</th> <th>D</th> <th>H</th> <th>W</th> <th>W1</th> <th>D</th> <th>H</th> </tr> </thead> <tbody> <tr> <td rowspan="8">200V</td> <td>FR-ABR-0.4K</td> <td>10%</td> <td>140</td> <td>500</td> <td>40</td> <td>21</td> <td>200</td> <td>0.2</td> <td rowspan="8">400V</td> <td>FR-ABR-H0.4K</td> <td>10%</td> <td>115</td> <td>500</td> <td>40</td> <td>21</td> <td>1200</td> <td>0.2</td> </tr> <tr> <td>FR-ABR-0.75K</td> <td>10%</td> <td>215</td> <td>500</td> <td>40</td> <td>21</td> <td>100</td> <td>0.4</td> <td>FR-ABR-H0.75K</td> <td>10%</td> <td>140</td> <td>500</td> <td>40</td> <td>21</td> <td>700</td> <td>0.2</td> </tr> <tr> <td>FR-ABR-2.2K*1</td> <td>10%</td> <td>240</td> <td>500</td> <td>50</td> <td>26</td> <td>60</td> <td>0.5</td> <td>FR-ABR-H1.5K</td> <td>10%</td> <td>215</td> <td>500</td> <td>40</td> <td>21</td> <td>350</td> <td>0.4</td> </tr> <tr> <td>FR-ABR-3.7K</td> <td>10%</td> <td>215</td> <td>500</td> <td>61</td> <td>33</td> <td>40</td> <td>0.8</td> <td>FR-ABR-H2.2K</td> <td>10%</td> <td>240</td> <td>500</td> <td>50</td> <td>26</td> <td>250</td> <td>0.5</td> </tr> <tr> <td>FR-ABR-5.5K</td> <td>10%</td> <td>335</td> <td>500</td> <td>61</td> <td>33</td> <td>25</td> <td>1.3</td> <td>FR-ABR-H3.7K</td> <td>10%</td> <td>215</td> <td>500</td> <td>61</td> <td>33</td> <td>150</td> <td>0.8</td> </tr> <tr> <td>FR-ABR-7.5K</td> <td>10%</td> <td>400</td> <td>500</td> <td>80</td> <td>40</td> <td>20</td> <td>2.2</td> <td>FR-ABR-H5.5K</td> <td>10%</td> <td>335</td> <td>500</td> <td>61</td> <td>33</td> <td>110</td> <td>1.3</td> </tr> <tr> <td>FR-ABR-11K</td> <td>6%</td> <td>400</td> <td>700</td> <td>100</td> <td>50</td> <td>13</td> <td>3.5</td> <td>FR-ABR-H7.5K</td> <td>10%</td> <td>400</td> <td>500</td> <td>80</td> <td>40</td> <td>75</td> <td>2.2</td> </tr> <tr> <td>FR-ABR-15K*2</td> <td>6%</td> <td>300</td> <td>700</td> <td>100</td> <td>50</td> <td>18 (×1/2)</td> <td>2.4 (×2)</td> <td>FR-ABR-H11K</td> <td>6%</td> <td>400</td> <td>700</td> <td>100</td> <td>50</td> <td>52</td> <td>3.2</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>FR-ABR-H15K*3</td> <td>6%</td> <td>300</td> <td>700</td> <td>100</td> <td>50</td> <td>18 (×2)</td> <td>2.4 (×2)</td> </tr> </tbody> </table> <p>*1 For the 1.5K and 2.2K inverter. *2 For the 15K brake resistor, configure so that two 18Ω resistors are connected in parallel. *3 For the 15K brake resistor, configure so that two 18Ω resistors are connected in series. FR-ABR-15K is indicated on the resistor. (same resistor as the 200V class 15K)</p>  <p>(Note) 1. The regenerative brake duty setting should be less than permissible brake duty in the table above. 2. The temperature of the brake resistor becomes 300°C or more depending on the operation frequency, care must be taken for installation and heat dissipation. 3. MYS type resistor can be also used. Note that the permissible brake duty. 4. The brake resistor can not be used with the 0.1K and 0.2K. 5. Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.</p>	Brake Resistor Type	Permissible Brake Duty	Outline Dimension				Resistance Value (Ω)	Approx. Mass (kg)	Brake Resistor Type	Permissible Brake Duty	Outline Dimension				Resistance Value (Ω)	Approx. Mass (kg)	W	W1	D	H	W	W1	D	H	200V	FR-ABR-0.4K	10%	140	500	40	21	200	0.2	400V	FR-ABR-H0.4K	10%	115	500	40	21	1200	0.2	FR-ABR-0.75K	10%	215	500	40	21	100	0.4	FR-ABR-H0.75K	10%	140	500	40	21	700	0.2	FR-ABR-2.2K*1	10%	240	500	50	26	60	0.5	FR-ABR-H1.5K	10%	215	500	40	21	350	0.4	FR-ABR-3.7K	10%	215	500	61	33	40	0.8	FR-ABR-H2.2K	10%	240	500	50	26	250	0.5	FR-ABR-5.5K	10%	335	500	61	33	25	1.3	FR-ABR-H3.7K	10%	215	500	61	33	150	0.8	FR-ABR-7.5K	10%	400	500	80	40	20	2.2	FR-ABR-H5.5K	10%	335	500	61	33	110	1.3	FR-ABR-11K	6%	400	700	100	50	13	3.5	FR-ABR-H7.5K	10%	400	500	80	40	75	2.2	FR-ABR-15K*2	6%	300	700	100	50	18 (×1/2)	2.4 (×2)	FR-ABR-H11K	6%	400	700	100	50	52	3.2									FR-ABR-H15K*3	6%	300	700	100	50	18 (×2)	2.4 (×2)
Brake Resistor Type	Permissible Brake Duty			Outline Dimension								Resistance Value (Ω)	Approx. Mass (kg)	Brake Resistor Type	Permissible Brake Duty			Outline Dimension				Resistance Value (Ω)	Approx. Mass (kg)																																																																																																																																																				
		W	W1	D	H	W	W1	D	H																																																																																																																																																																		
200V	FR-ABR-0.4K	10%	140	500	40	21	200	0.2	400V	FR-ABR-H0.4K	10%	115	500	40	21	1200	0.2																																																																																																																																																										
	FR-ABR-0.75K	10%	215	500	40	21	100	0.4		FR-ABR-H0.75K	10%	140	500	40	21	700	0.2																																																																																																																																																										
	FR-ABR-2.2K*1	10%	240	500	50	26	60	0.5		FR-ABR-H1.5K	10%	215	500	40	21	350	0.4																																																																																																																																																										
	FR-ABR-3.7K	10%	215	500	61	33	40	0.8		FR-ABR-H2.2K	10%	240	500	50	26	250	0.5																																																																																																																																																										
	FR-ABR-5.5K	10%	335	500	61	33	25	1.3		FR-ABR-H3.7K	10%	215	500	61	33	150	0.8																																																																																																																																																										
	FR-ABR-7.5K	10%	400	500	80	40	20	2.2		FR-ABR-H5.5K	10%	335	500	61	33	110	1.3																																																																																																																																																										
	FR-ABR-11K	6%	400	700	100	50	13	3.5		FR-ABR-H7.5K	10%	400	500	80	40	75	2.2																																																																																																																																																										
	FR-ABR-15K*2	6%	300	700	100	50	18 (×1/2)	2.4 (×2)		FR-ABR-H11K	6%	400	700	100	50	52	3.2																																																																																																																																																										
								FR-ABR-H15K*3	6%	300	700	100	50	18 (×2)	2.4 (×2)																																																																																																																																																												

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

**Name (type)** **Specifications, Structure, etc.**

**Brake unit**  
FR-BU2-(H)□□K

**Resistor unit**  
FR-BR-(H)□□K

**Discharging resistor**  
GZG type  
GRZG type



● A brake unit is an option that fully enhances the regenerative braking capability of the inverter, and should be used with an electrical-discharge resistor. Select from three discharging resistor according to the required braking torque.

● **Specification**  
<Brake Unit>

Type FR-BU2-□	200V					400V		
	1.5K	3.7K	7.5K	15K	30K	H7.5K	H15K	H30K
Applicable motor capacity	Capacity of the motor to be used with differs according to the braking torque and duty (%ED)							
Connected brake resistor	GRZG type, FR-BR, MT-BR5 (refer to the table below for combinations)							
Multiple (parallel) operation	Up to 10 units (note that torque generated is not more than the tolerable overcurrent amount of connected inverter)							
Approximate mass (kg)	0.9	0.9	0.9	0.9	1.4	0.9	0.9	1.4

<Resistor unit>

Type GRZG	200V				400V	
	GZG300W-50Ω	GRZG200-10Ω	GRZG300-5Ω	GRZG400-2Ω	GRZG200-10Ω	GRZG300-5Ω
Number of connectable devices	One	Three in series	Four in series	Six in series	Six in series	8 in series
Brake resistor total resistance value (Ω)	50	30	20	12	60	40
Continuous permissible power (W)	100	300	600	1200	600	1200

Type FR-BR-□	200V	400V
	15K	H15K
Brake resistor total resistance value (Ω)	8	32
Continuous permissible power (W)	990	990
Approximate mass (kg)	15	15

● **Combinations of brake unit and resistor unit**

Brake Unit	Discharging Resistor/Resistor Unit Type	
	GRZG type	FR-BR
200V class	FR-BU2-1.5K	GZG 300W-50Ω (1)
	FR-BU2-3.7K	GRZG 200-10Ω (3 in series)
	FR-BU2-7.5K	GRZG 300-5Ω (4 in series)
	FR-BU2-15K	GRZG 400-2Ω (6 in series)
	FR-BU2-30K	FR-BR-15K
400V class	FR-BU2-H7.5K	FR-BR-30K
	FR-BU2-H15K	GRZG 200-10Ω (6 in series)
	FR-BU2-H30K	GRZG 300-5Ω (8 in series)
	FR-BU2-H30K	FR-BR-H15K
FR-BU2-H30K	FR-BR-H30K	

● **Selection**

<When GRZG type is connected>

• The maximum temperature rise of the discharging resistors is approximately 100°C. Use heat-resistant wires and wire to avoid contact with resistors.

Power Supply Voltage	Motor (kW)	Braking torque									
		0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	
200V class	50% 30s	FR-BU2-1.5K		FR-BU2-3.7K		FR-BU2-7.5K		FR-BU2-15K			
	100% 30s	FR-BU2-1.5K	FR-BU2-3.7K	FR-BU2-7.5K		FR-BU2-15K		2 × FR-BU2-15K*1			
400V class	50% 30s	—*1		FR-BU2-H7.5K				FR-BU2-H15K			
	100% 30s	—*2		FR-BU2-H7.5K		FR-BU2-H15K		FR-BU2-H30K			

\*1 The number before the model name explains the number of connectable units in parallel.  
\*2 The inverter for 400V class 1.5K or less can not be used in combination with a brake unit. To use in combination with a brake unit, use the inverter of 2.2K or more.

<When FR-BR is connected>

• The temperature rise of the resistor unit is about a maximum of 100°C. Therefore, use heat-resistant wires (such as glass wires).



%ED at short-time rating when braking torque is 100%





Motor Capacity			5.5kW	7.5kW	11kW	15kW
200V class	FR-BU2-15K	%ED	80	40	15	10
	FR-BU2-30K	%ED	—	—	65	30
400V class	FR-BU2-H15K	%ED	80	40	15	10
	FR-BU2-H30K	%ED	—	—	65	30

Braking torque (%) at short-time rating when 10%ED is 15s





Motor Capacity			5.5kW	7.5kW	11kW	15kW
200V class	FR-BU2-15K	Injection brake torque (%)	280	200	120	100
	FR-BU2-30K	Injection brake torque (%)	—	—	260	180
400V class	FR-BU2-H15K	Injection brake torque (%)	280	200	120	100
	FR-BU2-H30K	Injection brake torque (%)	—	—	260	180





$$\text{Regeneration duty factor (operation frequency)\%ED} = \frac{t_b}{t_c} \times 100 \quad t_b < 15s \text{ (continuous operation time)}$$



Name (type)	Specifications, Structure, etc.																																																												
<p><b>Brake unit</b> FR-BU2-(H)□□K</p> <p><b>Resistor unit</b> FR-BR-(H)□□K</p> <p><b>Discharging resistor</b> GZG type GRZG type</p> 	<p><b>● Connection diagram</b></p>  <p>*1 A jumper is connected across BUE and SD in the initial status.</p> <p>*2 Connect the inverter terminals (P/+, N/-) and brake unit (FR-BU2) terminals so that their terminal symbols match with each other. Incorrect connection will damage the inverter. Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.</p> <p><b>When connecting several brake units</b></p> <p><b>● Outline dimension drawings</b></p> <p><b>&lt;FR-BU2&gt;</b></p>  <table border="1" data-bbox="901 952 1348 1108"> <thead> <tr> <th>Model</th> <th>W</th> <th>H</th> <th>D</th> </tr> </thead> <tbody> <tr> <td>FR-BU2-1.5K to 15K</td> <td>68</td> <td>128</td> <td>132.5</td> </tr> <tr> <td>FR-BU2-30K</td> <td>108</td> <td>128</td> <td>129.5</td> </tr> <tr> <td>FR-BU2-H7.5K, H15K</td> <td>68</td> <td>128</td> <td>132.5</td> </tr> <tr> <td>FR-BU2-H30K</td> <td>108</td> <td>128</td> <td>129.5</td> </tr> </tbody> </table> <p>(Unit: mm)</p> <p><b>&lt;GZG,GRZG&gt;</b></p>  <table border="1" data-bbox="925 1288 1364 1411"> <thead> <tr> <th>Type</th> <th>W</th> <th>D</th> <th>H</th> </tr> </thead> <tbody> <tr> <td>GZG300W</td> <td>335</td> <td>40</td> <td>78</td> </tr> <tr> <td>GRZG200</td> <td>306</td> <td>26</td> <td>55</td> </tr> <tr> <td>GRZG300</td> <td>334</td> <td>40</td> <td>79</td> </tr> <tr> <td>GRZG400</td> <td>411</td> <td>40</td> <td>79</td> </tr> </tbody> </table> <p>(Unit: mm)</p> <p><b>&lt;FR-BR&gt;</b></p>  <table border="1" data-bbox="917 1556 1356 1668"> <thead> <tr> <th>Model</th> <th>W</th> <th>H</th> <th>D</th> </tr> </thead> <tbody> <tr> <td>FR-BR-15K</td> <td>170</td> <td>450</td> <td>220</td> </tr> <tr> <td>FR-BR-30K</td> <td>340</td> <td>600</td> <td>220</td> </tr> <tr> <td>FR-BR-H15K</td> <td>170</td> <td>450</td> <td>220</td> </tr> <tr> <td>FR-BR-H30K</td> <td>340</td> <td>600</td> <td>220</td> </tr> </tbody> </table> <p>(Unit: mm)</p>	Model	W	H	D	FR-BU2-1.5K to 15K	68	128	132.5	FR-BU2-30K	108	128	129.5	FR-BU2-H7.5K, H15K	68	128	132.5	FR-BU2-H30K	108	128	129.5	Type	W	D	H	GZG300W	335	40	78	GRZG200	306	26	55	GRZG300	334	40	79	GRZG400	411	40	79	Model	W	H	D	FR-BR-15K	170	450	220	FR-BR-30K	340	600	220	FR-BR-H15K	170	450	220	FR-BR-H30K	340	600	220
Model	W	H	D																																																										
FR-BU2-1.5K to 15K	68	128	132.5																																																										
FR-BU2-30K	108	128	129.5																																																										
FR-BU2-H7.5K, H15K	68	128	132.5																																																										
FR-BU2-H30K	108	128	129.5																																																										
Type	W	D	H																																																										
GZG300W	335	40	78																																																										
GRZG200	306	26	55																																																										
GRZG300	334	40	79																																																										
GRZG400	411	40	79																																																										
Model	W	H	D																																																										
FR-BR-15K	170	450	220																																																										
FR-BR-30K	340	600	220																																																										
FR-BR-H15K	170	450	220																																																										
FR-BR-H30K	340	600	220																																																										

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

Name (type)	Specifications, Structure, etc.																																																																																																																																																																																															
<p><b>Power regeneration common converter FR-CV-(H)□□K</b></p> 	<ul style="list-style-type: none"> <li>Enables 100%-torque continuous regeneration to support continuous regenerative operation for line control, etc. (Maximum torque 150% 60s)</li> <li>Eliminates the need to use a brake unit with each inverter, reducing total space and total cost.</li> <li>Saves energy since regeneration energy is used for the other inverters and excess energy is returned to the power supply.</li> <li>Heatsink protrusion type has the heat generating section outside of the enclosure, and exhaust the converter generated heat to the outside of enclosure.</li> </ul> <p><b>● Connection diagram</b></p>  <p>*1 Always keep the power input terminals R/L1, S/L2, T/L3 open. Incorrect connection will damage the inverter. Opposite polarity of terminals N/-, P/+ will damage the inverter.</p> <p>*2 Do not insert an MCCB between the terminals P/+-N/- (between P/L+-P/+, between N/L--N/-). Connect the inverter terminals (P/+, N/-) and power regeneration common converter terminals so that their terminal symbols match with each other. Incorrect connection will damage the inverter. Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.</p> <p>*3 Assign the terminal for X10 signal using any of Pr: 178 to Pr: 184 (input terminal function selection).</p> <p>*4 Always connect the power supply and terminals R/L11, S/L21, T/MC1. If the inverter is operated without connection, the power regeneration common converter will be damaged.</p> <p>*5 Install the dedicated stand-alone reactor (FR-CVL) on horizontal plane.</p> <p><b>● Outline dimension drawings</b></p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>&lt;FR-CV-(H)&gt;</p> </div> <div style="text-align: center;">  <p>&lt;FR-CV-(H)-AT&gt;</p> </div> <div style="text-align: center;">  <p>&lt;FR-CVL&gt;</p> </div> </div> <table border="1" style="width:100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th colspan="10">FR-CV-(H) (Unit mm)</th> </tr> <tr> <th rowspan="2">Voltage/Capacity</th> <th rowspan="2">W</th> <th rowspan="2">H</th> <th rowspan="2">D</th> <th rowspan="2">D1</th> <th colspan="5">400V</th> </tr> <tr> <th>7.5K/11K/15K</th> <th>W</th> <th>H</th> <th>D</th> <th>D1</th> </tr> </thead> <tbody> <tr> <td>200V</td> <td>7.5K/11K</td> <td>90</td> <td>300</td> <td>303</td> <td>103</td> <td>120</td> <td>300</td> <td>305</td> <td>105</td> </tr> <tr> <td></td> <td>15K</td> <td>120</td> <td>300</td> <td>305</td> <td>105</td> <td>150</td> <td>380</td> <td>305</td> <td>105</td> </tr> <tr> <td></td> <td>22K/30K</td> <td>150</td> <td>380</td> <td>322</td> <td>122</td> <td>150</td> <td>380</td> <td>305</td> <td>105</td> </tr> <tr> <td></td> <td>37K/55K</td> <td>400</td> <td>620</td> <td>250</td> <td>135</td> <td>400</td> <td>620</td> <td>250</td> <td>135</td> </tr> </tbody> </table> <table border="1" style="width:100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th colspan="10">FR-CV-(H)-AT (Unit mm)</th> </tr> <tr> <th rowspan="2">Voltage/Capacity</th> <th rowspan="2">W</th> <th rowspan="2">H</th> <th rowspan="2">D</th> <th rowspan="2">D1</th> <th colspan="5">400V</th> </tr> <tr> <th>7.5K/11K/15K</th> <th>W</th> <th>H</th> <th>D</th> <th>D1</th> </tr> </thead> <tbody> <tr> <td>200V</td> <td>7.5K/11K</td> <td>110</td> <td>330</td> <td>315</td> <td>115</td> <td>130</td> <td>330</td> <td>320</td> <td>120</td> </tr> <tr> <td></td> <td>15K</td> <td>130</td> <td>330</td> <td>320</td> <td>120</td> <td>160</td> <td>410</td> <td>350</td> <td>150</td> </tr> <tr> <td></td> <td>22K/30K</td> <td>160</td> <td>410</td> <td>350</td> <td>150</td> <td>160</td> <td>410</td> <td>350</td> <td>150</td> </tr> </tbody> </table> <table border="1" style="width:100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th colspan="8">FR-CVL (Unit mm)</th> </tr> <tr> <th rowspan="2">Voltage/Capacity</th> <th rowspan="2">W</th> <th rowspan="2">H</th> <th rowspan="2">D</th> <th colspan="4">400V</th> </tr> <tr> <th>7.5K/11K</th> <th>W</th> <th>H</th> <th>D</th> </tr> </thead> <tbody> <tr> <td rowspan="6">200V</td> <td>7.5K/11K/15K</td> <td>165</td> <td>130</td> <td>155</td> <td>220</td> <td>135</td> <td>200</td> </tr> <tr> <td>22K</td> <td>165</td> <td>140</td> <td>155</td> <td>220</td> <td>135</td> <td>205</td> </tr> <tr> <td>30K</td> <td>215</td> <td>160</td> <td>175</td> <td>220</td> <td>150</td> <td>215</td> </tr> <tr> <td>37K</td> <td>220</td> <td>320</td> <td>200</td> <td>245</td> <td>185</td> <td>220</td> </tr> <tr> <td>37K</td> <td>220</td> <td>320</td> <td>200</td> <td>245</td> <td>185</td> <td>220</td> </tr> <tr> <td>55K</td> <td>250</td> <td>335</td> <td>225</td> <td>245</td> <td>230</td> <td>265</td> </tr> <tr> <td></td> <td>55K</td> <td>290</td> <td>230</td> <td>280</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	FR-CV-(H) (Unit mm)										Voltage/Capacity	W	H	D	D1	400V					7.5K/11K/15K	W	H	D	D1	200V	7.5K/11K	90	300	303	103	120	300	305	105		15K	120	300	305	105	150	380	305	105		22K/30K	150	380	322	122	150	380	305	105		37K/55K	400	620	250	135	400	620	250	135	FR-CV-(H)-AT (Unit mm)										Voltage/Capacity	W	H	D	D1	400V					7.5K/11K/15K	W	H	D	D1	200V	7.5K/11K	110	330	315	115	130	330	320	120		15K	130	330	320	120	160	410	350	150		22K/30K	160	410	350	150	160	410	350	150	FR-CVL (Unit mm)								Voltage/Capacity	W	H	D	400V				7.5K/11K	W	H	D	200V	7.5K/11K/15K	165	130	155	220	135	200	22K	165	140	155	220	135	205	30K	215	160	175	220	150	215	37K	220	320	200	245	185	220	37K	220	320	200	245	185	220	55K	250	335	225	245	230	265		55K	290	230	280			
FR-CV-(H) (Unit mm)																																																																																																																																																																																																
Voltage/Capacity	W	H	D	D1	400V																																																																																																																																																																																											
					7.5K/11K/15K	W	H	D	D1																																																																																																																																																																																							
200V	7.5K/11K	90	300	303	103	120	300	305	105																																																																																																																																																																																							
	15K	120	300	305	105	150	380	305	105																																																																																																																																																																																							
	22K/30K	150	380	322	122	150	380	305	105																																																																																																																																																																																							
	37K/55K	400	620	250	135	400	620	250	135																																																																																																																																																																																							
FR-CV-(H)-AT (Unit mm)																																																																																																																																																																																																
Voltage/Capacity	W	H	D	D1	400V																																																																																																																																																																																											
					7.5K/11K/15K	W	H	D	D1																																																																																																																																																																																							
200V	7.5K/11K	110	330	315	115	130	330	320	120																																																																																																																																																																																							
	15K	130	330	320	120	160	410	350	150																																																																																																																																																																																							
	22K/30K	160	410	350	150	160	410	350	150																																																																																																																																																																																							
FR-CVL (Unit mm)																																																																																																																																																																																																
Voltage/Capacity	W	H	D	400V																																																																																																																																																																																												
				7.5K/11K	W	H	D																																																																																																																																																																																									
200V	7.5K/11K/15K	165	130	155	220	135	200																																																																																																																																																																																									
	22K	165	140	155	220	135	205																																																																																																																																																																																									
	30K	215	160	175	220	150	215																																																																																																																																																																																									
	37K	220	320	200	245	185	220																																																																																																																																																																																									
	37K	220	320	200	245	185	220																																																																																																																																																																																									
	55K	250	335	225	245	230	265																																																																																																																																																																																									
	55K	290	230	280																																																																																																																																																																																												


Name (type)	Specifications, Structure, etc.																																																																																																																																																																													
<p><b>High power factor converter</b> FR-HC- (H)□□K</p> 	<ul style="list-style-type: none"> <li>Substantially suppresses power harmonics to realize the equivalent capacity conversion coefficient <math>K5=0</math> in the "Harmonic suppression guideline for consumers who receive high voltage or special high voltage".</li> <li>Has the power regeneration function as standard.</li> <li>Connects multiple inverters to enable common converter system operation.</li> </ul> <p><b>Specifications</b></p> <table border="1"> <thead> <tr> <th rowspan="2">Type FR-HC□□</th> <th colspan="4">200V</th> <th colspan="4">400V</th> </tr> <tr> <th>7.5K</th> <th>15K</th> <th>30K</th> <th>55K</th> <th>H7.5K</th> <th>H15K</th> <th>H30K</th> <th>H55K</th> </tr> </thead> <tbody> <tr> <td>Applicable inverter capacity (*1)</td> <td>3.7K to 7.5K</td> <td>7.5K to 15K</td> <td>15K to 30K</td> <td>30K to 55K</td> <td>3.7K to 7.5K</td> <td>7.5K to 15K</td> <td>15 to 30K</td> <td>30K to 55K</td> </tr> <tr> <td>Rated input voltage/frequency</td> <td colspan="4">Three-phase 200V to 220V 50Hz 200V to 230V 60Hz</td> <td colspan="4">Three-phase 380V to 460V 50/60Hz</td> </tr> <tr> <td>Rated input current (A)</td> <td>33</td> <td>61</td> <td>115</td> <td>215</td> <td>17</td> <td>31</td> <td>57</td> <td>110</td> </tr> <tr> <td>Rated output voltage (V) (*2)</td> <td colspan="4">293V to 335VDC</td> <td colspan="4">558V to 670VDC</td> </tr> </tbody> </table> <p>*1 The applicable capacity to the high power factor converter is the total capacity of the inverters. *2 The output voltage varies with the input voltage value. *3 Reactor 1 FR-HCL01, Reactor 2 FR-HCL02 and Outside box FR-HCB are supplied with an order of the high power factor converter (FR-HC)</p> <p><b>Outline dimension</b> (Unit: mm)</p> <table border="1"> <thead> <tr> <th rowspan="2">Voltage</th> <th rowspan="2">Capacity</th> <th colspan="3">High Power Factor Converter FR-HC</th> <th colspan="3">Reactor 1 FR-HCL01</th> <th colspan="3">Reactor 2 FR-HCL02</th> <th colspan="3">Outside Box FR-HCB</th> </tr> <tr> <th>W</th> <th>H</th> <th>D</th> <th>W</th> <th>H</th> <th>D</th> <th>W</th> <th>H</th> <th>D</th> <th>W</th> <th>H</th> <th>D</th> </tr> </thead> <tbody> <tr> <td rowspan="4">200V</td> <td>7.5K</td> <td>220</td> <td>300</td> <td>190</td> <td>160</td> <td>155</td> <td>100</td> <td>240</td> <td>230</td> <td>160</td> <td rowspan="2">190</td> <td rowspan="2">320</td> <td rowspan="2">165</td> </tr> <tr> <td>15K</td> <td>250</td> <td>400</td> <td>190</td> <td>190</td> <td>205</td> <td>130</td> <td>260</td> <td>270</td> <td>170</td> </tr> <tr> <td>30K</td> <td>340</td> <td>550</td> <td>195</td> <td>220</td> <td>230</td> <td>170</td> <td>340</td> <td>320</td> <td>180</td> <td rowspan="2">270</td> <td rowspan="2">450</td> <td rowspan="2">203</td> </tr> <tr> <td>55K</td> <td>480</td> <td>700</td> <td>250</td> <td>210</td> <td>260</td> <td>225</td> <td>430</td> <td>470</td> <td>360</td> </tr> <tr> <td rowspan="4">400V</td> <td>H7.5K</td> <td>220</td> <td>300</td> <td>190</td> <td>160</td> <td>150</td> <td>100</td> <td>240</td> <td>220</td> <td>160</td> <td rowspan="2">190</td> <td rowspan="2">320</td> <td rowspan="2">165</td> </tr> <tr> <td>H15K</td> <td>250</td> <td>400</td> <td>190</td> <td>190</td> <td>195</td> <td>130</td> <td>260</td> <td>260</td> <td>170</td> </tr> <tr> <td>H30K</td> <td>340</td> <td>550</td> <td>195</td> <td>220</td> <td>215</td> <td>140</td> <td>340</td> <td>310</td> <td>180</td> <td rowspan="2">270</td> <td rowspan="2">450</td> <td rowspan="2">203</td> </tr> <tr> <td>H55K</td> <td>480</td> <td>700</td> <td>250</td> <td>280</td> <td>255</td> <td>190</td> <td>400</td> <td>380</td> <td>285</td> </tr> </tbody> </table>  <p>* Install the reactor (FR-HCL01, 02) on horizontal plane.</p>	Type FR-HC□□	200V				400V				7.5K	15K	30K	55K	H7.5K	H15K	H30K	H55K	Applicable inverter capacity (*1)	3.7K to 7.5K	7.5K to 15K	15K to 30K	30K to 55K	3.7K to 7.5K	7.5K to 15K	15 to 30K	30K to 55K	Rated input voltage/frequency	Three-phase 200V to 220V 50Hz 200V to 230V 60Hz				Three-phase 380V to 460V 50/60Hz				Rated input current (A)	33	61	115	215	17	31	57	110	Rated output voltage (V) (*2)	293V to 335VDC				558V to 670VDC				Voltage	Capacity	High Power Factor Converter FR-HC			Reactor 1 FR-HCL01			Reactor 2 FR-HCL02			Outside Box FR-HCB			W	H	D	W	H	D	W	H	D	W	H	D	200V	7.5K	220	300	190	160	155	100	240	230	160	190	320	165	15K	250	400	190	190	205	130	260	270	170	30K	340	550	195	220	230	170	340	320	180	270	450	203	55K	480	700	250	210	260	225	430	470	360	400V	H7.5K	220	300	190	160	150	100	240	220	160	190	320	165	H15K	250	400	190	190	195	130	260	260	170	H30K	340	550	195	220	215	140	340	310	180	270	450	203	H55K	480	700	250	280	255	190	400	380	285
Type FR-HC□□	200V				400V																																																																																																																																																																									
	7.5K	15K	30K	55K	H7.5K	H15K	H30K	H55K																																																																																																																																																																						
Applicable inverter capacity (*1)	3.7K to 7.5K	7.5K to 15K	15K to 30K	30K to 55K	3.7K to 7.5K	7.5K to 15K	15 to 30K	30K to 55K																																																																																																																																																																						
Rated input voltage/frequency	Three-phase 200V to 220V 50Hz 200V to 230V 60Hz				Three-phase 380V to 460V 50/60Hz																																																																																																																																																																									
Rated input current (A)	33	61	115	215	17	31	57	110																																																																																																																																																																						
Rated output voltage (V) (*2)	293V to 335VDC				558V to 670VDC																																																																																																																																																																									
Voltage	Capacity	High Power Factor Converter FR-HC			Reactor 1 FR-HCL01			Reactor 2 FR-HCL02			Outside Box FR-HCB																																																																																																																																																																			
		W	H	D	W	H	D	W	H	D	W	H	D																																																																																																																																																																	
200V	7.5K	220	300	190	160	155	100	240	230	160	190	320	165																																																																																																																																																																	
	15K	250	400	190	190	205	130	260	270	170																																																																																																																																																																				
	30K	340	550	195	220	230	170	340	320	180	270	450	203																																																																																																																																																																	
	55K	480	700	250	210	260	225	430	470	360																																																																																																																																																																				
400V	H7.5K	220	300	190	160	150	100	240	220	160	190	320	165																																																																																																																																																																	
	H15K	250	400	190	190	195	130	260	260	170																																																																																																																																																																				
	H30K	340	550	195	220	215	140	340	310	180	270	450	203																																																																																																																																																																	
	H55K	480	700	250	280	255	190	400	380	285																																																																																																																																																																				
<p><b>DIN rail mounting attachments</b> FR-UDA□□</p>	<ul style="list-style-type: none"> <li>Attachment to enable installation of FR-E700 series on DIN rail.</li> </ul> <p><b>Selection table</b></p> <table border="1"> <thead> <tr> <th rowspan="2">Model</th> <th colspan="3">Inverter Capacity (kW)</th> </tr> <tr> <th>FR-UDA01</th> <th>FR-UDA02</th> <th>FR-UDA03</th> </tr> </thead> <tbody> <tr> <td>FR-E720</td> <td>0.1K, 0.2K, 0.4K, 0.75K</td> <td>1.5K, 2.2K</td> <td>3.7K</td> </tr> </tbody> </table> <p><b>Approximate dimension</b></p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>&lt;FR-UDA01&gt;</p>  </div> <div style="text-align: center;"> <p>&lt;FR-UDA02&gt;</p>  </div> <div style="text-align: center;"> <p>&lt;FR-UDA03&gt;</p>  </div> </div> <p>(Unit: mm)</p>	Model	Inverter Capacity (kW)			FR-UDA01	FR-UDA02	FR-UDA03	FR-E720	0.1K, 0.2K, 0.4K, 0.75K	1.5K, 2.2K	3.7K																																																																																																																																																																		
Model	Inverter Capacity (kW)																																																																																																																																																																													
	FR-UDA01	FR-UDA02	FR-UDA03																																																																																																																																																																											
FR-E720	0.1K, 0.2K, 0.4K, 0.75K	1.5K, 2.2K	3.7K																																																																																																																																																																											

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

Peripheral devices/cable size list

Inverter type	Motor Output (kW)	Moulded Case Circuit Breaker (MCCB)*1 or Earth Leakage Current Breaker (ELB)*4		Magnetic Contactor (MC)	HIV Cables, etc. (mm <sup>2</sup> )		Reactor		
		Standard	With power factor improving reactor		R/L1, S/L2, T/L3	U, V, W	FR-HAL	FR-HEL	
Three-phase 200V	FR-E720-0.1K	0.1	30AF 5A	30AF 5A	S-N10	2	2	0.4K	0.4K
	FR-E720-0.2K	0.2	30AF 5A	30AF 5A	S-N10	2	2	0.4K	0.4K
	FR-E720-0.4K	0.4	30AF 5A	30AF 5A	S-N10	2	2	0.4K	0.4K
	FR-E720-0.75K	0.75	30AF 10A	30AF 10A	S-N10	2	2	0.75K	0.75K
	FR-E720-1.5K	1.5	30AF 15A	30AF 15A	S-N10	2	2	1.5K	1.5K
	FR-E720-2.2K	2.2	30AF 20A	30AF 15A	S-N10	2	2	2.2K	2.2K
	FR-E720-3.7K	3.7	30AF 30A	30AF 30A	S-N20, S-N21	3.5	3.5	3.7K	3.7K
	FR-E720-5.5K	5.5	50AF 50A	50AF 40A	S-N25	5.5	5.5	5.5K	5.5K
	FR-E720-7.5K	7.5	100AF 60A	50AF 50A	S-N35	14	8	7.5K	7.5K
	FR-E720-11K	11	100AF 75A	100AF 75A	S-N35	14	14	11K	11K
	FR-E720-15K	15	225AF 125A	100AF 100A	S-N50	22	22	15K	15K

\*1 Select the MCCB according to the inverter power supply capacity.  
Install one MCCB per inverter.




- \*2 When the inverter capacity is larger than the motor capacity, select a brake and a magnetic contactor according to the inverter type and cable and reactor according to the motor output.
- \*3 When the breaker on the inverter primary side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.
- \*4 For installations in the United States or Canada, use the class T type fuse certified by the UL and cUL.

## Selecting the rated sensitivity current for the earth leakage current breaker


When using the earth leakage current breaker with the inverter circuit, select its rated sensitivity current as follows, independently of the PWM carrier frequency.

- Breaker designed for harmonic and surge suppression  
 Rated sensitivity current  $I_{\Delta n} \geq 10 \times (I_{g1} + I_{gn} + I_{gi} + I_{g2} + I_{gm})$
  - Standard breaker  
 Rated sensitivity current  $I_{\Delta n} \geq 10 \times (I_{g1} + I_{gn} + I_{gi} + 3 \times (I_{g2} + I_{gm}))$
- $I_{g1}, I_{g2}$ : Leakage currents in wire path during commercial power supply operation  
 $I_{gn}$  : Leakage current of inverter input side noise filter  
 $I_{gm}$  : Leakage current of motor during commercial power supply operation  
 $I_{gi}$  : Leakage current of inverter unit


Example of leakage current of cable path per 1km during the commercial power supply operation when the CV cable is routed in metal conduit (200V 60Hz)



Leakage current example of three-phase induction motor during the commercial power supply operation (200V 60Hz)



example



- (Note) 1 Install the earth leakage breaker (ELB) on the input side of the inverter.  
 2 In the  $\Delta$  connection earthed-neutral system, the sensitivity current is blunt against an earth (ground) fault in the inverter output side. Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)

### ● Selection example (in the case of the above figure)

	Breaker Designed for Harmonic and Surge Suppression	Standard Breaker
Leakage current $I_{g1}$ (mA)	$33 \times \frac{5m}{1,000m} = 0.17$	
Leakage current $I_{gn}$ (mA)	0 (without noise filter)	
Leakage current $I_{gi}$ (mA)	1	
Leakage current $I_{g2}$ (mA)	$33 \times \frac{50m}{1,000m} = 1.65$	
Motor leakage current $I_{gm}$ (mA)	0.18	
Total leakage current (mA)	3.00	6.66
Rated sensitivity current (mA) ( $\geq I_{g} \times 10$ )	30	100

Features

Peripheral Devices

Standard Specifications

Outline Dimension Drawings

Terminal Connection Diagram, Terminal Specification Explanation

Operation panel Parameter unit FR Configurator

Parameter List

Explanations of Parameters

Protective Functions

Options

Instructions

Motor

Compatibility

Warranty

Inquiry

## Precautions for Operation/Selection

### Precautions for use of the inverter

#### ⚠ Safety Precautions

- To operate the inverter correctly and safely, be sure to read the "instruction manual" before starting operation.
- This product has not been designed or manufactured for use with any equipment or system operated under life-threatening conditions.
- Please contact our sales office when you are considering using this product in special applications such as passenger mobile, medical, aerospace, nuclear, power or undersea relay equipment or system.
- Although this product is manufactured under strict quality control, safety devices should be installed when a serious accident or loss is expected by a failure of this product.
- The load used should be a three-phase induction motor only.

### Operation


- A magnetic contactor (MC) provided on the input side should not be used to make frequent starts and stops. It could cause the inverter to fail.
- However, at this time, the motor cannot be brought to a sudden stop. Hence, provide a mechanical stopping/holding mechanism for the machine/equipment which requires an emergency stop.
- It will take time for the capacitor to discharge after shutoff of the inverter power supply. When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched off, and check to make sure that there are no residual voltage using a tester or the like.

### Wiring

- Application of power to the output terminals (U, V, W) of the inverter will damage the inverter. Therefore, fully check the wiring and sequence to ensure that wiring is correct, etc. before powering on.
- The terminals P/+, PR, P1, N/- are provided for connection of a dedicated option. Connect only a dedicated option. Do not short the frequency setting power supply terminal 10 and common terminal 5 or the terminal PC and terminal SD.

### Power supply

- When the inverter is connected under a large-capacity power transformer (500kVA or more transformer) or when a power capacitor is to be switched over, an excessive peak current may flow in the power input circuit, damaging the inverter.



- To prevent this, always install an optional AC reactor (FR-HEL).
- If a surge voltage occurs in the power supply system, this surge energy may flow into the inverter, causing the inverter to display overvoltage protection (E.OV□) and come to an inverter trip. To prevent this, always install an optional AC reactor (FR-HAL).

### Installation

- Avoid hostile environment where oil mist, fluff, dust particles, etc. are suspended in the air, and install the inverter in a clean place or put it in an ingress-protected "enclosed" enclosure. When placing the inverter in an enclosure, determine the cooling system and panel dimensions so that the ambient temperature of the inverter is within the permissible value. (refer to page 8 for the specified value)
- Do not install the inverter on wood or other combustible material as it will be hot partly.
- Install the inverter in the vertical orientation.

### Setting

- The inverter can be operated as fast as a maximum of 400Hz by parameter setting. Therefore, incorrect setting can cause a danger. Set the upper limit using the maximum frequency limit setting function.
- A setting higher than the initial value of DC injection brake operation voltage or operation time can cause motor overheat (electronic thermal relay error).
- Do not set Pr. 70 Special regenerative brake duty except for using the optional brake resistor. This function is used to protect the brake resistor from overheating. Do not set the value exceeding permissible duty of the brake resistor.

## Precautions for selection

### Inverter capacity selection

- When operating a special motor or more than one motor in parallel with a single inverter, select the inverter capacity so that 1.1 times the total rated motor current is less than the rated output current of the inverter.
- Setting 2kHz or more in *Pr. 72 PWM frequency selection* to perform low acoustic noise operation with the ambient temperature exceeding 40°C (totally-enclosed structure is 30°C), decrease the output current according to the rating table on *page 7*. (Also change the *Pr. 9 Electronic thermal O/L relay* setting.)

### Starting torque of the motor

- The start and acceleration characteristics of the motor driven by the inverter are restricted by the overload current rating of that inverter. Generally the torque characteristic is less than when the motor is started by a commercial power supply. If torque boost adjustment, advanced magnetic flux vector control, or general-purpose magnetic flux vector control cannot provide enough torque when a large starting torque is necessary, select the inverter of one rank higher capacity or increase the capacities of both the motor and inverter.

### Acceleration/deceleration times

- The acceleration/deceleration time of the motor depends on the motor-generated torque, load torque and moment of inertia of the load (J).
- When the torque limit function or stall prevention function is activated during acceleration/deceleration, increase the acceleration/deceleration time as the actual time may become longer.
- To decrease the acceleration/deceleration time, increase the torque boost value (setting of a too large value may activate the stall prevention function at a start, longer the acceleration time), use the advanced magnetic flux vector control or general-purpose magnetic flux vector control or increase the inverter and motor capacities. To decrease the deceleration time, it is necessary to add optional brake resistor MRS or FR-ABR (for the 0.4K or more), the brake unit (FR-BU2), power regeneration common converter (FR-CV), or a similar device to absorb braking energy.

### Power transfer mechanism (reduction gear, belt, chain, etc.)

- When an oil-lubricated gear box, speed change/reduction gear or similar device is used in the power transfer system, note that continuous operation at low speed only may deteriorate oil lubrication, causing seizure. When performing fast operation at higher than 60Hz, fully note that such operation will cause strength shortage due to the noise, life or centrifugal force of the power transfer mechanism.

### Instructions for overload operation

- When performing operation of frequent start/stop of the inverter, rise/fall in the temperature of the transistor element of the inverter will repeat due to a repeated flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing current at locked condition, starting current, etc. Decreasing current may increase the life. However, decreasing current will result in insufficient torque and the inverter may not start. Therefore, choose the inverter which has enough allowance for current.

Features

Peripheral Devices

Standard Specifications

Outline Dimension Drawings

Terminal Connection Diagram Terminal Specification Explanation

Operation panel Parameter unit FR Configurator

Parameter List

Explanations of Parameters

Protective Functions

Options

Instructions

Motor

Compatibility

Warranty

Inquiry

# Precautions for Peripheral Device Selection

## Installation and selection of moulded case circuit breaker

Install a moulded case circuit breaker (MCCB) on the power receiving side to protect the wiring of the inverter input side. For MCCB selection, refer to *page 57* since it depends on the inverter power supply side power factor (which changes depending on the power supply voltage, output frequency and load). Especially for a completely electromagnetic MCCB, one of a slightly large capacity must be selected since its operation characteristic varies with harmonic currents. (Check it in the data of the corresponding breaker.) As an earth leakage current breaker, use the Mitsubishi earth leakage current breaker designed for harmonics and surge suppression. (Refer to *page 58*)

When installing a moulded case circuit breaker on the output side of the inverter, contact each manufacturer for selection of the moulded case circuit breaker.

## Handling of the inverter input side magnetic contactor

- For operation via external terminal (terminal STF or STR used), provide a input side MC to prevent an accident caused by a natural restart at power recovery after a power failure, such as an instantaneous power failure, and to ensure safety for maintenance work. Do not use this magnetic contactor to make frequent starts and stops. (The switching life of the inverter input circuit is about 1,000,000 times.) For parameter unit operation, an automatic restart after power failure is not made and the MC cannot be used to make a start. Note that the primary side MC may be used to make a stop but the regenerative brake specific to the inverter does not operate and the motor is coasted to a stop.
- Installation of a magnetic contactor on the primary side is recommended. Since when cycle operation or heavy-duty operation is performed with an optional brake resistor connected, overheat and burnout of the electrical-discharge resistor can be prevented if a regenerative brake transistor is damaged due to insufficient heat capacity of the electrical-discharge resistor and excess regenerative brake duty. In this case, shut-off the magnetic contactor when fault occurs and inverter trips.

## Handling of the inverter output side magnetic contactor

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned on while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided for switching to the commercial power supply, for example, switch it on/off after the inverter and motor have stopped.

## Thermal relay installation

The inverter has an electronic thermal relay function to protect the motor from overheating. However, when running multiple motors with one inverter or operating a multi-pole motor, provide a thermal relay (OCR) between the inverter and motor. In this case, set the electronic thermal relay function of the inverter to 0A. And for the setting of the thermal relay, add the line-to-line leakage current (refer to *page 62*) to the current value on the motor rating plate. For low-speed operation where the cooling capability of the motor reduces, it is recommended to use a thermal relay protector incorporated motor.

## Measuring instrument on the output side

When the inverter-to-motor wiring length is large, the meters and CTs may generate heat due to line-to-line leakage current. Therefore, choose the equipment which has enough allowance for the current rating.

## Disuse of power factor improving capacitor (power capacitor)

The power factor improving capacitor and surge suppressor on the inverter output side may be overheated or damaged by the harmonic components of the inverter output. Also, since an excessive current flows in the inverter to activate overcurrent protection, do not install a capacitor or surge suppressor. For power factor improvement, use a DC reactor (refer to *page 51*).

## Wire thickness and wiring distance

When the wiring length between the inverter and motor is long, use thick wires so that the voltage drop of the main circuit cable is 2% or less especially at low frequency output. (A selection example for the wiring distance of 20m is shown on *page 57*) Especially at a long wiring distance, the maximum wiring length should be within the length in the table below since the overcurrent protection function may be misactivated by the influence of a charging current due to the stray capacitances of the wiring. (The overall wiring length for connection of multiple motors should be within the value in the table below.)

Pr. 72 Setting (carrier frequency)	0.1K	0.2K	0.4K	0.75K	1.5K	2.2K	3.7K or more
1 or less	200V	200m	200m	300m	500m	500m	500m
2 to 15	200V	30m	100m	200m	300m	500m	500m


When using the automatic restart after instantaneous power failure function with wiring length exceeding below, select "without frequency search".

Motor Capacity	0.1K	0.2K	0.4K to 15K
Wiring Length	20m	50m	100m

Use the recommended connection cable when connecting the parameter unit.

For remote operation via analog signal, wire the control cable between the operation box or operation signal and inverter within 30m and away from the power circuits (main circuit and relay sequence circuit) to prevent induction from other devices.

When using the external potentiometer instead of the parameter unit to set the frequency, use a shielded or twisted cable, and do not earth (ground) the shield, but connect it to terminal 5 as shown below.



## Earth (Ground)


When the inverter is run in the low acoustic noise mode, more leakage currents occur than in the non-low acoustic noise mode due to high-speed switching operation. Be sure to earth (ground) the inverter and motor before use. In addition, always use the earth (ground) terminal of the inverter to earth (ground) the inverter. (Do not use the case and chassis)

## Noise

When performing low-noise operation at higher carrier frequency, electromagnetic noise tends to increase. Therefore, refer to the following measure example and consider taking the measures. Depending on the installation condition, the inverter may be affected by noise in a non-low noise (initial) status.

- The noise level can be reduced by decreasing the carrier frequency (*Pr. 72*).
- As measures against AM radio broadcasting noise, radio noise filter FR-BIF produces an effect.
- As measures against sensor malfunction, line noise filter FR-BSF01, FR-BLF produces an effect.
- As measures against induction noise from the power cable of the inverter, an effect is produced by putting a distance of 30cm (at least 10cm) or more and using a twisted pair shielded cable as a signal cable. Do not earth (ground) shield but connect it to signal common cable.

### Noise reduction examples



## Leakage currents

Capacitances exist between the inverter I/O cables, other cables and earth and in the motor, through which a leakage current flows. Since its value depends on the static capacitances, carrier frequency, etc., low acoustic noise operation at the increased carrier frequency of the inverter will increase the leakage current. Therefore, take the following measures. Select the earth leakage current breaker according to its rated sensitivity current, independently of the carrier frequency setting. (*Refer to page 58*)

### To-earth (ground) leakage currents

Type	Influence and Measures
Influence and measures	<ul style="list-style-type: none"> <li>• Leakage currents may flow not only into the inverter's own line but also into the other line through the earth (ground) cable, etc. These leakage currents may operate earth (ground) leakage circuit breakers and earth leakage relays unnecessarily.</li> <li>• Countermeasures</li> <li>• If the carrier frequency setting is high, decrease the <i>Pr. 72 PWM frequency selection</i> setting. Note that motor noise increases. Select <i>Pr. 240 Soft-PWM operation selection</i> to make the sound inoffensive.</li> <li>• By using earth leakage circuit breakers designed for harmonic and surge suppression in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).</li> </ul>
Undesirable current path	

### Line leakage current

Type	Influence and Measures
Influence and measures	<ul style="list-style-type: none"> <li>• This leakage current flows via a static capacitance between the inverter output cables.</li> <li>• The external thermal relay may be operated unnecessarily by the harmonics of the leakage current.</li> <li>• Countermeasures</li> <li>• Use <i>Pr.9 Electronic thermal O/L relay</i>.</li> <li>• If the carrier frequency setting is high, decrease the <i>Pr. 72 PWM frequency selection</i> setting. Note that motor noise increases. Select <i>Pr. 240 Soft-PWM operation selection</i> to make the sound inoffensive.</li> </ul> <p>To ensure that the motor is protected against line-to-line leakage currents, it is recommended to use a temperature sensor to directly detect motor temperature.</p>
Undesirable current path	<p style="text-align: center;">Line-to-line leakage currents path</p>

Features

Peripheral Devices

Standard Specifications

Outline Dimension Drawings

Terminal Connection Diagram Terminal Specification Explanation

Operation panel Parameter unit FR Configurator

Parameter List

Explanations of Parameters

Protective Functions

Options

Instructions

Motor

Compatibility

Warranty

Inquiry

●Harmonic suppression guideline

Harmonic currents flow from the inverter to a power receiving point via a power transformer. The harmonic suppression guideline was established to protect other consumers from these outgoing harmonic currents.

The three-phase 200V input specifications 3.7kW or less are previously covered by "Harmonic suppression guideline for household appliances and general-purpose products" and other models are covered by "Harmonic suppression guideline for consumers who receive high voltage or special high voltage". However, the transistorized inverter has been excluded from the target products covered by "Harmonic suppression guideline for household appliances and general-purpose products" in January 2004 and "Harmonic suppression guideline for household appliances and general-purpose products" was repealed on September 6, 2004.

All capacity and all models of general-purpose inverter used by specific consumers are covered by "Harmonic suppression guideline for consumers who receive high voltage or special high voltage".

- "Harmonic suppression guideline for consumers who receive high voltage or special high voltage"

This guideline sets forth the maximum values of harmonic currents outgoing from a high-voltage or especially high-voltage consumer who will install, add or renew harmonic generating equipment. If any of the maximum values is exceeded, this guideline requires that consumer to take certain suppression measures.

Users who use models other than the target models are not covered by the guideline. However, we ask to connect an AC reactor or a DC reactor as before to the users who are not covered by the guideline.

For compliance to the harmonic suppression guideline for consumers who receive high voltage or special high voltage

Input Power Supply	Target Capacity	Countermeasures
Three-phase 200V	All capacities	<p>Make a judgment based on "Harmonic suppression guideline for consumers who receive high voltage or special high voltage" issued by the Japanese Ministry of Economy, Trade and Industry (formerly Ministry of International Trade and Industry) in September 1994 and take measures if necessary. For calculation method of power supply harmonics, refer to materials below.</p> <p>Reference materials</p> <ul style="list-style-type: none"> <li>• "Harmonic suppression measures of the inverter" Jan. 2004 Japan Electrical Manufacturer's Association</li> <li>• "Calculation method of harmonic current of the general-purpose inverter used by specific consumers" JEM-TR201 (revised in Dec. 2003): Japan Electrical Manufacturer's Association Japan Electrical Manufacturer's Association</li> </ul>

For compliance to "Harmonic suppression guideline of the transistorized inverter (input current of 20A or less) for consumers other than specific consumers" published by JEMA.

Input power supply	Target capacity	Countermeasures
Three-phase 200V	3.7kW or less	<p>Connect the AC reactor or DC reactor recommended in a catalog or an instruction manual.</p> <p>Reference materials</p> <ul style="list-style-type: none"> <li>• "Harmonic suppression guideline of the general-purpose inverter (input current of 20A or less)" JEM-TR226 (revised in Dec. 2003): Japan Electrical Manufacturer's Association</li> </ul>

●Calculation of outgoing harmonic current

Outgoing harmonic current = fundamental wave current (value converted from received power voltage) × operation ratio × harmonic content

•Operation ratio: Operation ratio = actual load factor operation time ratio during 30 minutes

•Harmonic content: Found in Table.

Table 1: Harmonic Contents (Values at the fundamental current of 100%)

Reactor	5th	7th	11th	13th	17th	19th	23rd	25th
Not used	65	41	8.5	7.7	4.3	3.1	2.6	1.8
Used (AC side)	38	14.5	7.4	3.4	3.2	1.9	1.7	1.3
Used (DC side)	30	13	8.4	5.0	4.7	3.2	3.0	2.2
Used (AC, DC sides)	28	9.1	7.2	4.1	3.2	2.4	1.6	1.4

Table 2: Rated Capacities and Outgoing Harmonic Currents for Inverter Drive

Applied Motor kW	Rated Current [A]	Fundamental Wave Current Converted from 6.6kV (mA)	Rated Capacity (kVA)	Outgoing Harmonic Current Converted from 6.6kV (mA) (No reactor, 100% operation ratio)							
				5th	7th	11th	13th	17th	19th	23rd	25th
0.4	1.61	49	0.57	31.85	20.09	4.165	3.773	2.107	1.519	1.274	0.882
0.75	2.74	83	0.97	53.95	34.03	7.055	6.391	3.569	2.573	2.158	1.494
1.5	5.50	167	1.95	108.6	68.47	14.20	12.86	7.181	5.177	4.342	3.006
2.2	7.93	240	2.81	156.0	98.40	20.40	18.48	10.32	7.440	6.240	4.320
3.7	13.0	394	4.61	257.1	161.5	33.49	30.34	16.94	12.21	10.24	7.092
5.5	19.1	579	6.77	376.1	237.4	49.22	44.58	24.90	17.95	15.05	10.42
7.5	25.6	776	9.07	504.4	318.2	65.96	59.75	33.37	24.06	20.18	13.97
11	36.9	1121	13.1	728.7	459.6	95.29	86.32	48.20	34.75	29.15	20.18
15	49.8	1509	17.6	980.9	618.7	128.3	116.2	64.89	46.78	39.24	27.16

Application to standard motors

Motor loss and temperature rise


The motor operated by the inverter has a limit on the continuous operating torque since it is slightly higher in temperature rise than the one operated by a commercial power supply. At a low speed, reduce the output torque of the motor since the cooling effect decreases. When 100% torque is needed continuously at low speed, consider using a constant-torque motor. (Refer to page 65)

Torque characteristic

The motor operated by the inverter may be less in motor torque (especially starting torque) than the one driven by the commercial power supply. It is necessary to fully check the load torque characteristic of the machine.

Motor torque

When the Mitsubishi standard squirrel-cage motor (SF-JR, 4-pole) and inverter of the same capacity are used, the torque characteristics are as shown below.



\*1 Continuous operation torque is for checking the limit of permissible load torque when using the motor within the permissible ambient temperature, and is not the motor output torque itself. Maximum torque for short time is the amount of torque a motor can output.  
 \*2 Depending on the motor capacity or the number of motor poles, the operation at 60Hz or more may not be performed. Make sure to check the permissible maximum operating frequency of the motor.  
 \*3 A 60Hz torque reference indicates that the rated torque of the motor run at 60Hz is 100%, and a 50Hz torque reference indicates that the rated torque of the motor run at 50Hz is 100%.

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

## Application to constant-torque motors


### SF-HRCA type (Advanced magnetic flux vector control)

- Continuous operation with 100% torque even at low speed of 3Hz is possible  
Load torque is not need to be reduced even at a low speed and constant torque (100% torque) continuous operation is possible within the range of speed ratio 1/20 (3 to 60Hz). (The characteristic of motor running at 60Hz or more is that output torque is constant.)
- Installation size is the same as that of the standard motor
- ★ Note that operation characteristic in the chart below can not be obtained if V/F control is employed.

### Standard specifications (indoor type)

Output (kW)	Number of Poles	Frequency Range	Common Specifications
0.2	4	3 to 120Hz	Standard frequency 60Hz ● rotation direction (CCW) is counterclockwise when viewed from the motor end ● Lead wire 3.7kW or less ..... 3 wires 5.5kW or more ... 6 or 12 wires ● Ambient temperature: 40°C maximum Protective structure is IP44
0.4			
0.75			
1.5			
2.2			
3.7			
5.5			
7.5			
11			
15	3 to 100Hz		

- Torque characteristic (during advanced magnetic flux vector control, and initial value for other parameters)



- \* Please contact us separately when 150% or more of maximum torque for short time is necessary.
- When rapid acceleration/deceleration is needed, the inverter capacity may need to be one rank higher.
- When two or more motors are operated in parallel, torque imbalance is likely to occur as motor slip is smaller than that of the standard motor.

## Application to geared motor


### GM-S, GM-D, GM-SY, GM-HY2 series

- Wide constant torque range even with the standard type (when using advanced magnetic flux vector control)  
Load torque is not need to be reduced even at a low speed and constant torque (100% torque) continuous operation is possible within the range of speed ratio 1/20 (3 to 60Hz). (0.1K to 0.75K)
- Wide speed control range  
The motor can be used in the wide speed deviation range of 3 to 120Hz  
The characteristic of motor running at 60Hz or more is that output torque is constant. (0.1K to 0.75K)  
★Note that operation characteristic in the chart below can not be obtained if V/F control is employed.

### Standard specifications

Inverter Type	Output (kW)	Number of Poles	Available Frequency Range (base frequency 60Hz)		Constant Torque Range When Using Advanced Magnetic Flux Vector Control	
			Grease Lubrication	Oil Lubrication		
GM-S GM-SY GM-HY2	0.1 to 2.2	4	3 to 120Hz		3 to 60Hz (0.1kW to 0.75kW) 6 to 60Hz (1.5kW, 2.2kW)	
GM-D	0.4 to 2.2		3 to 120Hz	25 to 120Hz	25 to 115Hz	3 to 60Hz (0.4kW, 0.75kW) 6 to 60Hz (1.5kW, 7.5kW)
	3.7					
	5.5					
	7.5					

- Torque characteristic (range during advanced magnetic flux vector control)



- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram
- Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

## Application to special motors

### Motor with brake

Use the motor with brake having independent power supply for the brake, connect the brake power supply to the inverter input side power and make the inverter output off using the output stop terminal (MRS) when the brake is applied (motor stop). Rattle may be heard according to the type of the brake in the low speed region but it is not a fault.

### Pole changing motor

As this motor differs in rated current from the standard motor, confirm the maximum current of the motor and select the inverter. Be sure to change the number of poles after the motor has stopped. If the number of poles is changed during rotation, the regenerative overvoltage protection circuit may be activated to cause an inverter alarm, coasting the motor to a stop.

### Submersible motor

Since the motor rated current is larger than that of the standard motor, make selection of the inverter capacity carefully. In addition, the wiring distance between the motor and inverter may become longer, refer to page 57 to perform wiring with a cable thick enough. Leakage current may flow more than the land motor, take care when selecting the earth leakage current breaker.

### Explosion-proof motor

To drive an explosion-proof type motor in Japan, an explosion-proof test of the motor and inverter together is necessary. The test is also necessary when driving an existing explosion-proof motor. Please contact us for the FR-B, B3 series, which has passed an explosion-proof test. The inverter is a non-explosion proof structure, install it in a safety location.

### Geared motor

The continuous operating rotation range of this motor changes depending on the lubrication system and maker. Especially in the case of oil lubrication, continuous operation in the low-speed range only can cause gear seizure. For fast operation at higher than 60Hz, please consult the motor maker.

### Synchronous motor

This motor is not suitable for applications of large load variation or impact, where out-of-sync is likely to occur. Please contact us when using this motor because its starting current and rated current are greater than those of the standard motor and will not rotate stably at low speed.

### Single phase motor

The single phase motor is not suitable for variable operation by the inverter.

For the capacitor starting system, the capacitor may be damaged due to harmonic current flowing to the capacitor. For the deviation phase starting system and repulsion starting system, not only output torque is not generated at low speed but it will result in starting coil burnout due to failure of centrifugal force switch inside. Replace with a three-phase motor for use.

# Main Differences and Compatibilities with the FR-E500 series

Item	FR-E500	FR-E700
Control method	V/F control General-purpose magnetic flux vector control	V/F control General-purpose magnetic flux vector control Advanced magnetic flux vector control Optimum excitation control
Changed/cleared functions	Torque boost (Pr. 0) initial value FR-E520-1.5K to 7.5K: 6%	FR-E720-1.5K to 3.7K: 4% FR-E720-5.5K to 7.5K: 3%
	DC injection brake operation voltage (Pr.12) initial value FR-E520-0.4K to 7.5K: 6%	FR-E720-0.4K to 7.5K: 4%
	Frequency at 5V (10V) input (Pr. 38 ) Frequency at 20mA input frequency (Pr. 39 ) Second electronic thermal O/L relay (Pr. 48 ) Shortest acceleration/deceleration mode (Pr. 60 )	Parameter number change (Pr. 125 Terminal 2 frequency setting gain frequency) (Pr. 126 Terminal 4 frequency setting gain frequency) (Pr. 51 Second electronic thermal O/L relay) (Pr. 60 Energy saving control selection) (Pr. 292 Automatic acceleration/deceleration)
	Reverse rotation from the inverter operation panel  Press  .	After setting "1" in Pr. 40 RUN key rotation direction selection , press  .
	FM terminal function selection (Pr. 54 ) setting 0: Output frequency (initial value), 1: Output current, 2: Output voltage	1: Output frequency (initial value), 2: Output current, 3: Output voltage
	Second applied motor Pr. 71 = 100 to 123	Pr. 450 Second applied motor
	Terminal 2 0 to 5V, 0 to 10V selection (Pr. 73 ) setting 0: 0 to 5V (initial value), 1: 0 to 10V	Pr. 73 Analog input selection 0: 0 to 10V 1: 0 to 5V (initial value)
	Operation mode selection (Pr. 79 ) Initial value 1: PU operation mode	Initial value 0: External operation mode is selected at power on
	Setting 8: Operation mode switching by external signal	Setting 8: deleted (X16 signal is used instead)
	Setting general-purpose magnetic flux vector Pr. 80 ≠ 9999	Pr. 80 ≠ 9999, Pr. 81 ≠ 9999, Pr. 800 = 30
	User group 1 (16), user group 2 (16) (Pr. 160, Pr. 173 to Pr. 175 )	User group (16) only, setting methods were partially changed (Pr. 160, Pr. 172, Pr. 173 )
	Input terminal function selection (Pr. 180 to Pr. 183 ) setting 5: MRS signal (output stop) 6: STOP signal (start self-holding selection)	Pr. 178 to Pr. 184 Input terminal function selection setting 5: JOG signal (jog operation selection) 6: None 24: MRS signal (output stop) 25: STOP signal (start self-holding selection)
	Cooling fan operation selection (Pr. 244 ) initial setting 0: Cooling fan operates in power-on status.	1: Cooling fan on/off control valid
	Stop selection (Pr. 250 ) setting increments 1s	0.1s
RS-485 communication control source from the PU connector PU operation mode	Network operation mode (use Pr. 551 to change)	
Inrush current limit circuit	Provided for the 200V class 2.2K or more and 400V class	Provided for the all capacity
Control terminal block	Fixed terminal block (can not be removed) (+ screw M2.5)	Removable terminal block (- screw M2 (M3 for terminal A, B, and C only)
Operation panel	Removable operation panel (PA02)	Integrated operation panel (can not be removed)
PU	FR-PU04	FR-PU07 FR-PU04 (some functions, such as parameter copy, are unavailable.)
Plug-in option	Dedicated plug-in option (installation is incompatible)	
	for 400V class only FR-E5NC : CC-Link communication FR-E5ND : DeviceNet communication FR-E5NL : LonWORKS communication	FR-A7AX E kit : 16bit digital input FR-A7AY E kit: Digital output, Extension analog output FR-A7AR E kit: Relay output FR-A7NC E kit : CC-Link communication FR-A7ND E kit : DeviceNet communication * FR-A7NP E kit : PROFIBUS-DP communication * FR-A7NL E kit : LonWORKS communication * * : to be released soon
Installation size	0.1 to 7.5K are compatible in mounting dimensions	

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Diagram Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry

## Warranty

### 1. Gratis warranty period and coverage

#### [Gratis warranty period]

Note that an installation period of less than one year after installation in your company or your customer's premises or a period of less than 18 months (counted from the date of production) after shipment from our company, whichever is shorter, is selected.

#### [Coverage]

##### (1) Diagnosis of failure

As a general rule, diagnosis of failure is done on site by the customer.

However, Mitsubishi or Mitsubishi service network can perform this service for an agreed upon fee upon the customer's request.

There will be no charges if the cause of the breakdown is found to be the fault of Mitsubishi.

##### (2) Breakdown repairs

There will be a charge for breakdown repairs, exchange replacements and on site visits for the following four conditions, otherwise there will be a charge.

1) Breakdowns due to improper storage, handling, careless accident, software or hardware design by the customer.

2) Breakdowns due to modifications of the product without the consent of the manufacturer.

3) Breakdowns resulting from using the product outside the specified specifications of the product.

4) Breakdowns that are outside the terms of warranty.

Since the above services are limited to Japan, diagnosis of failures, etc. are not performed abroad.

If you desire the after service abroad, please register with Mitsubishi. For details, consult us in advance.

### 2. Exclusion of opportunity loss from warranty liability

Regardless of the gratis warranty term, compensation to opportunity losses incurred to your company or your customers by failures of Mitsubishi products and compensation for damages to products other than Mitsubishi products and other services are not covered under warranty.

### 3. Repair period after production is discontinued

Mitsubishi shall accept product repairs for seven years after production of the product is discontinued.

### 4. Terms of delivery

In regard to the standard product, Mitsubishi shall deliver the standard product without application settings or adjustments to the customer and Mitsubishi is not liable for on site adjustment or test run of the product.

**International FA Center**



**●FA Center in North America**

Mitsubishi Electric Automation, Inc.  
500 Corporate Woods Parkway, Vernon Hills, IL60061  
TEL. +1-847-478-2100 FAX. +1-847-478-0327

**●FA Center in Taiwan**

Setsuyo Enterprise Co., Ltd.  
6F No.105, Wu Kung 3rd RD, Wu-Ku Hsiang Taipei Hsien, Taiwan(R.O.C.)  
TEL. +886-2-2299-2499 FAX. +886-2-2299-2509

**●FA Center in Korea**

MITSUBISHI ELECTRIC AUTOMATION KOREA Co., Ltd. (Service)  
B1F,2F, 1480-6, Gayang-Dong, Gangseo-Gu, Seoul, 157-200, KOREA  
TEL. +82-2-3660-9607 FAX. +82-2-3664-0475

**●FA Center in Beijing**

Mitsubishi Electric Automation (SHANGHAI) Ltd. Beijing Office  
Unit 908, 9F, Office Tower 1, Henderson Centre, 18 Jianguomennei Avenue, Dongcheng District, Beijing, China 100005  
TEL. +86-10-6518-8830 FAX. +86-10-6518-8030

**●FA Center in Tianjin**

Mitsubishi Electric Automation (SHANGHAI) Ltd. Tianjin Office  
B-2-801-802, Youyi Building, 50 Youyi Road, Hexi District, Tianjin, China 300061  
TEL +86-22-2813-1015 FAX. +86-22-2813-1017

**●FA Center in Shanghai**

Mitsubishi Electric Automation (SHANGHAI) Ltd.  
4/F Zhi Fu Plazz, No.80 Xin Chang Road, Shanghai, China 200003  
TEL. +86-21-6121-2460 FAX. +86-21-6121-2424

**●FA Center in ASEAN**

Mitsubishi Electric Asia Pte. Ltd. ASEAN Factory Automation Centre  
307 Alexandra Road #05-01/02, Mitsubishi Electric Building, Singapore 159943  
TEL. +65-6470-2480 FAX. +65-6476-7439

**●FA Center in Hong Kong**

Mitsubishi Electric Automation (HONGKONG) Ltd.  
10th Floor, Manulife Tower, 169 Electric Road, North Point, Hong Kong  
TEL. +852-2887-8870 FAX. +852-2887-7984

**●FA Center in Europe**

Mitsubishi Electric Europe B.V. - German Branch Factory Automation European Business Group  
Gothaer Strasse 8, D-40880 Ratingen, Germany  
TEL. +49-2102-486-0 FAX. +49-2102-486-1120

**●FA Center in England**

Mitsubishi Electric Europe B.V. UK Branch Automation Systems Division  
Travellers Lane, Hatfield, Hertfordshire, AL10 8XB, UK.  
TEL. +44-1707-276100 FAX. +44-1707-278695

**●FA Center in Thailand**

Mitsubishi Electric Automation(Thailand) Co., Ltd.  
Bang-Chan Industrial Estate No.111, Soi Serithai 54, T.Kannayao, A.Kannayao, Bangkok 10230  
TEL. +66-2-906-3238 FAX. +66-2-906-3239

- Features
- Peripheral Devices
- Standard Specifications
- Outline Dimension Drawings
- Terminal Connection Program Terminal Specification Explanation
- Operation panel Parameter unit FR Configurator
- Parameter List
- Explanations of Parameters
- Protective Functions
- Options
- Instructions
- Motor
- Compatibility
- Warranty
- Inquiry